

# **Installation Guide**

# **Mounting**

1. From the MEP-4xxx actuator, remove and discard the V-bolt.


2. Assemble and install the kit and actuator as shown in the diagram below.

NOTE: In general, position both the ball joints as close to the end of the crank arms as is feasible for the application. Positioning a ball joint in the slot closer to the shaft will change the torque, rotation speed, and/or angle of rotation—which may be useful for some applications.

NOTE: Check for potential issues such as binding of the linkage or damage caused by the actuator still rotating when the damper (or other application) is already closed.

NOTE: See the Accessories section for an auxiliary crank arm if the damper or other equipment does not have one already installed.

NOTE: For much more information about installing MEP-4xxx actuators, see the MEP-4xxx Applications Guide on the KMC web site (www.kmccontrols.com) as well as the relevant installation guide.



HLO-4001 1 Installation Guide

#### Maintenance ■

Under normal conditions, no routine maintenance is required. In harsh environments, however, periodic lubrication of the ball joints may be necessary.

Each component is designed for dependable, longterm reliability and performance. Careful installation will also help ensure long-term reliability and performance.

### Accessories

#### **Auxiliary Crank Arms**



VTD-1403\* Short slotted, for 3/8" shafts
VTD-1404\* Short slotted, for 1/2" shafts
VTD-1405\* Long slotted, for 1/2" shafts
VTD-1406\* Long slotted, for 3/8" shafts

\*NOTE: In the VTD-1403/1404 short crank arms, a ball joint can be adjusted from 3/4 inches (minimum) from the center of the shaft to 2-7/8 inches (maximum) from the center. In VTD-1405/1406 long crank arms, the maximum is 4-5/8 inches.



VTD-1414 Three-hole, for 3/8" shafts VTD-1415 Three-hole, for 1/2" shafts

#### **Replacement Ball Joints**



VTD-0804

Ball joint for side-mounted 5/16" diameter rods (1/4-20 male mounting stud with locknut)

### More Information

For additional information about installing MEP-4xxx actuators, see the **MEP-4xxx Applications Guide** on the KMC web site (www.kmccontrols.com) as well as the relevant installation guide.

## **Important Notices**

The KMC logo and KMC Controls are registered trademarks of KMC Controls, Inc.

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of KMC Controls, Inc.

The material in this document is for information purposes only. The contents and the product it describes are subject to change without notice. KMC Controls, Inc. makes no representations or warranties with respect to this document. In no event shall KMC Controls, Inc. be liable for any damages, direct or incidental, arising out of or related to the use of this document

KMC Controls, Inc. 19476 Industrial Drive New Paris, IN 46553 574.831.5250 www.kmccontrols.com info@kmccontrols.com

© 2023 KMC Controls, Inc. 705-019-04D