



KMC Conquest™ Gen6 Controller

Application Guide

Do you find this document to be helpful? Click here to share feedback and help us improve:
[Give Feedback](#)



Contents

| | |
|---|-----------|
| GENERAL INFORMATION | 4 |
| About KMC Conquest | 4 |
| Specifications, Accessories, and Installation | 4 |
| Video Tutorials | 5 |
| Submittal Sheets (Diagrams and Operation) | 5 |
| Support | 6 |
| Important Notices | 6 |
| Notes and Cautions | 6 |
| Handling Precautions | 6 |
| STATUS INDICATORS | 7 |
| Indicators, Connections, and Status | 7 |
| Ready (Power/Status) LEDs (Green) | 7 |
| MS/TP LEDs (Amber) | 7 |
| EIO LEDs (Green) | 8 |
| Network Isolation Bulbs (HPO-0055) | 8 |
| Ethernet LEDs (Green and Amber) | 8 |
| CONNECTIONS (SENSORS, EQUIPMENT, NETWORKS) | 9 |
| Input Connections (Room Sensor Port) | 9 |
| Dedicated Use of (STE-9000/6000) Room Sensor Port | 9 |
| Digital STE-9000 Series NetSensors | 10 |
| STE-93xx/95xx CO ₂ Sensor and DCV | 10 |
| Analog STE-6000 Series Thermistor Sensors | 12 |
| Input Connections (Universal, Terminals) | 13 |
| Output Connections | 14 |
| Connecting Universal Outputs | 14 |
| Grounds Versus Switched (Relay) Commons | 14 |
| Installing Override Boards in BAC-5900A/CAN-5900 Series | 15 |
| Connecting a VAV Remote Actuator to a BAC-9311A(C)(E) | 17 |
| MS/TP Network Connections | 19 |
| Connections and Wiring | 19 |
| EOL (End of Line) Termination Switches | 20 |
| Temporary Network Connection | 20 |
| Ethernet Network Connections | 21 |
| Power (Controller) Connections | 22 |
| CONFIGURATION | 24 |
| Configuring, Programming, and Designing | 24 |
| NFC (Near Field Communication) | 25 |
| Passwords | 25 |

| | |
|---|-----------|
| Controller Configuration with STE-9xx1 Menus | 26 |
| Restore (RSTR) and Application/Units Selection..... | 30 |
| VAV Airflow Balancing with an STE-9xx1 | 31 |
| RESETTING AND TROUBLESHOOTING..... | 34 |
| Resetting Controllers..... | 34 |
| Types of Reset | 34 |
| Warm and Cold Starts | 34 |
| Troubleshooting | 35 |
| Communication Issues | 35 |
| LED Indicators and Isolation Bulbs Issues..... | 36 |
| Hardware Issues | 37 |
| Input Issues | 37 |
| Output Issues | 39 |
| NetSensor Display is Blank | 40 |
| Power Issues | 40 |
| VAV Airflow Issues | 40 |
| Configuration, Programming, and Operation Issues..... | 41 |
| Web Page Issues (Ethernet Models) | 42 |
| Other Issues | 42 |
| MAINTENANCE AND UPGRADES..... | 43 |
| Maintenance | 43 |
| Controller Upgrades and Cross-References | 43 |
| SEQUENCES OF OPERATIONS..... | 45 |
| AHU (Air Handling Unit) | 45 |
| CAV (Constant Air Volume)..... | 45 |
| FCU (Fan Coil Unit) | 46 |
| Introduction (FCU) | 47 |
| Room Temperature Setpoints (FCU) | 47 |
| Occupancy, Motion Sensing, and Standby (FCU) | 48 |
| System Mode and Cooling/Heating Changeover (FCU) | 49 |
| Scheduling Occupancy (FCU)..... | 49 |
| Dehumidification Sequence (FCU) | 49 |
| Temperature Sensing Inputs (FCU) | 50 |
| Fan Status (FCU) | 50 |
| PID (Proportional Integral Derivative) Loops (FCU)..... | 50 |
| Valve Operation (FCU) | 51 |
| Fan Operation (FCU)..... | 52 |
| HPU (Heat Pump Unit) | 54 |
| Introduction (HPU) | 54 |
| Room Temperature Setpoints (HPU) | 55 |
| Occupancy, Motion Sensing, and Standby (HPU) | 56 |
| System Mode and Cooling/Heating Changeover (HPU)..... | 57 |
| Scheduling Occupancy (HPU) | 57 |
| Dehumidification Sequence (HPU)..... | 57 |
| Temperature Sensing Inputs (HPU)..... | 58 |
| Fan Status (HPU)..... | 58 |

| | |
|--|-----|
| PID (Proportional Integral Derivative) Loops (HPU) | 58 |
| Staged Heating And Cooling (HPU)..... | 59 |
| Fan Operation (HPU) | 59 |
| Economizer Cooling (HPU) and DCV | 60 |
| Reversing Valve Action (HPU) | 60 |
| Auxiliary and Emergency Heat Action (HPU) | 61 |
| RTU (Roof Top Unit) or AHU (Air Handling Unit)..... | 62 |
| Introduction (RTU/AHU)..... | 62 |
| Room Temperature Setpoints (RTU/AHU) | 63 |
| Occupancy, Motion Sensing, and Standby (RTU/AHU) | 64 |
| System Mode & Cooling/Heating Changeover (RTU/AHU)..... | 65 |
| Scheduling Occupancy (RTU/AHU) | 65 |
| Dehumidification Sequence (RTU/AHU)..... | 65 |
| Temperature Sensing Inputs (RTU/AHU)..... | 65 |
| Fan Status (RTU/AHU)..... | 66 |
| PID (Proportional Integral Derivative) Loops (RTU/AHU) | 66 |
| Modulating Cooling and Heating (RTU/AHU) | 66 |
| Staged Heating And Cooling (RTU/AHU)..... | 67 |
| Fan Control (RTU/AHU)..... | 68 |
| Economizer Cooling (RTU/AHU) and DCV (RTU)..... | 68 |
| VAV (Variable Air Volume)..... | 69 |
| Introduction (VAV)..... | 70 |
| Sensors (VAV) | 71 |
| Room Temperature Setpoints (VAV) | 72 |
| Occupancy, Motion Sensing, and Standby (VAV) | 73 |
| Scheduling Occupancy (VAV) | 74 |
| PID (Proportional Integral Derivative) Loops (VAV) | 74 |
| Airflow Setpoints Sequence (VAV) | 75 |
| Cooling/Heating Changeover (VAV) | 75 |
| Discharge Air Temperature (DAT) Limiting (VAV) | 75 |
| Reheat (VAV)..... | 76 |
| Damper Operation (VAV)..... | 77 |
| Fan Operation (VAV) | 77 |
| Dual Duct (VAV) | 78 |
| Balancing Airflow (VAV) | 78 |
| System Diagnostics (VAV) | 79 |
| SYSTEM INTEGRATION AND NETWORKING | 80 |
| Networking | 80 |
| BACnet Objects List | 80 |
| General Notes..... | 80 |
| BAC-5900A Series (General Purpose Controller) Objects | 81 |
| BAC-9000A Series (VAV Controller) Objects | 82 |
| BAC-9300A Series (Unitary Controller) Objects | 91 |
| APPENDIX: K FACTORS FOR VAV | 106 |
| WE VALUE YOUR FEEDBACK! | 106 |
| INDEX | 107 |

GENERAL INFORMATION

About KMC Conquest

KMC Conquest controllers are fully programmable, native BACnet controllers with integrated alarming, trending, and scheduling. This applications guide provides expanded installation information, sequences of operation, troubleshooting, and other information. For additional installation instructions, see the installation guides for the respective products.

NOTE: The KMC Conquest Gen6 line (designated by an “A” suffix) replaced the original Gen5 series beginning in 2024. See the [KMC Conquest Controller Application Guide](#) for information specific to Gen5 models.

| TERMINAL COLOR CODE | |
|---------------------|------------------------------|
| Black | 24 VAC/VDC Power |
| Gray | MS/TP and CAN Communications |
| Green | Inputs and Outputs |




Illustration: Controller Overview (BAC-5901AC shown)

Specifications, Accessories, and Installation

See the relevant KMC Conquest documents for:

- [BAC-5900A Series BACnet General Purpose Controllers](#)
- [CAN-5900 Series I/O Expansion Modules](#)
- [BAC-9000A Series BACnet VAV Controller-Actuators](#)
- [BAC-9300A Series BACnet Unitary Controllers](#)
- [STE-9000 Series NetSensors Digital Room Sensors](#)
- [TSP-8003 \(Dual Duct\) Tri-State Actuator with Pressure Sensor](#)

See also the [Conquest Selection Guide](#) and the [BAC-5051AE BACnet Router](#).

For the STE-9000 Series NetSensors, see also the [Room Sensor and Thermostat Mounting and Maintenance Application Guide](#).

For 4–20 ma applications, see also the [4–20 mA Wiring for Controllers Application Guide](#).

See also the assorted Conquest videos on [KMC's YouTube channel](#).




Illustration: KMC YouTube Channel Videos

Submittal Sheets (Diagrams and Operation)

BAC-9300A series unitary controllers and BAC-9000A series VAV controllers have a collection of submittal sheets for common applications available through the KMC Connect, TotalControl, or Converge configuration wizards. The submittal sheets include wiring diagrams and sequences of operation.




Illustration: Sample (VAV) Submittal Sheet

See the applications library in KMC Connect, TotalControl, or KMC Converge to download the sheets.

Support

Additional resources for installation, configuration, application, operation, programming, upgrading and much more are available on the KMC Controls web site (www.kmccontrols.com). Log-in to see all available files.



Important Notices

KMC Controls® and NetSensor® are all registered trademarks of KMC Controls. KMC Conquest™, KMC Commander™, KMC Connect™, KMC Connect Lite™, KMC Converge™, and TotalControl™ are all trademarks of KMC Controls. All other products or name brands mentioned are trademarks of their respective companies or organizations.

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of KMC Controls, Inc.

The material in this document is for information purposes only. **The contents and the product it describes are subject to change without notice.** KMC Controls, Inc. makes no representations or warranties with respect to this document. In no event shall KMC Controls, Inc. be liable for any damages, direct or incidental, arising out of or related to the use of this document.

Specifications and design are subject to change without notice.

Notes and Cautions

NOTE: In this document, a **NOTE** provides additional information that is important.

⚠ CAUTION

In this document, a CAUTION indicates potential personal injury or equipment or property damage if instructions are not followed.

Handling Precautions

For **digital and electronic** sensors, thermostats, and controllers, take reasonable precautions to prevent electrostatic discharges to the devices when installing, servicing, or operating them. Discharge accumulated static electricity by touching one's hand to a securely grounded object before working with each device.



STATUS INDICATORS

Indicators, Connections, and Status

Indicators show the status of connections and the controller. Indicator actions are described below. For **troubleshooting** faulty operation, see [LED Indicators and Isolation Bulbs Issues on page 36](#).




Illustration: Indicators (BAC-5901AC)




Illustration: Indicators (BAC-9001AC)

Ready (Power/Status) LEDs (Green)

Within a few seconds after power is first applied, the green Ready (power/status) LED near the power terminals will begin flashing (on for a second and then off for a second) if the device is functioning normally.

MS/TP LEDs (Amber)

The (optional) MS/TP network has an amber LED that flickers as it receives and passes the token during communication with the network. When the controller is powered up (but not communicating on the MS/TP port), these amber LEDs will flash slowly, about once per second. When the MS/TP port establishes communications with the network, the amber LED for that MS/TP port will flash rapidly (multiple times a second) as it receives and passes the token.

EIO LEDs (Green)

For BAC-5900A series controllers with connected CAN-5900 series expansion modules, the EIO (Expansion Input Output) network (also known as a CAN bus) has a green LED (on each end) that flickers as it receives and passes the token during communication with the network. See the [CAN-5900 Series Installation Guide](#) for more information.

Network Isolation Bulbs (HPO-0055)

MS/TP and EIO networks have an assembly of two isolation bulbs located near the network terminals. Normally the bulbs are not illuminated. One or both bulbs illuminated indicates that the network is improperly phased (the ground potential of the controller/module is not the same as on other controllers/modules on the network).




Illustration: Ethernet Indicators

Ethernet LEDs (Green and Amber)

(Optional) Ethernet network connectors have two built-in LEDs:

- The amber LED illuminates when the controller has power and is communicating at its highest speed (100BaseT). (It is off when the connection is communicating at 10BaseT.)
- The green LED will blink at a rate in accordance to Ethernet traffic.
- If neither LED is illuminated, controller is unpowered or there is a faulty Ethernet connection.

The dual Ethernet ports on KMC Conquest Gen6 controllers function as Ethernet switches to other controllers as well as interfaces within each controller. This allows daisy-chaining of Ethernet models. See **Daisy-Chaining Conquest Ethernet Controllers Technical Bulletin (TB160426)** for more information.

NOTE: The Ethernet ports in the BAC-90xxACE VAV controllers are immediately **next** to the Room Sensor port. The Ethernet ports on the BAC-93xxACE and BAC-59xxACE controllers are on the opposite side from the Room Sensor port.

CONNECTIONS (SENSORS, EQUIPMENT, NETWORKS)

Input Connections (Room Sensor Port)

Dedicated Use of (STE-9000/6000) Room Sensor Port

⚠ CAUTION

On Conquest “E” models, do NOT plug a cable meant for Ethernet communications into the Room Sensor jack. The Room Sensor port powers a NetSensor, and the supplied voltage may damage an Ethernet card, switch, or router to which it is accidentally connected. See [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#).




Illustration: Room Sensor and Dual Ethernet Ports

NOTE: The Room Sensor port is immediately **next** to the Ethernet ports in the BAC-90xxACE VAV controllers. It is on the **opposite** side on BAC-93xxACE and BAC-59xxACE controllers.

NOTE: The input objects AI1 and AI2 are dedicated for use with analog electronic STE-6010, STE-6014, and STE-6017 sensors, but not digital STE-9xx1 NetSensors. See [Analog STE-6000 Series Thermistor Sensors on page 12](#). When a NetSensor is connected to the port, AI1 and AI2 will appear in software to be unused. The NetSensor digitally communicates with the value objects AV1, AV3, and AV4. See [Digital STE-9000 Series NetSensors on page 10](#).

NOTE: For additional information on value objects, see [BACnet Objects List on page 80](#).

NOTE: AI1 and AI2 can be used with other sensors by connecting to Pin 3 and Pin 1 and/or Pin 8 of an RJ45-type modular connector inserted in the Room Sensor port. See [Illustration: Room Sensor Port Pinouts on page 10](#).

Pin 1 = Setpoint Signal to Controller (AI2)
 Pin 3 = Ground Reference
 Pin 8 = Temperature Signal to Controller (AI1)




Illustration: Room Sensor Port Pinouts

Digital STE-9000 Series NetSensors



STE-90xx/93xx



STE-92xx/95xx
with Motion Sensor

Illustration: STE-9000 Series NetSensors

These KMC Conquest digital wall sensors include a room temperature sensor, optional sensors (humidity, motion, and/or CO₂), a digital display, and a push-button interface for entering setpoints and configuring the controllers. Connection is made using a standard Ethernet patch cable. If an STE-9000 series sensor is detected, the sensor's temperature is mapped to the Space Temperature Reference value object (AV1) as the temperature input value. The cooling and heating setpoints are mapped to Active Cooling Setpoint (AV4) and Active Heating Setpoint (AV5).

For information about using the NetSensor to configure Conquest controllers, see [Controller Configuration with STE-9xx1 Menus on page 26](#), [Restore \(RSTR\) and Application/Units Selection on page 30](#), and [VAV Airflow Balancing with an STE-9xx1 on page 31](#).

NOTE: If the display remains blank after plugging it in, see [NetSensor Display is Blank on page 40](#).

STE-93xx/95xx CO₂ Sensor and DCV

The space CO₂ level read by an STE-93xx/95xx sensor always maps to AV57.

DCV (Demand Control Ventilation) is available in a KMC Conquest controller (only) when all five of these conditions are met:

- A **BAC-93xxA** controller is used.
- The **HPU or RTU** application is chosen.
- An **economizer** is enabled.
- An **STE-93x1/95x1** NetSensor is connected to the Room Sensor port.
- **AND** the controller firmware is **R1.0.0.6** or higher.

After all the DCV conditions are met, adjust these settings:

- **DCV, which is disabled by default** (under **CO2** in the NetSensor System menu or BV29). Enable it to use it.
- **CO2 Setpoint** (800 ppm default), which is the value at which DCV control of the economizer damper position begins (under **CO** in the NetSensor Setpoint menu or AV59).
- **CO2 Range** (200 ppm default), which proportionally controls the economizer damper position for a given CO₂ reading above the setpoint (under **CORA** in the NetSensor Setpoint menu or AV58).




Illustration: DCV Control Sequence

NOTE: At the bottom of the CO₂ range, the damper is at the minimum position (assuming there is no other demand on the economizer). At the top of the range, the damper opens to the maximum value. For example, with the defaults and no other ventilation demand, the damper position would be at its minimum for a CO₂ reading of 800 ppm and at its maximum for a CO₂ reading of 1000 ppm or higher.

For **other applications and/or controllers**, application programming that references the (AV57) CO₂ value may be added to the controller either by modifying the factory application programming or by adding Control Basic logic in an unused program.

NOTE: Alternatively, to use an easy (menu-configurable) yet advanced DCV solution for AHU, RTU, FCU, and HPU applications, see the integrated sensor-and-controller **BAC-13xxx and BAC-14xxx series of FlexStats**.

NOTE: The STE-93xx/95xx CO₂ sensor uses a **self-calibration** technique designed to be used **in applications where CO₂ concentrations will periodically drop to outside ambient conditions (approximately 400 ppm)**, typically during unoccupied periods. The sensor will typically reach its **operational accuracy after 25 hours of continuous operation if it was exposed to ambient reference levels of air at 400 ±10 ppm CO₂**. The sensor will **maintain accuracy specifications if it is exposed to the reference value at least four times in 21 days**. (There is no provision for calibrating with gas.)

NOTE: For troubleshooting tips, see **Demand Control Ventilation (DCV) Is Not Available or Working Properly on page 37**.

Analog STE-6000 Series Thermistor Sensors




Illustration: STE-601x Sensors Compatible with Room Temp. Port

Three models of the STE-6000 series sensors are compatible with the Room Sensor port on KMC Conquest controllers. If an **STE-6010, STE-6014, or STE-6017** is connected to the Room Sensor port (with a standard Ethernet patch cable), the sensor's **temperature** from AI1 is automatically mapped to the Space Temperature Reference value object (AV1) as the temperature input value.

The **HPO-9005** room sensor adapter allows the use of other sensors and optional setpoint potentiometers to be used instead (e.g., an **STE-6011** or **STE-6019**). This provides the means of reusing an existing suitable sensor and wiring in a retrofit application or using a different kind of sensor (e.g., a flat plate sensor such as a **STE-1430**) for new installations.

NOTE: Other STE-6000 series sensors with terminals can be used with the controller's terminals.

The STE-6014 and STE-6017 include a **dial** for adjusting the zone **setpoint**. If either of these two sensors is detected, the reading of the dial setting (AI2) is mapped to the Setpoint Offset (AV2).

The default range of the setpoint offset (AV2) is plus or minus 3 for °F applications (or 1.5 for °C applications). This means that, **with the STE-6014/6017, users can adjust the scheduled setpoint a maximum of three degrees up or down (e.g., 69 to 75 for a scheduled setpoint of 72°)**. To change the maximum range (using KMC Connect or TotalControl):

- Change the relinquished default value (of 3) in AV12. (AV12 is the standby offset typically used with occupancy control). AI2 is mapped to AV2 (with a multiplier AV12) for the setpoint offset, and AV2 is the value used in room temperature control programming (not AI2 directly). $AV2 = AI2 \times AV12$. (If $AV12 = 1$, then $AV2 = AI2$.) See the **HPO-9005 Room Sensor Adapter Installation Guide** for more information about configuration.
- Alternately, import custom table values into (Table Object) Input Table 4. (See the software documentation for more information.)

An STE-6017/6019 sensor also includes a button that shunts the thermistor when pushed (SENSORON in Control Basic) to indicate **override** of an unoccupied state. Local Override (e.g., BV4 in a BAC-9001) then becomes Active until the Local Override Timer (AV38) value is exceeded. (The controller

performs the override function automatically, and no additional programming using SENSORON is required.)

NOTE: The override button needs to be pressed and held for at least a half a second to be reliably recognized for override mode.

Input Connections (Universal, Terminals)

NOTE: On Conquest controllers, Inputs 1 and 2 are dedicated to the Room Sensor port. Terminals on removable green blocks start with Input 3. (See [Illustration: Controller Overview \(BAC-5901AC shown\) on page 4](#) and [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#).) The input object AI1 is dedicated to the room temperature, and object AI2 is dedicated to room temperature setpoint. If reusing Custom Control Basic programs from older controllers, make any necessary changes to the input objects in the program. See [Analog STE-6000 Series Thermistor Sensors on page 12](#).

The universal inputs on green terminal blocks can be configured as:

- Analog objects—Changing resistance (thermistor) or 0 **TO** 12 VDC
- Binary objects—Open/Close passive switch or 0 **OR** 12 VDC

For an **active** voltage input, configure the input for 0–12 VDC (in the Termination drop-down selection of KMC Connect, Converge, or TotalControl).

NOTE: For 0–12 VDC inputs, select 0–12 V in the Termination drop-down box rather than Fixed Bias 0–12 V. Fixed Bias 0–12 V is automatically selected by built-in applications for mapping some inputs (e.g., AI1 and AI2 with STE-60xx sensors) into AVs. Other such inputs include: AI7 Primary Duct (BAC-9001), AI8 Primary Position (BAC-9001), and AI9 Duct (BAC-9311).

For **passive** analog input signals, such as thermistors, configure the input for 10K ohm (or 1K ohm for most RTDs) pull-up resistor.

For **passive binary** input signals, such as switch contacts, convert an analog input to a **binary** input by doing any one of the following:

- Right-clicking the input object in the Network Manager list and selecting **Convert To**.
- Opening the object configuration page and selecting **Convert To** above it.
- Removing an analog input object and adding a binary input object in its place. (See the software's documentation for more information.)

For a **pulse** input signal, convert an analog input to an **accumulator** input (in the same way as converting to a binary object above) and configure it in the following manner:

- If the pulse input is a passive input, such as switch contacts, then configure the input for 10K ohm pull-up resistor.
- If the pulse is an active voltage up to a maximum of 12 VDC, then configure the input for 0–12 VDC.

For a **4–20 mA** current loop input, configure the input for 4–20 mA. See also the [4–20 mA Wiring for Controllers Application Guide](#).

Output Connections

Connecting Universal Outputs

Connect the output device under control between the output terminal and the ground (GND) terminal on the same bank. On BAC-9300A series, Switched Common (SC) terminals are used on the BO terminals. On BAC-5900A series controllers and CAN-5900 series expansion modules, SC terminals are only used with some of the output override boards. See [Grounds Versus Switched \(Relay\) Commons on page 14](#).

The universal outputs (on green terminal blocks) can be configured as:

- Analog objects—0 TO 12 VDC
- Binary objects—0 OR 12 VDC

For either type of output, the DC voltage signals can—within the specification of the output—connect directly to most equipment. For additional options, see [Installing Override Boards in BAC-5900A/CAN-5900 Series on page 15](#).

NOTE: For 4–20 ma applications, see also the [4–20 mA Wiring for Controllers Application Guide](#).

Grounds Versus Switched (Relay) Commons

Use the SC terminal in the same output bank (individual terminal block) as its output terminal. The switched common terminals are isolated from the circuit grounds used for the universal output analog circuitry in controllers. See [Illustration: Conquest SC Terminals on page 14](#).




Illustration: Conquest SC Terminals

See also [on page 15](#).

Switched Common (SC) output terminals are unconnected in the BAC-5900A series controller unless the jumper is removed and an appropriate relay/triac override output board is installed. **Use only the Switched (relay) Common instead of the Ground with the HPO-6701 triac and HPO-6703/6705 relays!**

See [Illustration: Output Override Boards Configuration on page 15](#) and [Illustration: Output Schematics on page 16](#).

Installing Override Boards in BAC-5900A/CAN-5900 Series

For enhanced output options, such as manual control or using large relays or devices that cannot be powered directly from a standard output, install output override boards (also called “cards”). See [Illustration: Output Override Boards Configuration on page 15](#).

Output boards have an accessible three-position slide switch for selecting the “Hand-Off-Auto” functions:

- While in the “Hand” (H) position, the output is manually energized, and the controller receives a feedback signal to indicate the output has been overridden.
- While in the “Off” (O) position, the output is manually de-energized, and the controller receives a feedback signal to indicate the output has been overridden.
- While in the “Auto” (A) position, the output is under the command of the controller.

Each output board also has a red LED that illuminates when the output is turned On (either manually or automatically).




Illustration: Output Override Boards Configuration




Illustration: Output Schematics

The following output boards are available from KMC Controls:

| OUTPUT OVERRIDE BOARDS | |
|--|---|
| Model Number | Output Type* |
| HPO-6701** | Triac (AC only): zero-cross switching, optical isolation, 12 VAC min. and 30 VAC max. voltage, 20 mA min. and 1 A max. current |
| HPO-6702 | 0–10 VDC analog: short protection, 100 mA max., adjustable override potentiometer |
| HPO-6704 | 4–20 mA current loop: short protection, adjustable override potentiometer (since the HPO-6704 supplies the power, it will not work with a 4–20 mA device that also supplies its own power) |
| HPO-6703* | Normally open relay: 30 VAC/VDC, 2 A max. |
| HPO-6705* | Normally closed relay: 30 VAC/VDC, 2 A max. |
| *For more information, see the HPO-6700 Series Output Override Boards Data Sheet . | |
| **With the HPO-6701 triac and HPO-6703/6705 relays , use the Switched Common terminals instead of Ground. | |

NOTE: For 4–20 ma applications with the HPO6704, see also the [4–20 mA Wiring for Controllers Application Guide](#).

⚠ CAUTION

Connecting 24 VAC or other signals that exceed the operation specifications of the controller before the output jumper is removed will damage the controller. Remove the jumper and install the override board before connecting AC or other voltage to the output terminals of the controller.

To install the HPO-6700 series override boards:

1. Disconnect the power to the controller.
2. Pull the top edge of the (translucent black) override board cover away from the case and open the cover.
3. Remove the jumper from the relevant mounting header pins. See [Illustration: Output Override Boards Configuration on page 15](#).
4. Position the board in the relevant slot with the Hand-Off-Auto selection switch positioned toward the output connections.
5. Slide the board down the integral board tracks onto the header pins.
6. Set the selection switch on the override board to the desired position. A (Automatic) is the top position of the switch, O (Off) is the center position, and H

- (“Hand” or On) is on the bottom position.
7. Repeat steps 3 through 6 to install additional boards.
 8. Close the override board cover.
 9. Connect the output devices to the controller outputs. See [Grounds Versus Switched \(Relay\) Commons on page 14](#).
 10. Reconnect the power.

NOTE: If a board is to be moved or removed, reinstall the (HPO-0063) jumper (removed in Step 3) on the two pins closest to the outputs.

NOTE: For 4–20 ma applications, see also the [4–20 mA Wiring for Controllers Application Guide](#).

Connecting a VAV Remote Actuator to a BAC-9311A(C)(E)

Instead of using a BAC-9000A series controller-actuator in a VAV application, using a BAC-9311A(C)(E) with a remote actuator provides additional options, such as higher torque or fail-safe. The tri-state actuator should be connected to the B05, B06, and SC terminals of the triac (VAC only) outputs. See [Illustration: Remote Actuator Wiring on page 17](#).




Illustration: Remote Actuator Wiring

See [Illustration: Remote Actuators for a BAC-9311 on page 18](#) to select an appropriate actuator. Some applications may require custom programming.

| TRI-STATE MODELS* | TORQUE (IN-LB.) | | | | | | |
|--|-----------------|----|----|----|----|-----|-----|
| | 25 | 40 | 45 | 80 | 90 | 180 | 320 |
| NON-FAIL-SAFE | | | | | | | |
| MEP-4201 | ✓ | | | | | | |
| MEP-40x1/40x3 | | ✓ | | | | | |
| MEP-4501 | | | ✓ | | | | |
| MEP-48x1/48x3 | | | | ✓ | | | |
| MEP-4901 | | | | | ✓ | | |
| MEP-7501/7503 | | | | | | ✓ | |
| MEP-7801/7803 | | | | | | | ✓ |
| FAIL-SAFE | | | | | | | |
| MEP-4251 | ✓ | | | | | | |
| MEP-4551 | | | ✓ | | | | |
| MEP-4951 | | | | | ✓ | | |
| MEP-7551/7553 | | | | | | ✓ | |
| MEP-7851/7853 | | | | | | | ✓ |
| *See the relevant data sheet for options and other specifications. | | | | | | | |

Illustration: Remote Actuators for a BAC-9311

MS/TP Network Connections

Connections and Wiring




Illustration: MS/TP Network Wiring (Standard and Redundant Wiring)

Use the following principles when connecting a controller to an MS/TP network:

- Use 18 gauge, twisted-pair, shielded cable with capacitance of no more than 51 picofarads per foot (167 pf/m) for all network wiring. Manufacturers' cables that meet KMC requirements include Belden (18 AWG) P/N **82760**, Windy City Wire (18 AWG) P/N **052000LC**, and Windy City Wire (22 AWG) P/N **043000-110** or **043000AL**.
- Connect the -A terminal in parallel with all other -A terminals and the +B terminal in parallel with all other +B terminals. See [Illustration: MS/TP Network Wiring \(Standard and Redundant Wiring\) on page 19](#).
- Connect the shields of the cable together at each controller. For KMC BACnet controllers use the S (Shield) terminal. The S terminal is provided as a connecting point for the shield. The terminal is not connected to the circuit ground of the controller. When connecting to controllers from other manufacturers, verify the shield connection is not connected to ground.
- Connect the shield to an earth ground **at one end only**.
- To maintain communications in case of an open conductor on the network cable, use redundant wiring routed separately to enhance reliability. See [Illustration: MS/TP Network Wiring \(Standard and Redundant Wiring\) on page 19](#).
- Connect no more than 128 addressable BACnet master devices (total) to one MS/TP network. The devices can be any mix of controllers or routers. (Up to 127 slave devices can also be connected.)
- Limiting the MS/TP network size to no more than about 30 controllers will optimize network performance.
- If the network has more than 31 MS/TP devices or if the cable length exceeds 4,000 feet (1,220 meters), use a KMD-5575 repeater (on an MS/TP-only

network if the baud rate on the network is no higher than 38.4K baud) or a faster KMC BAC-5051E router with an Ethernet network. For each network segment, connect the shields to a good earth ground at only one end of the segment; tape back the shield ground at the other end. Generally, use no more than four KMD-5575 repeaters per MS/TP network.

- Use a KMC KMD-5567 surge suppressor where a cable exits the building.

NOTE: See [Planning BACnet Networks \(Application Note AN0404A\)](#) for additional information about installing controllers.

NOTE: To temporarily disconnect the controller from the network, pull out the isolation bulb assembly or the MS/TP terminal block from its connector.

NOTE: For troubleshooting the wiring, see the [MS/TP Troubleshooting Using a Multimeter - Bifurcation](#) video and downloadable troubleshooting guide.

EOL (End of Line) Termination Switches

The controllers on the physical ends of the EIA-485 wiring segment must have EOL (End of Line) termination enabled for proper network operation. In the end controllers (only), turn the EOL switches On. See [Illustration: End-of-Line Termination on page 20](#). Verify that all other controllers have EOLs turned Off (as shipped from the factory).




Illustration: End-of-Line Termination

Temporary Network Connection




Illustration: Using a BAC-5051AE as a Service Tool

For configuration and troubleshooting, data ports on the bottom of STE-9xxx NetSensors or STE-6010/6014/6017 analog sensors provide temporary MS/TP network connections using a BAC-5051E router and KMC Connect on a computer. See the [BAC-5051E Router Application Guide](#) for instructions.

NOTE: This temporary connection through the data port is not available on Ethernet networks.

Ethernet Network Connections

NOTE: See also [Status Indicators on page 7!](#)

The controller connects in the same manner as other Ethernet devices. Connect a standard T568B CAT 5 or CAT 6 Ethernet cable from the Ethernet port on the controller to a network router, switch, or hub.

CAUTION

Do NOT plug the cable meant for Ethernet communications into the Room Sensor jack. The Room Sensor port powers a NetSensor, and the supplied voltage may damage an Ethernet card, switch, or router to which it is accidentally connected. See [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#).

NOTE: BAC-59xxACE and BAC-9xxACE models have dual Ethernet ports that support daisy-chaining. See the technical bulletin (TB160426) **Daisy-Chaining Conquest Ethernet Controllers** on the KMC web site (after logging in) for more information

With current firmware, a Conquest “E” model controller can be configured (using KMC Connect, TotalControl, or Converge, but not a NetSensor) for the following types of communication:

- Ethernet 802.3 (ISO 8802-3)
- BACnet IP
- Foreign Device

NOTE: **Placing the controller on an BACnet IP network without proper configuration and assigning the correct IP address could cause disruption to the Ethernet LAN network service.** See relevant software documentation for more information about IP configuration.

Conquest Ethernet-enabled “E” models with the latest firmware can be configured with an HTML5 compatible web browser from pages served from within the controller. For complete details, see the [Conquest Ethernet Controller Configuration Web Pages Application Guide](#).




Illustration: Ethernet Model Configuration Web Pages

The controllers have the following default network address values:

- IP address—192.168.1.251
- Subnet mask—255.255.255.0
- Gateway—192.168.1.1

NOTE: The default IP address of the BAC-5051E router is 192.168.1.252.

Power (Controller) Connections

Use the following guidelines when choosing and wiring 24 VAC transformers.

- Use a KMC Controls Class-2 transformer of the appropriate size to supply power to the controllers. KMC Controls recommends powering only one controller from each transformer. Do not run 24 VAC power from within an enclosure to external controllers.
- If several controllers are mounted in the same cabinet, a transformer can be shared between them provided the transformer does not exceed 100 VA (or other regulatory requirements), the total power drawn does not exceed the transformer's rating, and the phasing is correct.

To **connect 24 VAC (–15%, +20%), 50/60 Hz, power** to the black (removable) terminal block:

- Connect the AC **phase** to the ~ (phase/R) terminal.
- Connect the **neutral** lead from the transformer to the **⊥** (common) terminal.

Power is applied to the controller when the transformer or power supply is powered and the removable terminal block is plugged into the connector.

Transformers for optional CAN-5900 series expansion modules should be powered on the same circuit as that of their controller. See the [CAN-5900 Series Installation Guide](#).

NOTE: New **BAC-5900A, CAN-5900, and BAC-9300A** series controllers can also be powered by 24 Volts **DC** as well as **AC**. See [Illustration: 24 VAC and VDC Power Connections on page 23](#).

NOTE: BAC-9000A series VAV controller-actuators and the TSP-8003 dual-duct actuator, however, are to be powered by AC only because of motor timing. STE-9000 NetSensors are powered by the connection to the controller.




Illustration: 24 VAC and VDC Power Connections

To connect 24 **VAC** (**-15%, +20%**), **50/60 Hz**, power to the black (removable) terminal block:

- Connect the AC **phase** to the ~ (phase/R) terminal.
- Connect the **neutral** lead from the transformer to the **⊥** (common) terminal.

To connect 24 **VDC** (**-15%, +20%**) instead of VAC power (to new BAC-5900A, CAN-5900, and BAC-9300A series only):

- Connect 24 **VDC** to the ~ (phase/R) terminal.
- Connect **GND** to the **⊥** (common) terminal.

CONFIGURATION

Configuring, Programming, and Designing

For configuration and programming information, see the documents and Help systems for the respective tool.

| SETUP PROCESS | | | KMC CONTROLS TOOL |
|---------------|-----------------------------|--------------------|---|
| Configuration | Programming (Control Basic) | Web Page Graphics* | |
| ✓ | | | Conquest NetSensor |
| ✓ | | | Internal configuration web pages in Ethernet "E" models** |
| ✓ | | | KMC Connect Lite™ (NFC) app*** |
| ✓ | ✓ | | KMC Connect™ software |
| ✓**** | ✓**** | ✓ | TotalControl™ software |
| ✓ | ✓ | | KMC Converge™ module for Niagara WorkBench |
| | | ✓ | KMC Converge GFX module for Niagara WorkBench |

*Custom graphical user-interface web pages can be hosted on a remote web server, but not in the controller.

**Conquest Ethernet-enabled "E" models with the latest firmware can be configured with an HTML5 compatible web browser from pages served from within the controller. For information, see the [Conquest Ethernet Controller Configuration Web Pages Application Guide](#).

***Near Field Communication via enabled smart phone or tablet running the KMC Connect Lite app (optionally with an HPO-9003 NFC-Bluetooth/USB module/fob).

****Full configuration and programming of KMC Conquest controllers is supported starting with TotalControl ver. 4.0.

Illustration: Configuration, Programming, and Graphics Tools

For configuration using a **NetSensor**, see [Controller Configuration with STE-9xx1 Menus on page 26](#). See also [Restore \(RSTR\) and Application/Units Selection on page 30](#) and [VAV Airflow Balancing with an STE-9xx1 on page 31](#).

NOTE: A NetSensor is only one option for configuring controllers, however. For example, a NetSensor cannot configure controllers while they are still in the box or configure IP options for Ethernet models. But those functions can be done with the **KMC Connect Lite app** on an NFC enabled smart phone. You would probably also want to use Connect Lite instead of a NetSensor if you are configuring a large number of controllers. On the other hand, use a NetSensor if you want to configure MS/TP model controllers without any software or app. You may want to use a NetSensor if you only have a few controllers to configure.

NOTE: On Conquest controllers, Inputs 1 and 2 are dedicated to the Room Sensor port (for the STE-6010/6014/6017—see [Analog STE-6000 Series Thermistor Sensors on page 12](#)). The input object AI1 is dedicated to the room temperature (for the STE-6010/6014/6017), and object AI2 is dedicated to room temperature setpoint (for the

6014/6017). If reusing Custom Control Basic programs from older controllers, make any necessary changes to the input objects in the program.

- NOTE:** Input objects AI1 and AI2 are **not** used by STE-9xxx NetSensors. Those digital sensors map temperature and setpoint values directly to AV1, AV4, and AV5. (See [Digital STE-9000 Series NetSensors on page 10.](#))
- NOTE:** Terminals on removable blocks start with Input 3. (See [Illustration: Controller Overview \(BAC-5901AC shown\) on page 4.](#))
- NOTE:** Customized programming is the responsibility of the user. KMC Controls does not provide support for such programs.

NFC (Near Field Communication)

An NFC-enabled device can be used with KMC Connect Lite to configure KMC Conquest controllers. See the [KMC Connect Lite Mobile App User Guide](#) for information on configuring controllers via NFC.

- NOTE:** To meet FCC regulations and enhance data communication reliability, NFC operation should only be used when the controller is **not** powered.
- NOTE:** Because of the very short range of NFC, hold the NFC-enabled phone or HPO-9003 NFC-Bluetooth/USB module (fob) as close as possible over the NFC symbol on the controller or unpacked controller box.

For additional security after configuration, NFC can be disabled (in controllers with firmware E1.0.0.31 or later), using the latest version of KMC Connect, Converge, or TotalControl. Disabling NFC prevents the reading and updating of configuration data in the controller through NFC. To disable NFC, see the instructions in the Disabling/Enabling NFC in Controllers section of the [KMC Connect Lite Mobile App User Guide](#).

- NOTE:** NFC should only be disabled after the controller has been installed.


Passwords

To protect against unauthorized tampering with the configuration parameters, Conquest controllers are factory-set with a default level 2 password when using an STE-9000 series NetSensor or the KMC Connect Lite NFC app. See the **Conquest Controllers Default Password Technical Bulletin** by logging into the [KMC web site](#) and looking at the downloadable documents for any of the KMC Conquest controllers or STE-9000 series NetSensors.

Controller Configuration with STE-9xx1 Menus

(Press and hold both Up and Down buttons at least 6 seconds to access menus)

NOTE: Screens are dependent on application (default dual duct VAV is shown below). For descriptions of these and other screens not shown, see [Conquest NetSensor Screen Abbreviations on page 27](#).



CONQUEST NETSENSOR SCREEN ICONS

| Icon | Meaning | Comments |
|------|----------------------|---|
| | Cooling/Heating Mode | User-selected Cooling (snowflake) or Heating (flame) or automatic (A) |
| | Fan | Off, Low, Medium, or High speed (number of bars are dependent on configuration and fan type) and A = Automatic operation |
| | Occupancy Mode | According to the schedule, sensed motion, or button activation: <ul style="list-style-type: none"> Person in house = Occupied Empty house = Standby OVR = Override None of the icons = Unoccupied |

| DIAGRAM AND CHART COLOR CODE |
|--|
| Advanced Menu |
| Balancing (VAV) Menu |
| Communications Menu |
| Navigation and Password Entry Items |
| Restore (Applications, Units, and Defaults) Menu |
| Setpoint Menu |
| System Menu |

| CONQUEST NETSENSOR SCREEN ABBREVIATIONS | | |
|---|--------------------------------------|--|
| Abbreviation | Meaning | Function/Comments |
| 0.0 | Calibration | Enter a positive number if reading is too low or negative number if reading is too high |
| ADVC | Advanced Menu | Set passwords and calibration |
| AUMD | Automatic Occupancy Mode | Automatic occupancy mode—enable (controller automatically enters unoccupied mode when it detects the loss of primary air supply) or disable (controller will remain in occupied mode regardless of the primary air supply) |
| AUX | Auxiliary Airflow (BAC-9xx1) | Set the BAC-9xx1 VAV auxiliary airflow setpoint for when reheat is active (cfm) |
| | Auxiliary Damper Position (BAC-9021) | Set the BAC-9021 pressure-dependent VAV auxiliary damper position (%) |
| | Auxiliary Heat (BAC-9301 FCU) | Enable/disable auxiliary heat for two-pipe BAC-9301 FCU applications |
| AUXH | Auxiliary Heat (BAC-93x1 HPU) | Select auxiliary heat options (None, 3rd Stage, Compressor Lockout) for BAC-93x1 HPU applications |
| AXLK | OAT Aux Heat Lockout | Set the Outside Air Temperature that locks out HPU auxiliary heat (°) |
| BACK | Back | Go back to previous menu |
| BAUD | Baud Rate | Set baud rate |
| BLNC | Balance Menu | Set airflow balancing parameters—only the PRI (primary) menu is used for single duct VAV |
| CHNG | SAT Changeover | Set the Supply Air Temperature setpoint (°) at which the controller will change between heating and cooling |
| CMLK | Compressor Lockout Temperature | Set Compressor Lockout Temperature (°) |
| CNFG | Configuration Menu | Access the configuration menus |
| CO | CO ₂ Setpoint | The setpoint for DCV control (see STE-93xx/95xx CO2 Sensor and DCV on page 10) |
| CO ₂ | CO ₂ /DCV Enable | Demand Control Ventilation (DCV) is an available option when an economizer is enabled in BAC-93xx HPU or RTU applications and an STE-93x1/95x1 NetSensor is connected to the Room Sensor port (but is disabled by default) |
| CORA | CO ₂ Range | The CO ₂ value for DCV min. to max. damper opening (see STE-93xx/95xx CO2 Sensor and DCV on page 10) |
| COMM | Communication Menu | Set BACnet device instance, MAC address, and network baud rate |
| CVA | Cooling Valve Action | Select Normally Closed or Normally Open valve |
| DAEN | DAT Limiting Enable | Enable/disable Discharge Air Temperature Limiting |
| DDIR | Damper Direction | Select the rotation direction (CW or CCW) of the actuator to close the damper |
| DEHU | Dehumidification Setpoint | Set Dehumidification Setpoint (%) |

| DIAGRAM AND CHART COLOR CODE |
|--|
| Advanced Menu |
| Balancing (VAV) Menu |
| Communications Menu |
| Navigation and Password Entry Items |
| Restore (Applications, Units, and Defaults) Menu |
| Setpoint Menu |
| System Menu |

| | | |
|-------------|----------------------------------|--|
| DHDF | Dehumidification Differential | Set Dehumidification Differential (%) |
| D ID | BACnet Device Instance | Set BACnet Device Instance number |
| DIFF | Minimum Setpoint Differential | Set the minimum allowable temperature value (differential) between the cooling and heating setpoints (°) |
| DMIN | Dual Duct Min Airflow (BAC-9001) | Set the BAC-9001 dual duct VAV minimum airflow (cfm) |
| EETM | Economizer Enable Temperature | Set Economizer Enable (Outside Air) Temperature (°) |
| ELOC | Enable Compressor Lockout | Enable/disable compressor lockout |
| ENEC | Econ Enable | Enable/disable Economizer operation |
| ENDH | Enable Dehumidification | Enable/disable Dehumidification operation |
| ENST | Enable Standby Mode | Enable/disable Standby Mode |
| EQDY | Equipment Delay | Set Equipment Delay time (minutes) |
| EVAL | Start H2O Evaluation | Set Offset Temperature to Start Water Evaluation for 2-pipe FCU (°) |
| EXIT | Exit | End configuration |
| FNDY | Fan Off Delay | Set Fan Off Delay time (minutes) |
| FNHT | Fan Active In Heat | Select Fan Off or Auto in Heat mode |
| FNOC | Fan On During Occupied Mode | Enable/disable Fan On (continuously) during Occupied mode |
| FNTP | Fan Type | Set the fan type in VAV applications (None, Series, or Parallel) |
| FSPD | Fan Speeds Available | Select number of Fan Speeds Available (1, 2, or 3) |
| HVA | Heating Valve Action | Select Normally Closed or Normally Open valve |
| MAC | BACnet MAC Address | Set BACnet MAC address number |
| MAX | Maximum Heating Setpoint | Set the highest temperature that a user can enter as the active setpoint (°) |
| MIN | Minimum Cooling Setpoint | Set the lowest temperature that a user can enter as the active setpoint (°) |
| MNCL | Minimum Cooling Airflow | Set Minimum Cooling Airflow limit (cfm) |
| MNDC | Minimum DAT | Set Minimum Discharge Air Temperature (°) |
| MNDM | Minimum Econ Damper | Set Minimum Economizer Damper position (%) |
| MNFN | Min. Fan Speed | Set Minimum Fan Speed (%) |
| MNHT | Minimum Heating Airflow | Set Minimum Heating Airflow (cfm) |
| MXCL | Maximum Cooling Airflow | Set the maximum limit for cooling airflow (cfm) |
| MXDT | Maximum DAT | Set Maximum Discharge Air Temperature (°) |

| DIAGRAM AND CHART COLOR CODE |
|--|
| Advanced Menu |
| Balancing (VAV) Menu |
| Communications Menu |
| Navigation and Password Entry Items |
| Restore (Applications, Units, and Defaults) Menu |
| Setpoint Menu |
| System Menu |

| | | |
|-------------|---------------------------------|---|
| MXHT | Maximum Heating Airflow | Set Maximum Heating Airflow limit (cfm) |
| MXFN | Max. Fan Speed | Set Maximum Fan Speed (%) |
| OCCL | Occupied Cooling Setpoint | Set the cooling setpoint used as the active setpoint when the the space is occupied (°) |
| OCHT | Occupied Heating Setpoint | Set the heating setpoint used as the active setpoint when the the space is occupied (°) |
| OVRD | Override Mode | Enable/disable local unoccupied override mode |
| OVRT | Override Timer | Set Local Unoccupied Override Timer after override has been initiated (minutes) |
| PKFT | Primary K Factor | Enter the K-factor supplied by the manufacturer of the VAV terminal unit |
| PMAX | Primary Measured Max. Airflow | Set value for either the cooling or heating maximum airflow in primary duct (cfm) |
| PMIN | Primary Measured Min. Airflow | Set value for either the cooling or heating minimum airflow in primary duct (cfm) |
| PRI | Primary | Select Primary duct to balance |
| PSW1 | Password Level 1 | Set Password 1 (entering four zeros removes the password) |
| PSW2 | Password Level 2 | Set Password 2 (entering four zeros removes the password)—see (Unknown) Password Is Required on page 41 |
| RHTP | Reheat Type | Select the reheat type for none, staged, modulating (0–10 VDC actuator), floating (tri-state actuator), or time proportional (thermal wax actuator) |
| RSTR | Restore (Menu) | Select application, select English/Metric units, and restore STPT, SYST, and BLNC menu items to factory default settings |
| RVA | Reversing Valve Action | Set Reversing Valve Action (active during cooling or active during heating)—see Reversing Valve Action (HPU) on page 60 |
| SEC | Secondary | Select Secondary duct to balance |
| SKFT | Secondary K Factor | Enter the K-factor supplied by the manufacturer of the VAV terminal unit for the second duct of a dual duct system |
| SMAX | Secondary Measured Max. Airflow | Set value for either the cooling or heating maximum airflow in secondary duct (cfm) |
| SMIN | Secondary Measured Min. Airflow | Set value for either the cooling or heating minimum airflow in secondary duct (cfm) |
| STBT | Standby Timer | Set motion sensor inactivity time before triggering Standby mode (minutes) |
| STDY | Stage Delay | Set Stage Delay time (minutes) |
| STBO | Standby Offset | Set the offset value (°) added or subtracted (depending on mode) from the value of the active setpoint |
| STPT | Setpoint Menu | Enter temperature setpoints and limits |
| SYST | System Menu | Configure basic HVAC application functions |
| UNCL | Unoccupied Cooling | Set the cooling setpoint used as the active setpoint when the the space is unoccupied (°) |
| UNHT | Unoccupied Heating | Set the heating setpoint used as the active setpoint when the the space is unoccupied (°) |
| VA | Valve Action | Select Normally Closed or Normally Open valve |

Restore (RSTR) and Application/Units Selection

The Restore (RSTR) menu performs three functions:







- Selects the application (dependent on controller model)
- Selects the units (English, Metric, or mixed)
- Restores the items in the Setpoint, System, and Balance menus to their factory defaults. (Communication settings and user-defined passwords are not affected.)

See [Controller Configuration with STE-9xx1 Menus on page 26](#).

To perform one or more of these functions, follow the steps below.

NOTE: Changing the application or the units will **ALSO** restore the factory defaults to the Setpoint, System, and Balance menu items! Select the desired **application and units first**, let the controller **restart** (at least 30 seconds), and **then continue configuring** the applicable Setpoint, System, and Balance items.

NOTE: To restore a configured controller to the factory defaults while **keeping the existing application and units**, restore with a different application and/or units first. After the controller restarts, change the application and/or units back to the original setting. After the controller restarts again, continue with the configuration.

| APPLICATIONS, UNITS, AND DEFAULTS STEPS | DISPLAY |
|---|---|
| 1. Start at the temperature display. |  |
| 2. Press the Up and Down buttons together for at least 6 seconds and enter the level 2 password. The display changes to CNFG after Password 2 is correctly entered. See (Unknown) Password Is Required on page 41 . |  |
| 3. At the CNFG display, press the Enter button. |  |
| 4. At the STPT display, press the Up or Down button to advance to the RSTR display. |  |
| 5. With RSTR flashing, press the Enter button. The application and units will start flashing. (If you do NOT want to restore application settings to the factory defaults, do NOT press the Enter button while the application and units are flashing . Let the display time out instead—about 30 seconds.) |  |
| 6. With the application and units flashing, use the Up and Down buttons to find the correct choice and press the Enter button. With RSTR flashing, either navigate to the Exit menu (using the Up or Down button) or let the menu time out (about 30 seconds). |  |

See also [VAV Airflow Balancing with an STE-9xx1 on page 31](#).

VAV Airflow Balancing with an STE-9xx1

NOTE: This procedure is very similar to that of using an STE-8x01 NetSensor to balance a KMC SimplyVAV controller. See the balancing video and other information on www.simplyvav.com/balance/.






The airflow balancing/calibrating procedure requires the following:





- An STE-9000 series NetSensor. If the system does not include one of these sensors, temporarily disconnect any STE-60xx sensor connected to the Room Sensor port and connect an STE-9xx1 as a service tool.
- The level 2 password.
- A flow hood or other accurate method to measure airflow.
- The engineering design specifications for the minimum and maximum airflow setpoints.
- The K factor for the box (see [Appendix: K Factors for VAV on page 106](#)).
The **K factor value is first entered in the SYST menu** (see [Controller Configuration with STE-9xx1 Menus on page 26](#)).

NOTE: For a heating-only or cooling-only VAV unit, the airflow setpoints for the unused mode must be set within the range of the mode in use. Failure to set the unused setpoints correctly will result in unpredictable or erroneous air balancing settings. See [Controller Configuration with STE-9xx1 Menus on page 26](#).

NOTE: Starting the balancing procedure erases all previous airflow correction factors. The airflow readings displayed by the STE-9xx1 are the actual uncorrected airflow readings as measured by the controller. Sensor calibration must be done at both Minimum and Maximum settings.

NOTE: Once the following procedure is started, all steps must be completed in order.


| PROCEDURES AND STEPS | DISPLAY |
|---|---|
| Select balancing mode | |
| 1. Start at the temperature display. |  |
| 2. Press and hold the Up and Down buttons together for at least 6 seconds and enter the level 2 password. The display changes to CNFG after Password 2 is correctly entered. See (Unknown) Password Is Required on page 41 . |  |
| 3. From the CNFG display, press the Up or Down buttons to advance to the BLNC display. |  |
| 4. Press the Enter button to select BLNC . The display advances to PRI . |  |
| 5. Press the Enter button to select PRI . |  |

| | |
|---|---|
| Measure and enter maximum primary airflow | |
| <p>NOTE: The display begins flashing PMAX and displays the (uncorrected) actual airflow at the bottom. The airflow will attempt to stabilize on the highest value for either the cooling or heating maximum airflow even if only one mode is operational.</p> <ol style="list-style-type: none"> Wait for the maximum airflow value to stabilize. With a flow hood, measure the actual airflow. Press the Enter button to advance to the entry display. PMAX stops flashing. Press the Up or Down button to enter the measured airflow. Press the Enter button to save the measured airflow. The display changes to PMIN. |  |
| Measure and enter minimum primary airflow | |
| <p>NOTE: The display begins flashing PMIN and displays the (uncorrected) actual airflow at the bottom. The airflow will attempt to stabilize on the lowest value for either the cooling or heating maximum airflow even if only one mode is operational.</p> <ol style="list-style-type: none"> Wait for the minimum airflow value to stabilize. With a flow hood, measure the actual airflow. Press the Enter button to advance to the entry display. PMIN stops flashing. Press the Up or Down button to enter the measured airflow. Press the Enter button to save the measured airflow. The display changes to PRI. |  |
| Continue for dual duct or exit | |
| <ol style="list-style-type: none"> Press the Up or Down button to advance to one of the following choices and then press the Enter button: <ul style="list-style-type: none"> BACK to choose another function. EXIT to return to the temperature display. SEC to balance the secondary VAV for dual duct systems. This option is available only on dual duct models. (Continue on the steps on the next page.) |  |
| Measure and enter maximum secondary airflow | |
| <p>NOTE: If SEC is selected, the display begins flashing SMAX and also displays the (uncorrected) actual airflow at the bottom. The airflow will attempt to stabilize on the highest value for either the cooling or heating maximum airflow even if only one mode is operational.</p> <ol style="list-style-type: none"> Wait for the maximum airflow value to stabilize. With a flow hood, measure the actual airflow. Press the Enter button to advance to the entry display. SMAX stops flashing. Press the Up or Down buttons to enter the measured airflow. Press the Enter button to save the measured airflow. The display changes to SMIN. |  |


Measure and enter minimum secondary airflow

NOTE: The display begins flashing **SMIN** and also displays the (uncorrected) actual airflow at the bottom. The airflow will attempt to stabilize on the lowest value for either the cooling or heating maximum airflow even if only one mode is operational.

22. Wait for the minimum airflow value to stabilize.
23. With a flow hood, measure the actual airflow.
24. Press the Enter button to advance to the entry display. **SMIN** stops flashing.
25. Press the Up or Down buttons to enter the measured airflow.
26. Press the Enter button to save the measured airflow.



27. Press the Up or Down button to advance to one of the following (and then press the Enter button):
 - **BACK** to choose another function.
 - **EXIT** to return to the temperature display.



See also [Restore \(RSTR\)](#) and [Application/Units Selection](#) on page 30.

RESETTING AND TROUBLESHOOTING

Resetting Controllers

Types of Reset

If a controller is not operating correctly, reset the controller. Any reset interrupts normal operation, and several types of reset exist:

- A **warm start** is generally the least disruptive option (restarting normal operation the quickest).
- If problems still persist, try a **cold start**. (This should also be used after a new Control Basic program is loaded and compiled.)
- To **restore** (STPT, SYST, and BLNC) configuration values to their **factory defaults**, see [Restore \(RSTR\) and Application/Units Selection on page 30](#).

Warm and Cold Starts

⚠ CAUTION

During a restart, the analog outputs go to zero, and triacs go to their normally open state. A restart is a process that lasts several seconds, and it may result in several changes of state for an output, turning equipment off and on abruptly. Before resetting the controller, manually override equipment as needed. If a large fan is controlled by the controller, for example, set a minimum off time.

A **WARM start** does the following in the controller:

- Zeroes out objects (during the restart process).
- Restores present values of objects to **their last values before the restart** (until they are updated by the controller's programs).
- Restarts the controller's Control Basic programs.
- Leaves configuration and programming intact.

To perform a warm start, do one of the following:

- Momentarily remove power to the controller.
- From TotalControl, Connect, or Converge, select Reinitialize Device > Warm Start.

NOTE: When power is restored after an outage, the controller will attempt a warm start as long as the values in RAM are retained (up to about six hours). If the RAM checksum test fails, a cold start is done instead.

NOTE: In custom Control Basic programming, using the POWERLOSS command may be desirable to determine start-up conditions and to take appropriate actions—see the Help system in KMC Connect or TotalControl for more information.)

A **COLD start** does the following in the controller:

- Zeroes out objects (during the restart process).
- Returns all present values of objects to **their relinquished defaults** (until they are updated by the controller's programs).
- Restarts the controller's Control Basic programs.
- Leaves configuration and programming intact.

To perform a cold start, from TotalControl, Connect, or Converge, select Reinitialize Device > Cold Start.

Troubleshooting

Communication Issues

Communication Issues—CAN (Expansion Module)

- See [EIO LEDs \(Green\) on page 8](#).
- See also [Ready \(Power/Status\) LED \(Green\) Issues on page 36](#).
- Check that EOL switches are correctly positioned on the controller and each module. See [EOL \(End of Line\) Termination Switches on page 20](#).
- Check for correct wiring and phasing.
- Check addressing switches. See the [CAN-5900 Series Installation Guide](#).

NOTE: If the **CAN-5901** loses **EIO communication** with the BAC-5900A series controller, the CAN-5901 **retains the last present value for the outputs** until communication is restored or power is lost. When communication is restored, the outputs will go to whatever state the controller is commanding them to be at that time. (For CAN-5901 modules with firmware 0.0.0.1, about 30 seconds after communications loss, the module turns all of its outputs **off** until communication is restored.)

Communication Issues—Ethernet

CAUTION

On Conquest “E” models, do NOT plug the cable meant for Ethernet communications into the Room Sensor jack. The Room Sensor port powers a NetSensor, and the supplied voltage may damage an Ethernet card, switch, or router to which it is accidentally connected. See [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#).

- Check that the Ethernet connection cable is plugged into the Ethernet port and not the Room Sensor port.
- See [Ethernet LEDs \(Green and Amber\) Issues on page 36](#).
- Use a BAC-5051AE router to check route status for network issues such as duplicate network numbers.
- Restart the controller. See [Resetting Controllers on page 34](#).
- See also the Troubleshooting section in the [Conquest Ethernet Controller Configuration Web Pages Application Guide](#).

Communication Issues—MS/TP

- See [LED Indicators and Isolation Bulbs Issues on page 36](#).
- Check that EOL switches are correctly positioned at each controller on the network. See [EOL \(End of Line\) Termination Switches on page 20](#).
- Check for correct wiring and phasing.
- Check the Max Master setting in a configuration tool. It should be (just) higher than the highest numbered controller.
- See [Planning BACnet Networks \(Application Note AN0404A\)](#).
- Check the baud rate setting (which should be the same on all the controllers on the network).
- See the [MS/TP Troubleshooting Using a Multimeter - Bifurcation](#) video and downloadable troubleshooting guide.

Communication Issues—NFC (Near Field Communication)

- NOTE:** To meet FCC regulations and enhance data communication reliability, NFC operation should only be used when the controller is **not** powered.
- Hold the NFC-enabled phone or HPO-9003 NFC-Bluetooth/USB module (fob) as close as possible over the NFC symbol on the controller or unpacked controller box.
 - For no NFC communication with a previously configured controller, check that NFC has not been disabled. See [NFC \(Near Field Communication\) on page 25](#).
 - For other issues, see the [KMC Connect Lite User Guide](#).

LED Indicators and Isolation Bulbs Issues

- NOTE:** For general information about indicators, see [Status Indicators on page 7](#).

Ready (Power/Status) LED (Green) Issues

- Within a few seconds after power is first applied, the green Ready (power/status) LED near the power terminals will begin flashing (on for a second and then off for a second) if the device is functioning normally.
- If it is not illuminated, check the power and connections to the controller.

Ethernet LEDs (Green and Amber) Issues

The Ethernet connector has two built-in LEDs:

- The amber LED illuminates when the controller has power and is communicating at its highest speed (100BaseT). (It is off when the connection is communicating at 10BaseT.)
- The green LED will blink at a rate in accordance to Ethernet traffic.
- If neither LED is illuminated, check the power and Ethernet connection.

MS/TP LEDs (Amber) Issues

- NOTE:** The MS/TP network has an amber LED that flickers as it receives and passes the token during communication with the network. When the controller is powered up (but not communicating on the MS/TP port), these amber LEDs will flash slowly, about once per second. When the MS/TP port establishes communications with the network, the amber LED for that MS/TP port will flash rapidly (multiple times a second) as it receives and passes the token.

If the amber LED is not periodically flashing rapidly:

- Check the isolation bulbs. See [Network Isolation Bulbs \(HPO-0055\) Issues on page 36](#).
- Check the network connections and configuration.
- Restart the controller.

Network Isolation Bulbs (HPO-0055) Issues

MS/TP and CAN bus networks have an assembly of two isolation bulbs located near the network terminals. Normally the bulbs are not illuminated.

- If one or both bulbs are illuminated, it indicates the network is improperly phased (the ground potential of the controller is not the same as on other controllers on the network). Disconnect the power and check the MS/TP and power connections.

- If one or both bulbs are blown, it indicates the voltage or current on the network exceeded safe levels. Correct the conditions and replace the bulbs.

Hardware Issues

Broken or Lost Terminals or DIN Clips

- Replace the item from the HPO-9901 kit.

Burned Out Network Isolation Bulbs

- See [Network Isolation Bulbs \(HPO-0055\) Issues on page 36](#).

Lost Jumper

- Replace with an HPO-0063.

NOTE: The (watch dog) jumper on the BAC-9000A series VAV controllers should never be removed.

NOTE: An output jumper under the cover of a BAC-5900A series controller should only be removed when installing an HPO-6700 series output override board in its slot.

Input Issues

CAUTION

On Conquest “E” models, do NOT plug the cable meant for Ethernet communications into the Room Sensor port. The Room Sensor port powers a NetSensor, and the supplied voltage may damage an Ethernet card, switch, or router to which it is accidentally connected. See [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#).

Demand Control Ventilation (DCV) Is Not Available or Working Properly

NOTE: For details, see [STE-93xx/95xx CO2 Sensor and DCV on page 10](#).

- With firmware **R1.0.0.6** or later, **built-in** DCV (Demand Control Ventilation) with a CO₂ sensor is available **only** when an economizer is enabled in BAC-93xx HPU or RTU applications and an STE-93x1/95x1 NetSensor is connected to the Room Sensor port. Upgrade to the latest firmware if needed.
- For other applications and/or controllers, application programming that references the CO₂ value may be added to the controller either by modifying the factory application programming or by adding Control Basic logic in an unused program.
- Ensure that **DCV is enabled** (under CO2 in the NetSensor System menu or BV29).
- Adjust the CO₂ **setpoint** (under CO in the NetSensor Setpoint menu or AV59) and/or **range** (under CORA in the NetSensor Setpoint menu or AV58).
- Check that conditions for **self-calibration** are met.
- Check that AV57 is not out of service.


Input Values Are Outside the Expected Range

- Check that the cable to the NetSensor is plugged into the Room Sensor port and not the Ethernet port.
- After initial power-up, allow time for readings to stabilize.
- Using KMC Connect, KMC Converge, or TotalControl, check input configuration. Check that the input is not configured as Out Of Service.
- Check input wiring.

NOTE: Faulty wiring on one input can potentially cause fluctuating input values on other inputs.

- Check connected sensors (see [Illustration: Input Voltages on page 38](#)).

NOTE: All voltages are approximate



(When inputs are properly configured)

Illustration: Input Voltages

Motion/Occupancy Sensor (STE-92x1/95x1) Does Not Work

- Check that the cable to the NetSensor is plugged into the Room Sensor port and not the Ethernet port.
- After an initial power-up or restart, the motion/occupancy sensor requires about 30 seconds before it will begin responding to motion.
- In standard application programs, the motion/occupancy sensor initiates override only during “off” times in the schedule. See [Configuration/Programming Issues on page 41](#).
- Check that the motion sensor is enabled and detects motion.
- See the Motion Sensing and Troubleshooting (Location) sections in the [Room Sensor and Thermostat Mounting and Maintenance Application Guide](#).
- Using KMC Connect, KMC Converge, or TotalControl, check input configuration. Check that the value objects (e.g., BV6, MSV1) controlling occupancy mode are not configured as Out Of Service.

NOTE: The STE-92x1/95x1 motion sensor does not have a corresponding binary input object in the controller. The motion sensor writes to BV6.

Temperature Reading Is Incorrect

- Check that the cable to the NetSensor is plugged into the Room Sensor port and not the Ethernet port.
- After initial power-up, allow time for readings to stabilize.
- Check that the correct °F/°C temperature scale is selected. (Changing the temperature scale in the configuration, resets the controller to its factory default.)
- If the discrepancy is small, adjust the calibration offset in the configuration setup using KMC Connect, KMC Converge, or TotalControl.
- Using KMC Connect, KMC Converge, or TotalControl, check the AV1 and (for STE-6010/6014/6017 sensors) the AI1 configuration. Check that the objects are not configured as Out Of Service.
- Check that the sensor is properly mounted in a proper location. See the [Room Sensor and Thermostat Mounting and Maintenance Application Guide](#).
- See also [Input Values Are Outside the Expected Range on page 37](#).

Temperature Setpoint Is Not Maintained

- Check inputs and outputs. See [Input Values Are Outside the Expected Range on page 37](#) and [Output Issues on page 39](#).
- Check schedules. See [Schedules Do Not Operate Properly on page 42](#).
- Check that room temperature is being sensed correctly. See [Temperature Reading Is Incorrect on page 38](#).
- Using KMC Connect, KMC Converge, or TotalControl, check output configuration. Check that the corresponding analog value object (e.g., AV3, AV4) is not configured as Out Of Service.
- In 2-pipe FCU applications, check the changeover water temperature sensor and wiring.
- If the HVAC system has trouble recovering from the unoccupied setpoint to the occupied setpoint during very cold weather, decrease the amount the setback.
- If the space temperature is overshooting the setpoint or is oscillating, try increasing the proportional band by a degree. If the problem persists, try increasing the integral value slightly (up to 20%). If the problem still persists, try setting the integral value to 0. (The optimal integral value is dependent on the characteristics of the particular space and HVAC system.)

Output Issues

Analog Output Does Not Work

CAUTION

Do not connect 24 VAC to an analog output ground. This is not the same as a relay's switched common.

NOTE: For an output on a CAN-5900 series expansion module, see also [Communication Issues—CAN \(Expansion Module\) on page 35](#).

NOTE: Excessive loads will be clamped at the maximum. External relays may chatter or fail to latch if they need more current than the maximum allowed.

- Check for proper output object configuration.
- Using KMC Connect, KMC Converge, or TotalControl, check the outputs. Check that the output object (e.g., A07) is not configured as Out Of Service.
- Check the Control Basic programs, loop objects, and schedules.
- Check that the output is on.
- Check the current draw of the load. Substitute an output device that draws less current.

Relay or Triac (HPO-670x Override Board) Does Not Work

CAUTION

Relays and triacs are for Class-2 voltages (24 VAC) only. Do not connect line voltage to them! Do not attach a device that draws more than the maximum current rating.

NOTE: Triacs are for AC only. See the [HPO-6700 Series Output Override Boards Data Sheet](#).

NOTE: For an HPO-6701 triac output override board on a CAN-5900 series expansion module, see also [Communication Issues—CAN \(Expansion Module\) on page 35](#).

- Check for proper output object configuration.
- Using KMC Connect, KMC Converge, or TotalControl, check the outputs. Check that the output object (e.g., B04) is not configured as Out Of Service.
- Check the current draw of the load. Substitute an output device that draws less current.
- Check that the output is on.

NetSensor Display is Blank

⚠ CAUTION

Do NOT plug the cable meant for Ethernet communications into the Room Sensor jack. The Room Sensor port powers a NetSensor, and the supplied voltage may damage an Ethernet card, switch, or router to which it is accidentally connected. See [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#) and [Illustration: Room Sensor and Dual Ethernet Ports on page 9](#).

- Check that the cable from the NetSensor is plugged into the **Room Temperature port** and not an Ethernet port.
- Check that the cable is a standard Ethernet patch cable and not a crossover cable.
- Unplug the NetSensor for a moment and plug it back in.
- See [Power Issues on page 40](#).
- Check (using KMC Connect, TotalControl, or Converge) that Screen Blanking has not been enabled in the NetSensor object. For more information, see the video [Enabling Screen Blanking on STE-9000 Series NetSensor](#) on [KMC's YouTube channel](#).

Power Issues

NOTE: When the controller is powered, the green LED above the power terminals flashes slowly.

- See [Power \(Controller\) Connections on page 22](#).
- Check for a tripped circuit breaker to the transformer.
- Check for proper supply voltage and phasing from the transformer (or power supply) and that the transformer has enough capacity (VA) for all connected devices. See the devices' respective data sheets and [Tips for Connecting 24-Volt Power Application Note \(AN0604D\)](#).

NOTE: Wiring must be adequate to avoid excessive voltage drop on long runs! Allow plenty of "cushion." A voltage meter may be too slow to register transient dips or peaks during startup.

VAV Airflow Issues

- Hold down the gear disengagement lever and check that the damper moves freely to each end of its travel.
- Check the controller configuration.
- Check for 24 VAC at the terminals ~ (phase) and the **⏏** (common). Tolerance can be -15% to +20% (20.4 to 28.8 VAC). If using the same transformer for more than one controller, the phase and common must be the same on each device. See [Power Issues on page 40](#).
- Check that the V-clamp on the actuator shaft is secure (not slipping).
- Check that the tubing to the differential pressure sensor is not kinked, pulled off, or leaking.
- Check that the flow sensor in the duct is not dirty.

- Check for adequate airflow in the duct leading to the controller.
- Review the sequence of operations in [VAV \(Variable Air Volume\) on page 69](#).
- To properly set up a VAV controller, the correct K factor for the VAV box must be entered into the controller. If this information is unknown, see [Appendix: K Factors for VAV on page 106](#).

Configuration, Programming, and Operation Issues

NOTE: Use the relevant software or app to perform the following tasks.

Control Basic Programs Do Not Work

NOTE: Standard configurations are available through the KMC application configuration wizards in KMC Connect, Converge, or TotalControl. Beyond these standard configurations, custom changes can be added to a controller using Control Basic.

NOTE: Customized programs are the responsibility of the user. KMC Controls does not provide support for such programs.

- Check that program objects are not configured as Out Of Service.
- Check that program objects are running and they have Run on Cold Start selected.
- Check the Control Basic code for errors in syntax, priority levels, and other issues. For assistance with Control Basic commands, see the Help system in KMC Connect or TotalControl.

Configuration/Programming Issues

- Check for proper connections between the controller and the app or software.
- See the help information in the documentation for the app or software. See [Configuring, Programming, and Designing on page 24](#).
- To restore (STPT, SYST, and BLNC) configuration values to their factory defaults, see [Restore \(RSTR\) and Application/Units Selection on page 30](#).

Objects Are Missing

- For missing objects (e.g., inputs and outputs on CAN-5901 expansion modules, trend log multiples, and other objects that have been accidentally deleted), use KMC Connect, Converge, or TotalControl to create objects. See [BACnet Objects List on page 80](#).

(Unknown) Password Is Required

- A **default** Level 2 password is required for initial configuration when using a STE-9000 series NetSensor or the KMC Connect Lite NFC app. See the **Conquest Controllers Default Password Technical Bulletin (TB150716)** by logging into the [KMC web site](#) and looking at the downloadable documents for any of the KMC Conquest controllers or STE-9000 series NetSensors.

NOTE: If a Level 1 or 2 password is configured for 0000 in the Advanced menu, that password screen (for later user setpoint changes or configuration) is bypassed in an STE-9000 series NetSensor.

NOTE: To enhance security after configuration, change the Level 2 password for the controllers in the Advanced menu. **Be sure to document the new password for future reference!**

- If a **user-configured** Level 2 password has been forgotten, use KMC Connect to view the password in the NetSensor object screen. In KMC Connect, both levels of passwords can be viewed and changed as desired without having to first enter either one.

Schedules Do Not Operate Properly

- Check for proper schedule configuration.
- Check the controller's time. See [Time and/or Date Are Not Correct on page 42](#).
- Using KMC Connect, KMC Converge, or TotalControl, check the outputs. Check that the schedule object is not configured as Out Of Service.

Time and/or Date Are Not Correct

NOTE: When powered up after losing the RTC (Real Time Clock) time, the time and date will revert to the default and must be set manually or by syncing to the system time.

- Set the time and date using one of the configuration tools.
- Check the DST (Daylight Saving Time) settings.
- Check the UTC Offset.

Trends Do Not Work

- Check the trend log object properties for proper configuration.
- Check that the trend log object Start Time and Stop Time are valid in the configuration.
- Check that Log Enable is selected.
- Check that the log is not full because Stop When Full is selected.
- Using KMC Connect, KMC Converge, or TotalControl, check that trend log objects are not configured as Out Of Service.

Web Page Issues (Ethernet Models)

- Restart the controller. See [Resetting Controllers on page 34](#).
- See [Communication Issues—Ethernet on page 35](#).
- See the [Conquest Ethernet Controller Configuration Web Pages Application Guide](#).

Other Issues

- Thoroughly check appropriate connections, wiring, and settings.
- Reset the controller. See [Resetting Controllers on page 34](#).
- Consult with the network administrator for proper network settings.
- Contact KMC Controls technical support.

MAINTENANCE AND UPGRADES

Maintenance

For controllers, no routine maintenance is required. Each component is designed for dependable, long-term reliability and performance. Careful installation will ensure long-term reliability and performance.

For STE-9000 series NetSensors, see the [Room Sensor and Thermostat Mounting and Maintenance Application Guide](#).

Controller Upgrades and Cross-References

KMC Conquest controllers are compatible with any existing BACnet networks, but some changes must be made:

- **Conquest controllers require Conquest NetSensors.** If an older KMC BACnet controller (e.g., BAC-5801) is replaced with a Conquest controller (e.g., BAC-5901), the KMD-11xx NetSensor must also be replaced with an STE-9000 series NetSensor. See [BAC-58xx/7xxx Series Controller Cross-Reference on page 44](#) and [KMD-11xx/12xx NetSensor Cross-Reference on page 44](#).
- The **NetSensor cable must also be replaced with a Category 5 or better Ethernet patch cable** (such as an [HSO-9001](#), [HSO-9011](#), or [HSO-9012](#)) of equivalent length.

See also [Specifications, Accessories, and Installation on page 4](#).

NOTE:

- For the new controllers, **inputs and outputs** may be different.
- Before reusing any **custom Control Basic** programs from older controllers, carefully evaluate them and make any needed modifications.
- Before reusing any **graphics**, evaluate all points and update them as necessary.

BAC-58XX/7XXX SERIES CONTROLLER CROSS-REFERENCE

| Model Number | Comments | Replacement Model Number* | Comments |
|--|--------------------------------|----------------------------------|--------------------------------|
| BAC-5801 | 8 x 8 General Purpose | BAC-5901AC(E) | 8 x 8 General Purpose w/ RTC |
| BAC-5802, BAC-5901C | 8 x 8 General Purpose w/ RTC | | |
| BAC-5831 | 16 x 12 General Purpose w/ RTC | BAC-59x1AC(E), with (1) CAN-5901 | 16 x 16 General Purpose w/ RTC |
| BAC-7001/7003 | VAV Controller, 18°/minute | BAC-9001A(C)(E) | VAV controller, 60°/minute |
| BAC-7051/7053 | VAV Controller, 60°/minute | | |
| BAC-7301, BAC-9301 | AHU Controller | BAC-9301A | Unitary Controller |
| BAC-7301C, BAC-9301C | AHU Controller w/ RTC | BAC-9301A(C)(E) | Unitary Controller w/ RTC |
| BAC-7302, BAC-9301 | RTU Controller | BAC-9301A) | Unitary Controller |
| BAC-7302C, BAC-9301C | RTU Controller w/ RTC | BAC-9301A(C)(E) | Unitary Controller w/ RTC |
| BAC-7303, BAC-9301 | FCU Controller | BAC-9301A | Unitary Controller |
| BAC-7303C, BAC-9301 | FCU Controller w/ RTC | BAC-9301A(C)(E) | Unitary Controller w/ RTC |
| BAC-7401, BAC-9301 | HPU Controller | BAC-9301A | Unitary Controller |
| BAC-7401C, BAC-9301C | HPU Controller w/ RTC | BAC-9301A(C)(E) | Unitary Controller w/ RTC |
| <p>*NOTE: Replacement of a controller also requires replacement of any connected KMD-1xxx NetSensor with the equivalent STE-9xxx NetSensor (see below). Also the cable connecting the controller and NetSensor must be replaced with an equivalent length of Cat. 5 Ethernet patch cable (e.g., HSO-9001, HSO-9011, HSO-9012).</p> | | | |

KMD-11XX/12XX NETSENSOR CROSS-REFERENCE

| Model Number* | Comments | Replacement Model Number** | Comments |
|---|-----------------------------|----------------------------|-----------------------------|
| KMD-1161 | Temperature Only | STE-9001 | Temperature Only |
| KMD-1164 | | | |
| KMD-1162 | Temp. Only, Hospitality*** | | |
| KMD-1181 | Temp. and Humidity | STE-9021 | Temp. and Humidity |
| KMD-1183 | | | |
| KMD-1184 | | | |
| KMD-1185 | | | |
| KMD-1261 | Temp. and Motion | STE-9201 | Temp. and Motion |
| KMD-1281 | Temp., Humidity, and Motion | STE-9221 | Temp., Humidity, and Motion |
| <p>*NOTE: Replacement of a KMD-1xxx NetSensor with the equivalent STE-9xxx NetSensor also requires replacement of the controller (see above). Also the cable connecting the controller and NetSensor must be replaced with an equivalent length of Cat. 5 Ethernet patch cable (e.g., HSO-9001, HSO-9011, HSO-9012). The button interface on the new NetSensor will be different.</p> | | | |
| <p>**NOTE: For color choice, the default color is Light Almond. For white, add a W to the end (e.g., STE-9001W).</p> | | | |
| <p>***NOTE: KMD-1162 Hospitality NetSensors have slide switches for fan speed and heat/cool/off selection. An STE-9001 can perform similar functions but has a very different user interface.</p> | | | |

SEQUENCES OF OPERATIONS

AHU (Air Handling Unit)

See **RTU (Roof Top Unit) or AHU (Air Handling Unit)** on page 62.

CAV (Constant Air Volume)




Illustration: VAV Operations

See relevant sections of **VAV (Variable Air Volume)** on page 69 for additional descriptions.

FCU (Fan Coil Unit)












Illustration: FCU Operations

Introduction (FCU)

Topics in this section cover the FCU sequences of operation for the KMC Conquest BAC-9301 unitary controller. These are advanced topics for controls technicians and engineers.

NOTE: For sequence of operations with charts and wiring diagrams, see also the FCU submittal sheets (see [Submittal Sheets \(Diagrams and Operation\) on page 5](#)).

NOTE: See also [BACnet Objects List on page 80](#) for more information about objects listed in the descriptions.

Room Temperature Setpoints (FCU)

Types of Setpoints

There are four temperature setpoints each for heating and cooling for a total of eight setpoints.

- Active cooling
- Occupied cooling
- Unoccupied cooling
- Standby cooling
- Active heating
- Occupied heating
- Unoccupied heating
- Standby heating

These setpoints are based on a user-entered value or the occupancy state and standby value described in [Occupancy, Motion Sensing, and Standby \(FCU\) on page 48](#).

Active Setpoint

The active setpoint is the current setpoint being used for control. The active setpoint is determined according to the occupancy state (see [Occupancy, Motion Sensing, and Standby \(FCU\) on page 48](#)):

- When the space becomes **Occupied**, the Occupied Cooling Setpoint (AV5) is placed in the Active Cooling Setpoint (AV3), and the Occupied Heating Setpoint (AV6) is placed in the Active Heating Setpoint (AV4).
- When the space becomes **Unoccupied**, the Unoccupied Cooling Setpoint (AV7) is placed in the Active Cooling Setpoint (AV3), and the Unoccupied Heating Setpoint (AV8) is placed in the Active Heating Setpoint (AV4).
- When the space enters **Standby**, the controller calculates the active setpoint by adding or subtracting (depending on mode) the Standby Offset (AV12) from the relevant occupied (but not unoccupied) setpoint. Standby is only applied to the occupied setpoint and thus is only valid when the schedule is active.

A user with a level 1 password (if a level 1 password is configured) can enter an active setpoint from the KMC Conquest STE-9000 series NetSensor (via AV3 and AV4). The local override is valid only when the schedule is inactive. This change is for a limited time or until the next time the occupancy state changes.

For display and control loop calculations, the active setpoint value is compared to the value of the space temperature variable AV1, which is taken from the physical temperature input AI1.

Occupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is occupied, which is usually controlled by the schedule in the controller.

Unoccupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is unoccupied, which is usually controlled by the schedule in the controller.

Standby Setpoint

This setpoint is used when the controller is in the standby state. It is calculated from the relevant occupied setpoint value and the Standby Offset value. The Standby Offset value is entered by the controls technician during controller setup and system commissioning. See [Occupancy, Motion Sensing, and Standby \(FCU\) on page 48](#).

Setpoint Limits

Programming in the controller limits the setpoint entry so that a heating setpoint is not set higher than its corresponding cooling setpoint.

If a user adjusts a setpoint so that it falls within the range set by the value of Minimum Setpoint Differential, the corresponding setpoint is changed to maintain the differential. For example, the Minimum Setpoint Differential is 4° F and the Occupied Heating setpoint is 70° F. If the user lowers the Occupied Cooling setpoint to 71° F, the controller recalculates the Occupied Heating setpoint and changes it to 67° F.

Occupancy, Motion Sensing, and Standby (FCU)

The controller is designed to operate as a stand-alone controller and can determine occupancy based on its internal occupancy schedule and (if connected to an STE-92x1/95x1 NetSensor) motion in the space. The controller can be in any one of the following occupancy states:

- Occupied
- Unoccupied
- Standby

The controller chooses which setpoint to use based on the occupancy and standby states. See [Room Temperature Setpoints \(FCU\) on page 47](#).

The occupancy and standby states can also be commanded by another BACnet device or an operator workstation connected to the building automation network.

Occupied

For controllers without a connected motion sensor, the controller starts in the occupied state. If an internal schedule is enabled, the state of the schedule is set to either occupied or unoccupied as the initial state. See [Scheduling Occupancy \(FCU\) on page 49](#).

Unoccupied

The controller changes to the unoccupied state only if the internal occupancy schedule is enabled and if the schedule is inactive.

Standby

In units with a connected motion sensor, the controller starts in standby and changes to occupied after detecting motion in the space. The controller will change from occupied to standby after a lack of motion for the period specified by the variable Standby Timer (AV28).

System Mode and Cooling/Heating Changeover (FCU)

The heating/cooling mode can also be manually set by adjusting the System Mode through the user interface. The System Mode (MSV2) can be set to Off, Auto, Heat, or Cool. Setting the System Mode to Heat or Cool forces the unit into that mode. Setting the System Mode to Off turns off all heating and cooling functions but has no effect on fan control.

When set to Auto:

- If the space temperature rises above the active cooling setpoint, the mode is set to cooling.
- If the space temperature falls below the heating setpoint, the mode is set to heating.
- The changeover is immediate.

Scheduling Occupancy (FCU)

The schedule in the controller is a standard BACnet schedule object. It can be changed from a configuration tool or a BACnet operator workstation.

The internal occupancy schedule changes the controller between the Occupied (Active) and Unoccupied (Inactive) states. If the controller is connected to an STE-92x1/95x1 NetSensor with a motion sensor, the motion sensor may change the controller between occupied and standby based on motion detected in the space.

NOTE: See also [Occupancy, Motion Sensing, and Standby \(FCU\)](#) on page 48.

Dehumidification Sequence (FCU)

NOTE: See also the four-pipe section in [Illustration: FCU Operations](#) on page 46.

Optional dehumidification control is available only for four-pipe applications when a controller is connected to an STE-9x21 NetSensor with an internal humidity sensor. (It is not available in two-pipe applications.) The controller can run the dehumidification sequence only if the heating and cooling modes are set to automatic.

If the space humidity rises above the dehumidification setpoint, the cooling valve is opened 100%. The heating valve then follows its normal operation to maintain the cooling setpoint. Once the space humidity drops below the dehumidification setpoint minus its span, dehumidification ceases and the heating and cooling valves resume normal operation.

Temperature Sensing Inputs (FCU)

Space Temperature Sensing

The controller uses a connected STE-9000 series NetSensor digital wall sensor or an STE-6010/6014/6017 analog wall sensor. See [Digital STE-9000 Series NetSensors on page 10](#) and [Analog STE-6000 Series Thermistor Sensors on page 12](#).

WST (Water Supply Temperature) Sensor

The WST sensor is a required sensor (e.g., STE-1455) for two-pipe fan coil units and is optional for other fan coil applications. The controller is configured for a Type III thermistor sensor to monitor water temperature. The water temperature can be monitored as an analog input, and it is also stored as an analog value object (AV19).

DAT (Discharge Air Temperature) Sensor

The DAT input is a required input for economizer applications and is an option for other applications. For DAT applications, the controller is configured for a Type III thermistor sensor (e.g., STE-1405). DAT can be monitored as an analog input (AI3), and it is also stored as an analog value object (AV20).

Fan Status (FCU)

The function requires an NC (Normally Closed) fan status switch (e.g., CSE-1102) connected across the fan input terminals (UI7 and GND for 2-pipe FCU; UI6 and GND for 4-pipe FCU). When the fan is started at any speed, the controller program waits 10 seconds for the Fan Status switch (FST) to open. The fan output remains enabled until the fan status switch opens. The state of fan status is stored in a binary variable (BV14).

PID (Proportional Integral Derivative) Loops (FCU)

A PID control loop calculates an error value from the difference between the measured room temperature and the active setpoint values. The error value is expressed as a percentage and is typically used in a controller to control the state of an output. When the difference between the setpoint and room temperature is large, the error is large. As the system reduces the difference between the setpoint and space temperature, the error becomes smaller. In a simple example, if the output of the PID loop that is controlling a modulating valve is 50%, the valve position is half-way open; if the output of the loop is 100%, the valve position is fully open.

The controller uses up to three PID control loops:

- The **heating** loop and **cooling** loop are implemented in all models.
- The **reheat** loop is used only for heating outputs during dehumidification.

The PID control loops in the controller are standard BACnet objects.

Valve Operation (FCU)

Four-Pipe vs. Two Pipe

Four-pipe applications have both hot and chilled water valves for heating and cooling and an option for dehumidification. Two-pipe applications have one valve, a method to determine supply water temperature, and an option for electric reheat.

On/Off Valves

On a call for cooling or heating, the valve will open once the PID loop controlling the valve reaches 50% (half the span away from setpoint). The valve will close once the loop falls to 5%. The controller programming supports both normal and reverse action valves, which are set from the user interface.

Modulating Valves

On a call for cooling or heating, a modulating valve modulates from 0 to 100% over the first half (0 to 50%) of the PID loop output controlling the valve. When the temperature drops below 50% of the span, the valve starts modulating closed.

Valve Action

The controller supports both normal and reverse valve action that is set from the user interface.

- **Normal**—The valve is fully closed when the output signal is inactive and fully open when the output is active.
- **Reverse**—The valve is fully closed when the output signal is active and fully open when the output is inactive.

Two-Pipe Water Supply Temperature Evaluation

For two-pipe fan coil units, the controller uses the WST sensor to determine if chilled or hot water is being supplied to the unit. See [WST \(Water Supply Temperature\) Sensor on page 50](#). The water type is determined by comparing the value of the water temperature sensor input to the room temperature. The controller programming then determines that the water temperature is one of the following.

- **Hot**—the water temperature is 10° F (default) or more above room temperature.
- **Chilled**—the water temperature is over 10° F (default) or more below room temperature.
- **None**—the water temperature is within that range.

NOTE: The default of 10° F can be changed in the STE-9xx1 menu by modifying the value in EVAL. See [Conquest NetSensor Screen Abbreviations on page 27](#).

If the water temperature is evaluated as None, the controller runs the water evaluation program every six hours. During a water evaluation, the controller opens the valve until a water type is determined or for five minutes, whichever is reached first. If a water evaluation is not being performed, the valve remains closed.

Electric Heating (Two-Pipe Option)

Electric heat can be added to two-pipe systems, typically through a duct or baseboard resistance heater controlled by a relay.

When the supply water type is chilled water and there is a call for heat, the controller controls the heating element through output terminal B05. The output turns on when the heating loop is greater than 99%. The output is turned off when the loop falls to 5%. If the supply water type is hot water, only the water valve output is used to satisfy a call for heat.

Fan Operation (FCU)

Automatic Fan Control

The controller supports both modulating fans and fans with one, two, or three speeds. Fan speed is determined by the PID loop currently controlling the heating or cooling. Fan speed control is set up from the user interface by a user with a level 2 password (if a level 2 password is configured).

A user with a level 1 password (if a level 1 password is configured) can set the controller controlled fan to either run continuously or to start automatically on a call for cooling or heating.

- **On**—The fan runs continuously regardless of the heating/cooling modes or occupied/standby states.
- **Auto**—The fan begins running only when there is a call for cooling or heating. After the call for cooling or heating ends, the fan continues to run for the period set by the fan delay timer.
- **Low, Medium, High**—For systems with three-speed fans, the user has the choice of low, medium or high speed as the continuous running speed for the fan. Two-speed fans have two choices.

One, Two, and Three Speed Fans

For one, two, and three speed fans, the controller controls the fan speed with terminals B01 (Low), B02 (Medium), and B03 (High) and SC.

- Single speed fans use terminal B01 only
- Two speed fans use terminals B01 and B03
- Three speed fans use terminals B01, B02, and B03

The fan output terminals are energized as the cooling or heating loop varies from 0–100%. When the fan mode is set to Auto and either valve is called for, the fan starts on low speed. As the space temperature deviates further from the setpoint, the fan speed changes to medium. As the space temperature passes the active setpoint (plus/minus its span), high fan speed becomes the active speed. As the space temperature begins to return to the setpoint, the active fan speed drops to medium. As the space temperature further returns to the setpoint, the fan speed switches to low. As the active valve closes, all fan speeds are deenergized. During the occupied and standby modes, low fan speed is energized while both valves are closed if the fan mode is set to On.

Fan terminal activation is shown in the following table.

| FAN SPEED | L TERMINAL (B01) | | M TERMINAL (B02) | | H TERMINAL (B03) | |
|--------------|------------------|-----|------------------|-----|------------------|-----|
| | ON | OFF | ON | OFF | ON | OFF |
| One (Low) | Active valve | 5% | N/A | N/A | N/A | N/A |
| Two (Medium) | Active valve | 5% | N/A | N/A | 95% | 80% |
| Three (High) | Active valve | 5% | 65% | 50% | 95% | 80% |

Illustration: Fan Speed and Terminal States

Modulating Fans

When the fan mode is set to Auto and either valve opens, the fan (controlled by U07) starts at the minimum fan speed. Once the active valve is fully open, as the space temperature deviates further from the setpoint, the fan speed increases until it reaches the maximum fan speed. As the space temperature begins to return to the setpoint, the fan speed modulates toward the minimum fan speed. The fan runs at the minimum speed until the space temperature further returns to setpoint and the active valve closes. During the occupied and standby modes, the fan is energized at the minimum fan speed while both valves are closed if the fan mode is set to On.

HPU (Heat Pump Unit)









Illustration: HPU Operations

Introduction (HPU)

Topics in this section cover the sequences of operation for the HPU applications in the KMC Conquest BAC-9301 unitary controller. These are advanced topics for controls technicians and engineers.

NOTE: For sequence of operations with charts and wiring diagrams, see also the HPU submittal sheet. See [Submittal Sheets \(Diagrams and Operation\) on page 5](#).

NOTE: See also [BACnet Objects List on page 80](#) for more information about objects listed in the descriptions.

NOTE: For information about the **CO₂ sensor and DCV (Demand Control Ventilation)** operation, see [STE-93xx/95xx CO2 Sensor and DCV on page 10](#).

Room Temperature Setpoints (HPU)

Types of Setpoints

There are four temperature setpoints each for heating and cooling for a total of eight setpoints:

- Active cooling
- Occupied cooling
- Unoccupied cooling
- Standby cooling
- Active heating
- Occupied heating
- Unoccupied heating
- Standby heating

These setpoints are based on a user-entered value or the occupancy state and standby value described in [Occupancy, Motion Sensing, and Standby \(HPU\) on page 56](#).

Active Setpoint

The active setpoint is the current setpoint being used for control. The active setpoint is determined according to the occupancy state (see [Occupancy, Motion Sensing, and Standby \(HPU\) on page 56](#)):

- When the space becomes **Occupied**, the Occupied Cooling Setpoint (AV5) is placed in the Active Cooling Setpoint (AV3), and the Occupied Heating Setpoint (AV6) is placed in the Active Heating Setpoint (AV4).
- When the space becomes **Unoccupied**, the Unoccupied Cooling Setpoint (AV7) is placed in the Active Cooling Setpoint (AV3), and the Unoccupied Heating Setpoint (AV8) is placed in the Active Heating Setpoint (AV4).
- When the space enters **Standby**, the controller calculates the active setpoint by adding or subtracting (depending on mode) the Standby Offset (AV12) from the relevant occupied (but not unoccupied) setpoint. Standby is only applied to the occupied setpoint and thus is only valid when the schedule is active.

AA user with a level 1 password (if a level 1 password is configured) can enter an active setpoint from the KMC Conquest STE-9000 series NetSensor (via AV3 and AV4). The local override is valid only when the schedule is inactive. This change is for a limited time or until the next time the occupancy state changes.

For display and control loop calculations, the active setpoint value is compared to the value of the space temperature variable AV1, which is taken from the physical temperature input AI1.

Occupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is occupied, which is usually controlled by the schedule in the controller.

Unoccupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is unoccupied, which is usually controlled by the schedule in the controller.

Standby Setpoint

This setpoint is used when the controller is in the standby state. It is calculated from the relevant occupied setpoint value and the Standby Offset value. The Standby Offset value is entered by the controls technician during controller setup and system commissioning. See [Occupancy, Motion Sensing, and Standby \(HPU\) on page 56](#).

Setpoint Limits

Programming in the controller limits the setpoint entry so that a heating setpoint is not set higher than its corresponding cooling setpoint.

If a user adjusts a setpoint so that it falls within the range set by the value of Minimum Setpoint Differential, the corresponding setpoint is changed to maintain the differential. For example, the Minimum Setpoint Differential is 4° F and the Occupied Heating setpoint is 70° F. If the user lowers the Occupied Cooling setpoint to 71° F, the controller recalculates the Occupied Heating setpoint and changes it to 67° F.

Occupancy, Motion Sensing, and Standby (HPU)

The controller is designed to operate as a stand-alone controller and can determine occupancy based on its internal occupancy schedule and (if connected to an STE-92x1/95x1 NetSensor) motion in the space. The controller can be in any one of the following occupancy states:

- Occupied
- Unoccupied
- Standby

The controller chooses which setpoint to use based on the occupancy and standby states. See [Room Temperature Setpoints \(HPU\) on page 55](#).

The occupancy and standby states can also be commanded by another BACnet device or an operator workstation connected to the building automation network.

Occupied

For controllers without a connected motion sensor, the controller starts in the occupied state. If an internal schedule is enabled, the state of the schedule is set to either occupied or unoccupied as the initial state. See [Scheduling Occupancy \(HPU\) on page 57](#).

Unoccupied

The controller changes to the unoccupied state only if the internal occupancy schedule is enabled and if the schedule is inactive.

Standby

In units with a connected motion sensor, the controller starts in standby and changes to occupied after detecting motion in the space. The controller will change from occupied to standby after a lack of motion for the period specified by the variable Standby Timer (AV28).

System Mode and Cooling/Heating Changeover (HPU)

The heating/cooling mode can also be manually set by adjusting the System Mode through the user interface. The System Mode (MSV2) can be set to Off, Auto, Heat, Cool, or Emergency Heat. Setting the System Mode to Heat, Cool, or Emergency Heat forces the unit into that mode. Setting the System Mode to Off turns off all heating and cooling functions but has no effect on fan control.

When set to Auto:

- If the space temperature rises above the active cooling setpoint, the mode is set to cooling.
- If the space temperature falls below the heating setpoint, the mode is set to heating.
- The changeover does not take place until the time set by Fan Off Delay expires.

Scheduling Occupancy (HPU)

The schedule in the controller is a standard BACnet schedule object. It can be changed from a configuration tool or a BACnet operator workstation.

The internal occupancy schedule changes the controller between the Occupied (Active) and Unoccupied (Inactive) states. If the controller is connected to an STE-92x1/95x1 NetSensor with a motion sensor, the motion sensor may change the controller between occupied and standby based on detected motion.

NOTE: See also [Occupancy, Motion Sensing, and Standby \(HPU\) on page 56](#).

Dehumidification Sequence (HPU)

NOTE: See [Illustration: HPU Operations on page 54](#).

Optional dehumidification control is available only when a controller is connected to an STE-9x21 NetSensor with an internal humidity sensor.

The controller can run the dehumidification sequence only if the heating and cooling modes are set to automatic.

When dehumidification is active, cooling output is set to 100%. Heating then reheats the discharge air to maintain the space temperature to the value of the Active Cooling setpoint. The controller continuously runs the fan during dehumidification regardless of other fan settings.

If the space humidity rises above the dehumidification setpoint, compressor 1 is energized if the minimum off time has been met. If the humidity remains high for the stage delay and compressor 2's minimum off time has been met, compressor 2 is energized. Auxiliary heat is then cycled to maintain the cooling setpoint. Once the space humidity drops below the dehumidification setpoint minus its span, dehumidification ceases and the compressors resume normal space temperature control.

Temperature Sensing Inputs (HPU)

Space Temperature Sensing

The controller uses a connected STE-9000 series NetSensor digital wall sensor or an STE-6010/6014/6017 analog wall sensor. See [Digital STE-9000 Series NetSensors on page 10](#) and [Analog STE-6000 Series Thermistor Sensors on page 12](#).

OAT (Outside Air Temperature) Sensing

The OAT input is a required input for compressor lockout and economizer applications and is an optional input for others. The controller is configured for a Type III thermistor sensor (e.g., STE-1451) to monitor outside air temperature. The outside air temperature is also stored in an analog value object (AV19).

DAT (Discharge Air Temperature) Sensor

The DAT input is a required input for economizer applications and is an option for other applications. For DAT applications, the controller is configured for a Type III thermistor sensor (e.g., STE-1405). The DAT can be monitored as an analog input (AI3) and is also stored in an analog value object (AV20).

Fan Status (HPU)

NOTE: See [Illustration: HPU Operations on page 54](#).

The function requires an NC (Normally Closed) fan status switch (e.g., CSE-1102) connected across the fan input terminals (UI6 and GND). When the fan is started at any speed, the controller program waits 10 seconds for the Fan Status switch (FST) to open. If the status switch does not open within 10 seconds after the fan is commanded to start, all heating and cooling is commanded to stop at BACnet priority level 5. The fan output remains enabled until the fan status switch opens. The state of fan status is stored in a binary variable (BV14).

PID (Proportional Integral Derivative) Loops (HPU)

A PID control loop calculates an error value from the difference between the measured room temperature and the active setpoint. The error value is expressed as a percentage and is typically used in a controller to control the state of an output. When the difference between the setpoint and room temperature is large, the error is large. As the system reduces the difference between the setpoint and space temperature, the error becomes smaller. In a simple example, if the output of the PID loop that is controlling a modulating valve is 50%, the valve position is half-way open; if the output of the loop is 100%, the valve position is fully open.

The controller uses up to four PID control loops:

- The **heating** loop and **cooling** loop are implemented in all models.
- The **discharge air** loop controls the position of the economizer damper. For this loop, the setpoint is the measured temperature of the air that is discharged by a heat pump unit. See [Economizer Cooling \(HPU\) and DCV on page 60](#).
- The **reheat** loop is used only for heating outputs during dehumidification. See also [Auxiliary and Emergency Heat Action \(HPU\) on page 61](#).

The PID control loops in the controller are standard BACnet objects.

Staged Heating And Cooling (HPU)

Staged heating and cooling are used for applications other than chilled or hot water systems. Typically the controller controls gas heat, electric heat, or direct expansion (DX) cooling with staged heating and cooling. Staged heating or cooling can be mixed with a modulating valve for heating or cooling.

NOTE: See [Illustration: HPU Operations on page 54](#).

Staged Cooling

As the demand for cooling increases, the controller starts the first stage of cooling when the cooling PID loop rises above 99% and the first stage of cooling has been turned off for at least the time set by the value of Minimum Off Time. See [PID \(Proportional Integral Derivative\) Loops \(HPU\) on page 58](#).

The second stage of cooling turns on when:

- The cooling loop rises above 99%.
- And the first stage has been turned on for the period set by Stage Delay.
- And the second stage has been turned off for at least as long as the value of Minimum Off Time.

As the demand for cooling is satisfied, the second stage turns off when the cooling PID loop drops below 50%. This first stage turns off when the cooling loop drops below 1%.

Staged Heating

As the demand for heating increases, the controller starts the first stage of heating when the heating PID loop rises above 99%. The second stage of heating turns on when the heating loop rises above 99% and the first stage has already been on for the period set by the Stage Delay.

As the demand for heating is satisfied, the second stage is turned off when the heating PID loop drops below 50%. This first stage is turned off when the heating loop drops below 1%.

See also [Auxiliary and Emergency Heat Action \(HPU\) on page 61](#).

Fan Operation (HPU)

A user with a level 1 password (if a level 1 password is configured) can set the controller controlled fan to either run continuously or to start automatically on a call for cooling or heating.

- **On**—The fan runs continuously regardless of the heating/cooling modes or occupied/standby states.
- **Auto**—The fan begins running only when there is a call for cooling or heating. After the call for cooling or heating ends, the fan continues to run for the period set by the fan delay timer.

Economizer Cooling (HPU) and DCV

NOTE: See [Illustration: HPU Operations on page 54](#).

NOTE: During Occupied mode, the optional economizer can be enabled only if both OAT and DAT sensors are connected to the controller. See [OAT \(Outside Air Temperature\) Sensing on page 58](#) and [DAT \(Discharge Air Temperature\) Sensor on page 58](#).

During occupied mode, if the OAT drops below the economizer enable temperature and there is a call for cooling, the economizer mode is enabled. The economizer mode is disabled if the OAT rises 1° above the economizer enable temperature.

Once enabled, the economizer OAD (Outside Air Damper) opens to the larger value of either the minimum damper position limit (Minimum Econ Damper) or the DAT PID loop. The DAT loop modulates from 0 to 100% as the DAT rises above the DAT setpoint. The DAT setpoint resets between the sensed room temperature and the limit for minimum discharge air temperature as the cooling loop varies between 0 and 50%. If the DAT decreases below 55° F, the OAD returns to the minimum damper position.

While economizing, the OAD is open to the greater of the minimum damper position or DAT control. The OAD is shut during unoccupied mode and any time the fan is off.

NOTE: For information about the **CO₂ sensor and DCV (Demand Control Ventilation)** operation, see [STE-93xx/95xx CO2 Sensor and DCV on page 10](#).

Reversing Valve Action (HPU)

The controller reversing valve output B04 to HPU terminal O/B, is energized on a call for cooling ("O" function). The action can be changed from the user interface to be active on a call for heating ("B" function). The "O" function is the default.

HPU REVERSING VALVE CONNECTIONS AND CONFIGURATION

| BAC-9301 Terminal | HPU Terminal | RVA on NetSensor Display* | BV15 Object State | Reversing Valve Action* |
|-------------------|--------------|---------------------------|-------------------|-------------------------|
| B04 | O | ACTV CL or Disable** | Inactive | Energized for Cooling |
| | B | ACTV HT or Enable** | Active | Energized for Heating |

*NOTE: The RVA (Reversing Valve) configuration is in the SYS menu of the STE-9xxx NetSensor. See [Controller Configuration with STE-9xx1 Menus on page 26](#).

**NOTE: Displayed text is dependent on firmware version. Only initial firmware had Disable/Enable.

Illustration: HPU Reversing Valve Connections and Configuration

Auxiliary and Emergency Heat Action (HPU)

NOTE: See [Illustration: HPU Operations on page 54](#).

The heat pump unit AUX/E terminal is for auxiliary or emergency heat.

Auxiliary heat operation can be configured for one of three modes:

- **Compressor lockout**—The compressors are locked out when the outside air temperature drops below the value of the Compressor OAT Low Limit, and the auxiliary heat output follows the compressor 1 heating sequence. The lockout is cleared when the outside air temperature rises 2° F above the value of Compressor OAT Low Limit. The B05 (AUX/E) output terminal is active only on a call for heating when the compressors are locked out.
- **Third stage**—The B05 (AUX/E) output functions as the output for a third stage of heat. When auxiliary heat is configured for third stage, the unit is in heating mode and compressor 2 has been on for the stage delay, the aux heat output is energized. As the space temperature rises above 65% of the heating span below heating setpoint, aux heat is deenergized.
- **None**—Auxiliary heat is disabled.

When the system mode is manually set to **Emergency** heat, the compressor heating outputs (B02 and B03) are locked out and emergency heat (B05) is energized as the space temperature drops below the heating setpoint minus heating span. As the space temperature rises above the heating setpoint, the emergency heat output is deenergized.

RTU (Roof Top Unit) or AHU (Air Handling Unit)










Illustration: RTU Operations

Introduction (RTU/AHU)

Topics in this section cover the RTU sequences of operation for the KMC Conquest BAC-9301 unitary controller. These are advanced topics for controls technicians and engineers.

NOTE: For sequence of operations with charts and wiring diagrams, see also the RTU submittal sheets (see [Submittal Sheets \(Diagrams and Operation\)](#) on page 5).

NOTE: See also [BACnet Objects List](#) on page 80 for more information about objects listed in the descriptions.

NOTE: For information about the **CO₂ sensor and DCV (Demand Control Ventilation)** operation, see [STE-93xx/95xx CO2 Sensor and DCV on page 10](#).

Room Temperature Setpoints (RTU/AHU)

Types of Setpoints

There are four temperature setpoints each for heating and cooling for a total of eight setpoints.

- Active cooling
- Occupied cooling
- Unoccupied cooling
- Standby cooling
- Active heating
- Occupied heating
- Unoccupied heating
- Standby heating

These setpoints are based on a user-entered value or the occupancy state and standby that is described in [Occupancy, Motion Sensing, and Standby \(RTU/AHU\) on page 64](#).

Active Setpoint

The active setpoint is the current setpoint being used for control. The active setpoint is determined according to the occupancy state (see [Occupancy, Motion Sensing, and Standby \(RTU/AHU\) on page 64](#)):

- When the space becomes **Occupied**, the Occupied Cooling Setpoint (AV5) is placed in the Active Cooling Setpoint (AV3), and the Occupied Heating Setpoint (AV6) is placed in the Active Heating Setpoint (AV4).
- When the space becomes **Unoccupied**, the Unoccupied Cooling Setpoint (AV7) is placed in the Active Cooling Setpoint (AV3), and the Unoccupied Heating Setpoint (AV8) is placed in the Active Heating Setpoint (AV4).
- When the space enters **Standby**, the controller calculates the active setpoint by adding or subtracting (depending on mode) the Standby Offset (AV12) from the relevant occupied (but not unoccupied) setpoint. Standby is only applied to the occupied setpoint and thus is only valid when the schedule is active.

A user with a level 1 password (if a level 1 password is configured) can enter an active setpoint from the KMC Conquest STE-9000 series NetSensor (via AV3 and AV4). The local override is valid only when the schedule is inactive. This change is for a limited time or until the next time the occupancy state changes.

For display and control loop calculations, the active setpoint value is compared to the value of the space temperature variable AV1, which is taken from the physical temperature input AI1.

Occupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is occupied, which is usually controlled by the schedule in the controller.

Unoccupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is unoccupied, which is usually controlled by the schedule in the controller.

Standby Setpoint

The standby setpoint is used when the controller is in the standby state. It is calculated from the occupied setpoint and the value of Standby Offset. The Standby Offset value is entered by the controls technician during controller setup and system commissioning. See [Occupancy, Motion Sensing, and Standby \(RTU/AHU\) on page 64](#).

Setpoint Limits

Programming in the controller limits the setpoint entry so that a heating setpoint is not set higher than its corresponding cooling setpoint.

If a user adjusts a setpoint so that it falls within the range set by the value of Minimum Setpoint Differential, the corresponding setpoint is changed to maintain the differential. For example, the Minimum Setpoint Differential is 4° F and the Occupied Heating setpoint is 70° F. If the user lowers the Occupied Cooling setpoint to 71° F, the controller recalculates the Occupied Heating setpoint and changes it to 67° F.

Occupancy, Motion Sensing, and Standby (RTU/AHU)

The controller is designed to operate as a stand-alone controller and can determine occupancy based on its internal occupancy schedule and (if connected to an STE-92x1/95x1 NetSensor) motion in the space. The controller can be in any one of the following occupancy states:

- Occupied
- Unoccupied
- Standby

The controller chooses which setpoint to use based on the occupancy and standby states. See [Room Temperature Setpoints \(RTU/AHU\) on page 63](#).

The occupancy and standby states can also be commanded by another BACnet device or an operator workstation connected to the building automation network.

Occupied

For controllers without a connected motion sensor, the controller starts in the occupied state. If an internal schedule is enabled, the state of the schedule is set to either occupied or unoccupied as the initial state. See [Scheduling Occupancy \(RTU/AHU\) on page 65](#).

Unoccupied

The controller changes to the unoccupied state only if the internal occupancy schedule is enabled and if the schedule is inactive.

Standby

In units with a connected motion sensor, the controller starts in standby and changes to occupied after detecting motion in the space. The controller will

change from occupied to standby after a lack of motion for the period specified by the variable Standby Timer (AV28).

System Mode & Cooling/Heating Changeover (RTU/AHU)

The heating/cooling mode can also be manually set by adjusting the System Mode through the user interface. The System Mode (MSV2) can be set to Off, Auto, Heat, or Cool. Setting the System Mode to Heat or Cool forces the unit into that mode. Setting the System Mode to Off turns off all heating and cooling functions but has no effect on fan control.

When set to Auto:

- If the space temperature rises above the active cooling setpoint, the mode is set to cooling.
- If the space temperature falls below the heating setpoint, the mode is set to heating.
- The changeover does not take place until the time set by Fan Off Delay expires.

Scheduling Occupancy (RTU/AHU)

The schedule in the controller is a standard BACnet schedule object. It can be changed from a configuration tool or a BACnet operator workstation.

The internal occupancy schedule changes the controller between the Occupied (Active) and Unoccupied (Inactive) states. If the controller is connected to an STE-92x1/95x1 NetSensor with a motion sensor, the motion sensor may change the controller between occupied and standby based on motion detected in the space.

NOTE: See also [Occupancy, Motion Sensing, and Standby \(RTU/AHU\) on page 64](#).

Dehumidification Sequence (RTU/AHU)

NOTE: See [Illustration: RTU Operations on page 62](#).

Optional dehumidification control is available only when a controller is connected to an STE-9x21 NetSensor with an internal humidity sensor.

The controller can run the dehumidification sequence only if the heating and cooling modes are set to automatic.

When dehumidification is active, cooling output is activated to 100%. Heating then reheats the discharge air to maintain the space temperature to the value of the Active Cooling setpoint. The controller continuously runs the fan during dehumidification regardless of other fan settings.

Temperature Sensing Inputs (RTU/AHU)

Space Temperature Sensing

The controller uses a connected STE-9000 series NetSensor digital wall sensor or an STE-6010/6014/6017 analog wall sensor. See [Digital STE-9000 Series NetSensors on page 10](#) and [Analog STE-6000 Series Thermistor Sensors on page 12](#).

OAT (Outside Air Temperature) Sensing

The OAT input is a required input for compressor lockout and economizer applications and is an optional input for others. The controller is configured for a Type III thermistor sensor (e.g., STE-1451) to monitor outside air temperature. The outside air temperature is also stored in an analog value object (AV19).

DAT (Discharge Air Temperature) Sensor

The DAT input is a required input for economizer applications and is an option for other applications. For DAT applications, the controller is configured for a Type III thermistor sensor (e.g., STE-1405). The DAT can be monitored as an analog input (AI3) and is also stored in an analog value object (AV20).

Fan Status (RTU/AHU)

NOTE: See [Illustration: RTU Operations on page 62](#).

The function requires an NC (Normally Closed) fan status switch (e.g., CSE-1102) connected across the fan input terminals (UI6 and GND). When the fan is started at any speed, the controller program waits 10 seconds for the Fan Status switch (FST) to open. If the status switch does not open within 10 seconds after the fan is commanded to start, all heating and cooling is commanded to stop at BACnet priority level 5. The fan output remains enabled until the fan status switch opens. The state of fan status is stored in a binary variable (BV14).

PID (Proportional Integral Derivative) Loops (RTU/AHU)

A PID control loop calculates an error value from the difference between the measured room temperature and the active setpoint. The error value is expressed as a percentage and is typically used in a controller to control the state of an output. When the difference between the setpoint and room temperature is large, the error is large. As the system reduces the difference between the setpoint and space temperature, the error becomes smaller. In a simple example, if the output of the PID loop that is controlling a modulating valve is 50%, the valve position is half-way open; if the output of the loop is 100%, the valve position is fully open.

The controller uses up to four PID control loops:

- The **heating** loop and **cooling** loop are implemented in all models.
- The **discharge air** loop controls the position of the economizer damper. For this loop, the setpoint is the measured temperature of the air that is discharged by the RTU. See [Economizer Cooling \(RTU/AHU\) and DCV \(RTU\) on page 68](#).
- The **reheat** loop is used only for heating outputs during dehumidification.

The PID control loops in the controller are standard BACnet objects.

Modulating Cooling and Heating (RTU/AHU)

Modulating cooling and heating are used in controller controlled systems with modulating valves and chilled or hot water coils. A single modulating valve can be used with staged cooling or heating.

Modulating Cooling

Modulating cooling does not start until the cooling loop exceeds 99%. Then the analog cooling output modulates over 10 VDC as the cooling loop changes from

0 to 100%. When the cooling loop drops below 1%, cooling stops until the loop again exceeds 99%.

If the economizer is enabled, cooling will not start modulating until the economizer damper is fully open.

Modulating Heating

Modulating heating does not start until the heating loop exceeds 99%. Then the analog heating output modulates over 10 VDC as the heating loop changes from 0 to 100%. When the heating loop drops below 1%, heating stops until the loop exceeds 99% again.

Valve Action

The controller supports both normal and reverse valve action that can be set from the user interface.

- **Normal**—The valve is fully closed when the output signal is 0 VDC and fully open when the output is 10 VDC.
- **Reverse**—The valve is fully closed when the output signal is 10 VDC and fully open when the output is 0 VDC.

Staged Heating And Cooling (RTU/AHU)

Staged heating and cooling are used for applications other than chilled or hot water systems. Typically the controller controls gas heat, electric heat, or direct expansion (DX) cooling with staged heating and cooling. Staged heating or cooling can be mixed with a modulating valve for heating or cooling.

NOTE: See [Illustration: RTU Operations on page 62](#).

Staged Cooling

As the demand for cooling increases, the controller starts the first stage of cooling when the cooling PID loop rises above 99% and the first stage of cooling has been turned off for at least the time set by the value of Minimum Off Time. See [PID \(Proportional Integral Derivative\) Loops \(RTU/AHU\) on page 66](#).

The second stage of cooling turns on when:

- The cooling loop rises above 99%.
- And the first stage has been turned on for the period set by Stage Delay.
- And the second stage has been turned off for at least as long as the value of Minimum Off Time.

As the demand for cooling is satisfied, the second stage turns off when the cooling PID loop drops below 50%. This first stage turns off when the cooling loop drops below 1%.

Staged Heating

As the demand for heating increases, the controller starts the first stage of heating when the heating PID loop rises above 99%. The second stage of heating is turned on when the heating loop rises above 99% and the first stage has been turned on for period set by the Stage Delay.

As the demand for heating is satisfied, the second stage is turned off when the heating PID loop drops below 50%. This first stage is turned off when the heating loop drops below 1%.

Fan Control (RTU/AHU)

A user with a level 1 password (if a level 1 password is configured) can set the controller controlled fan to either run continuously or to start automatically on a call for cooling or heating.

- **On**—The fan will run continuously regardless of the heat/cool modes or occupied/standby states.
- **Auto**—The fan will run only when there is a call for heating or cooling. It continues to run for the period set by the fan delay timer after the call for heating or cooling.

Economizer Cooling (RTU/AHU) and DCV (RTU)

NOTE: See [Illustration: RTU Operations on page 62](#).

NOTE: During Occupied mode, the optional economizer can be enabled only if both OAT and DAT sensors are connected to the controller. See [OAT \(Outside Air Temperature\) Sensing on page 66](#) and [DAT \(Discharge Air Temperature\) Sensor on page 66](#).

During occupied mode, if the OAT drops below the economizer enable temperature and there is a call for cooling, the economizer mode is enabled. The economizer mode is disabled if the OAT rises 1° above the economizer enable temperature.

Once enabled, the economizer OAD (Outside Air Damper) opens to the larger value of either the minimum damper position limit (Minimum Econ Damper) or the DAT PID loop. The DAT loop modulates from 0 to 100% as the DAT rises above the DAT setpoint. The DAT setpoint resets between the sensed room temperature and the limit for minimum discharge air temperature as the cooling loop varies between 0 and 50%. If the DAT decreases below 55° F, the OAD returns to the minimum damper position.

While economizing, the OAD is open to the greater of the minimum damper position or DAT control. The OAD is shut during unoccupied mode and any time the fan is off.

NOTE: For information about the **CO₂ sensor and DCV (Demand Control Ventilation)** operation in RTU applications, see [STE-93xx/95xx CO2 Sensor and DCV on page 10](#).

VAV (Variable Air Volume)




Illustration: VAV Airflow Operations




Illustration: VAV Reheat Operations




Illustration: VAV Fan Operations

Introduction (VAV)

Topics in this section cover the VAV (and CAV) sequences of operation for the KMC Conquest BAC-9000A series controller-actuators and (with use of an external actuator) the BAC-9311 unitary controller. These are advanced topics for controls technicians and engineers. Considerable differences in sequences and options exist for the various configurations of VAV (e.g., dual duct vs. single duct and type of reheat). See the sections relevant for the desired application.

NOTE: For CAV-specific diagrams, see [CAV \(Constant Air Volume\) on page 45](#).

NOTE: For sequence of operations with charts and wiring diagrams, see also the VAV submittal sheets (see [Submittal Sheets \(Diagrams and Operation\) on page 5](#)).

NOTE: See also [BACnet Objects List on page 80](#) for more information about objects listed in the descriptions.

NOTE: Starting the balancing procedure clears the previously calculated balancing correction factors. See [Balancing Airflow \(VAV\) on page 78](#).

- NOTE:** If Auto Occupancy is enabled (disabled by default) and the measured airflow is 75% or less of the requested airflow for at least five minutes during Occupied mode, the mode will change to Unoccupied. See [Occupancy, Motion Sensing, and Standby \(VAV\) on page 73](#).
- NOTE:** Auxiliary Flow is the airflow setpoint used during reheat operation. If the measured airflow is 25% or less of the Auxiliary Flow setting, reheat is disabled.
- NOTE:** If the supply air is warmer than the changeover setpoint (74° default) plus 2° F, the controller modulates between minimum and maximum heating airflows and reheat is locked out. See [Cooling/Heating Changeover \(VAV\) on page 75](#).
- NOTE:** To properly set up a VAV controller, the correct K factor for the VAV box must be entered into the controller. If this information is unknown, see [Appendix: K Factors for VAV on page 106](#).

Sensors (VAV)

Space Temperature Sensor

The controller uses a connected STE-9000 series NetSensor digital wall sensor or an STE-6010/6014/6017 analog wall sensor. See [Digital STE-9000 Series NetSensors on page 10](#) and [Analog STE-6000 Series Thermistor Sensors on page 12](#).

DAT (Discharge Air Temperature) Sensor

The DAT sensor is an optional Type III, 10K ohm thermistor (e.g., STE-1400 series) and is required for VAV heating applications. If the controller detects that this sensor is connected, the controller uses discharge air temperature to determine when to change between heating and cooling. The DAT sensor input is also used to control reheat. See [Reheat \(VAV\) on page 76](#) and [Cooling/Heating Changeover \(VAV\) on page 75](#).

NOTE: DAT can be monitored as an analog input (AI3).

Airflow Sensors and Pickups

VAV airflow is calculated by measuring the high and low duct pressures with the built-in airflow sensor connected to airflow pickup tubes (e.g., SSS-101x). The high and low pressure measurements along with the K-factor of the VAV terminal unit are used to calculate the airflow through the VAV unit. (See [Appendix: K Factors for VAV on page 106](#).)

Room Temperature Setpoints (VAV)

Types of Setpoints

There are four temperature setpoints each for heating and cooling for a total of eight setpoints.

- Active cooling
- Occupied cooling
- Unoccupied cooling
- Standby cooling
- Active heating
- Occupied heating
- Unoccupied heating
- Standby heating

These setpoints are based on a user-entered value or the occupancy state and standby value described in [Occupancy, Motion Sensing, and Standby \(VAV\) on page 73](#).

Active Setpoint

The active setpoint is the current setpoint being used for control. The active setpoint is determined according to the occupancy state (see [Occupancy, Motion Sensing, and Standby \(VAV\) on page 73](#)):

- When the space becomes **Occupied**, the Occupied Cooling Setpoint (AV5) is placed in the Active Cooling Setpoint (AV3), and the Occupied Heating Setpoint (AV6) is placed in the Active Heating Setpoint (AV4).
- When the space becomes **Unoccupied**, the Unoccupied Cooling Setpoint (AV7) is placed in the Active Cooling Setpoint (AV3), and the Unoccupied Heating Setpoint (AV8) is placed in the Active Heating Setpoint (AV4).
- When the space enters **Standby**, the controller calculates the active setpoint by adding or subtracting (depending on mode) the Standby Offset (AV12) from the relevant occupied (but not unoccupied) setpoint. Standby is only applied to the occupied setpoint and thus is only valid when the schedule is active.

A user with a level 1 password (if a level 1 password is configured) can enter an active setpoint from the KMC Conquest STE-9000 series NetSensor (via AV3 and AV4). The local override is valid only when the schedule is inactive. This change is for a limited time or until the next time the occupancy state changes.

For display and control loop calculations, the active setpoint value is compared to the value of the space temperature variable AV1, which is taken from the physical temperature input AI1.

Occupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is occupied, which is usually controlled by the schedule in the controller.

Unoccupied Setpoint

This temperature setpoint is entered by the controls technician during controller setup and system commissioning. This is the setpoint used when the system is unoccupied, which is usually controlled by the schedule in the controller.

Standby Setpoint

This setpoint is used when the controller is in the standby state. It is calculated from the relevant occupied setpoint value and the Standby Offset value. The Standby Offset value is entered by the controls technician during controller setup and system commissioning. See [Occupancy, Motion Sensing, and Standby \(VAV\) on page 73](#).

Setpoint Limits

Programming in the controller limits the setpoint entry so that a heating setpoint is not set higher than its corresponding cooling setpoint.

If a user adjusts a setpoint so that it falls within the range set by the value of Minimum Setpoint Differential, the corresponding setpoint is changed to maintain the differential. For example, the Minimum Setpoint Differential is 4° F and the Occupied Heating setpoint is 70° F. If the user lowers the Occupied Cooling setpoint to 71° F, the controller recalculates the Occupied Heating setpoint and changes it to 67° F.

Occupancy, Motion Sensing, and Standby (VAV)

Occupancy Options

The controller can operate as a stand-alone controller and can determine occupancy based on its internal occupancy schedule and (if connected to an STE-92x1/95x1 NetSensor) motion in the space. The controller can be in any one of the following occupancy states:

- Occupied
- Unoccupied
- Standby

The controller chooses which setpoint to use based on the occupancy and standby states. See [Room Temperature Setpoints \(VAV\) on page 72](#).

The occupancy and standby states can also be commanded by another BACnet device or an operator workstation connected to the building automation network.

Automatic Occupancy

If Automatic Occupancy is enabled, the controller automatically toggles between Unoccupied, Occupied, and Standby based on the presence of primary airflow and motion in the zone. The default for Automatic Occupancy is Disabled.

Occupied

For controllers without a connected motion sensor, the controller changes to Occupied upon the detection of primary airflow.

Controllers **with** a connected motion sensor change to Occupied upon the detection of primary airflow **and** motion in the space. The unit remains in the Occupied state as long as periodic motion is detected and primary airflow continues. If motion stops, the controller changes to Standby.

If an internal schedule is enabled, the occupancy state is set according to the schedule. See [Scheduling Occupancy \(VAV\) on page 74](#).

Unoccupied

Occupancy mode changes to Unoccupied when the controller detects a loss of primary airflow. While in the Unoccupied state, the controller will fully open the damper in an attempt to reach the maximum airflow setpoint.

Loss of primary airflow is defined as detection of less than 25% of the requested flow for at least 5 minutes. The occupancy mode changes to Occupied or Standby once the actual airflow is at least 30% of the requested flow.

The Occupied state changes to the Unoccupied state if the internal occupancy schedule is enabled and if the schedule for that time is inactive.

Standby

In units with a connected motion sensor, the controller starts in Standby and changes to Occupied after detecting motion in the space. Motion in the space is defined as two movements detected within 5 minutes. The controller will change back to Standby after a lack of motion for the period specified by the variable Standby Timer (AV39).

Standby mode is not available for controllers without a motion sensor, unless commanded by a building management system.

Scheduling Occupancy (VAV)

The schedule in the controller is a standard BACnet schedule object. It can be changed from a configuration tool or a BACnet operator workstation.

The internal occupancy schedule changes the controller between the Occupied (Active) and Unoccupied (Inactive) states. If the controller is connected to an STE-92x1/95x1 NetSensor with a motion sensor, the motion sensor may change the controller between occupied and standby based on motion detected in the space.

See also [Occupancy, Motion Sensing, and Standby \(VAV\) on page 73](#).

PID (Proportional Integral Derivative) Loops (VAV)

A PID control loop calculates an error value from the difference between the measured room temperature and the active setpoint. The error value is expressed as a percentage and is typically used in a controller to control the state of an output. When the difference between the setpoint and room temperature is large, the error is large. As the system reduces the difference between the setpoint and space temperature, the error becomes smaller. In a simple example, if the output of the PID loop that is controlling the damper is 50%, the damper position is half-way open; if the output of the loop is 100%, the damper position is fully open.

The controller uses up to four PID control loops:

- The output of either the **heating** loop or the **cooling** loop is used to control the position of the damper.
- The **discharge air** loop and the DAT input (if present) control the reheat loop.
- The **reheat** loop is used to control the temperature of the discharge air.

The PID control loops in the controller are standard BACnet objects.

Airflow Setpoints Sequence (VAV)

NOTE: See [Illustration: VAV Airflow Operations on page 69](#). See also [Reheat \(VAV\) on page 76](#).

If no room sensor is connected to the controller, the controller uses the Minimum Cooling Airflow setpoint to maintain airflow.

Cool Air Sequence: As the Cooling loop increases from 0% to 100%, the Primary Airflow Setpoint is proportionally calculated between the Minimum Cooling Airflow and the Maximum Cooling Airflow. If there is a call for reheat to maintain room temperature, the primary airflow is set to the value of Auxiliary Flow.

Warm Air Available: In the heating mode, as the Heating Loop increases from 0% to 100%, the Primary Airflow Setpoint is proportionally calculated between the Minimum Heating Airflow and the Maximum Heating Airflow.

Cooling/Heating Changeover (VAV)

The DAT input (AI3) is used by the controller to determine the type of air being supplied by the AHU or RTU. The DAT sensor is required for applications that require automatic changeover between cooling and heating.

The changeover function is disabled while Heating (reheat) is active. Changeover is enabled again 3 minutes after Heating ends. (This is because the same sensor is used for DAT and changeover.)

When Heating is inactive, the DAT input is compared to the SAT Changeover Temperature (AV37). If the DAT is below the SAT Changeover Temperature minus 2°, the SAT Changeover Mode is set to Cooling. If the DAT is above the SAT Changeover Temperature plus 2° F, the SAT Changeover Mode is set to Heating. The default changeover temperature is 74° F.

NOTE: The **SAT (Supply Air Temperature)** is the temperature of the air in the duct supplied by the AHU or RTU and entering into the VAV box before any reheat is applied. The **DAT (Discharge Air Temperature)** is the temperature of the air leaving from the VAV box and entering the room. A DAT sensor can be used to measure SAT since they are equivalent as long as no reheat is active.

NOTE: See also [Reheat \(VAV\) on page 76](#).

Discharge Air Temperature (DAT) Limiting (VAV)

If a DAT sensor is detected and DAT Limiting is enabled, the VAV terminal will be controlled by the DAT loop. When there is a call for heat and the primary air is cool air, the reheat outputs are directly controlled by the DAT Loop and the DAT Setpoint reset based on the output of the Heating loop. As the Heating loop increases from 0% to 50%, the DAT Setpoint is proportionally calculated between the Space Temperature Reference and the Space Temperature Reference +15° F up to a maximum of 90° F. This allows the reheat to be controlled by the DAT loop over the first 50% of a call for heat.

If DAT Limiting is enabled, and a DAT sensor is not connected, the controller will lock out reheat control only in the cooling mode. The unit will operate this way until a DAT sensor is detected or DAT limiting is disabled.

If DAT Limiting is disabled, the unit's reheat is controlled by the Heating loop instead of the DAT loop. **See also Reheat (VAV) on page 76.**

Reheat (VAV)

Types and Control of Reheat

The controllers can control four types of reheat installations:

- Modulating
- Time-proportioned
- Floating
- Staged

NOTE: See **Illustration: VAV Reheat Operations on page 70.**

All reheat is controlled by either the Heating loop or the Discharge Air Temp Limiting (DAT) PID loop. See **PID (Proportional Integral Derivative) Loops (VAV) on page 74.**

- If Discharge Air Temp Limiting is enabled, reheat is controlled by the DAT PID loop.
- If DAT control is not enabled, reheat is controlled by the Heating loop.

In the following descriptions, the PID loop controlling reheat is referred to as the Reheat loop.

Modulating Reheat

If the controller is configured for modulating reheat, it controls an analog reheat unit with 0–10 VDC at the analog reheat output. On a call for reheat, the reheat output is modulated over the span of the Reheat loop. If the Reheat loop is less than 10%, the reheat output remains at zero. The reheat is set to zero if the Cooling loop is active.

Time Proportioned Reheat

For controllers configured for time proportional reheat, the duty cycle of a binary triac output varies over a 10 second period. For example, if the Reheat loop is at 50%, the reheat output is On for 5 seconds and Off for 5 seconds. If the Reheat loop is less than 10%, the reheat output remains at zero.

Floating Reheat

If the controller is configured for floating reheat, it controls two binary triac outputs to drive the inputs of a tri-state actuator connected to a valve. If the Reheat loop is less than 30%, the valve is driven closed. If the loop is greater than 70%, the valve is driven open. If the loop is in between 30% and 70%, no valve action is taken.

Staged Reheat

If the controller is configured for staged reheat, it can control up to three stages of reheat through binary triac outputs. The reheat outputs are commanded On when the Reheat loop rises above the On threshold and Off when the loop drops below the Off threshold. Thresholds and stage activation are shown in the following table.

| HEATING STAGES | OUTPUT STATE | |
|----------------|--------------|---------------|
| | ON THRESHOLD | OFF THRESHOLD |
| Stage 1 | 35% | 15% |
| Stage 2 | 65% | 45% |
| Stage 3 | 95% | 75% |

Illustration: Staged Reheat Thresholds

Damper Operation (VAV)

Damper movement is determined by comparing the actual airflow reading to the airflow setpoints. If the actual airflow is within 5% of the setpoint, no damper action is initiated. Once within the 5% deadband, the actual airflow must be outside a 7% deadband before damper position changes.

Fan Operation (VAV)

The controllers support both series and parallel fan powered VAV units. See [Illustration: VAV Fan Operations on page 70](#). For either type of fan operation, the fan is controlled through the following terminals:

- A binary output triac controls a 24-volt fan starting circuit.
- A 0–10 VDC analog output controls the speed of the fan. The output controls fan speed at either Min Fan Speed or Max Fan Speed. See the topic Set the airflow setpoints on page 34 for the procedure to set the fan speeds.

If the VAV unit is not configured for a fan, the two outputs are not used and remain inactive regardless of the occupancy state.

Series Fan

If the controller is configured for a series fan, any time the Occupancy mode of the controller is set to either Occupied or Standby, the fan runs continuously. The fan speed is set to Maximum Fan Speed when the state is Occupied and set to Minimum Fan Speed when the state is Standby.

When the Occupancy state is Unoccupied, the fan starts and runs at minimum speed only on a call for heating. The fan starts when the Heating loop is greater than 5% and stops when the Heating loop is less than 1%.

Parallel Fan

If the controller is configured for a parallel fan, any time the Occupancy mode of the controller is set to either Occupied or Standby and there is a call for heat, the fan runs continuously. The fan starts when the Heating loop is greater than 5% and stops when the Heating loop is less than 1%.

When the unit Occupancy state is Unoccupied, the fan starts and runs at minimum speed only on a call for heating. The fan starts when the Heating loop is greater than 5% and stops when the Heating loop is less than 1%.

Dual Duct (VAV)

A dual duct installation consists of separate primary heating and cooling ducts, both with control dampers and airflow monitoring. For this type of installation a BAC-9001 controller-actuator controls the cooling air (primary) damper and a TSP-8003 actuator controls the heating air (secondary) damper.

- As the space temperature rises above the cooling setpoint, the primary airflow is modulated from the Cooling Minimum flow to the Cooling Maximum Flow.
- As the space temperature falls below the heating setpoint, the secondary airflow is modulated from the Heating Minimum flow to the Heating Maximum Flow.
- Between the heating and cooling setpoints, both the primary airflow and secondary airflow are modulated to maintain the Dual Duct Minimum airflow.

Balancing Airflow (VAV)

Balancing airflow is the process of calibrating the internal airflow sensor to a known standard. In the field, airflow is measured with an airflow hood or other measuring instrument and then compared to the airflow measurements from the sensor in the controller. The balancing process uses a KMC Conquest STE-9000 series NetSensor as the technician setup tool for initiating the balancing sequence and entering actual flow measurements.

When the balancing sequence starts, all other functions of the controller are locked out.

At the start of the sequence, the controller drives the damper open until the airflow reaches the highest value of either the cooling or heating maximum airflow setpoints. An airflow measurement is made with an airflow hood and the actual airflow value is entered into the controller. Once the actual airflow is entered, the controller drives the damper closed to the lower value of either the cooling or heating minimum airflow. Another measurement is made with the flow hood and that measurement is entered into the controller.

After the minimum airflow measurement is entered, the programming in the controller calculates the airflow correction factors, which are used to adjust the measurements from the internal airflow sensor. Balancing is complete and the controller is returned to normal operation.

NOTE: For the procedure to balance the airflow with a Conquest NetSensor, see [VAV Airflow Balancing with an STE-9xx1 on page 31](#).

System Diagnostics (VAV)

Object Types Monitored

The controller programming includes four system diagnostic indicators in the form of BACnet value objects.

- Need AHU start
- Need for cooler supply air
- Need for warmer supply air
- Need for higher static pressure

These diagnostic indicators or flags are monitored by other BACnet devices connected to the same building automation system as the controller. (See the documentation for the relevant equipment.)

Need AHU Start (BV1)

The Need AHU Start value object is set to Active for any of the following conditions:

- The system mode is Unoccupied and the Cooling loop or the Heating loop reaches 100%.
- The system mode is Occupied.
- The system mode is Standby.

The Need AHU Start object changes to Inactive when both loops drop below 5%.

Need for Cooler Supply Air (BV2)

The Need Cooler Supply value object is set to Active when the damper is fully open and the Cooling loop is greater than 95% for 30 minutes. The indicator changes to Inactive when the Cooling loop falls below 90%.

Need For Warmer Supply Air (BV7)

The Need Warmer Supply value object is set to Active when the damper is fully open and the Heating loop is greater than 95% for 30 minutes. The indicator changes to Inactive when the Heating loop falls below 90%.

Need for Higher Static Pressure (BV3)

The Need Higher Static value object is set to Active when the damper is fully open and airflow cannot reach the required setpoint value.

SYSTEM INTEGRATION AND NETWORKING

Networking

See [MS/TP Network Connections on page 19](#) and [Ethernet Network Connections on page 21](#).

BACnet Objects List

General Notes

NOTE: Objects are dependent on controller model and application. Use KMC Connect, KMC Converge, or TotalControl to check relevant objects in a controller.

NOTE: Objects can be **deleted or created** in KMC Connect, KMC Converge, or TotalControl. If needed objects are “missing,” check the application and create the required objects. See the Help system in the relevant program for more information about creating and deleting objects. As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs**. Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.




Illustration: Creating Objects in KMC Connect

NOTE: AI1 and AI2 are dedicated for use with the analog electronic STE-6010/6014/6017 sensors but not the digital STE-9xx1 NetSensors or any other sensors. Room temperature and setpoints are mapped to value objects. See [Digital STE-9000 Series NetSensors on page 10](#) and [Analog STE-6000 Series Thermistor Sensors on page 12](#).

On the following pages, see:

- [BAC-5900A Series \(General Purpose Controller\) Objects on page 81](#)
- [BAC-9000A Series \(VAV Controller\) Objects on page 82](#)
- [BAC-9300A Series \(Unitary Controller\) Objects on page 91](#)

BAC-5900A Series (General Purpose Controller) Objects



| BAC-5901 GENERAL PURPOSE OBJECTS | | | | |
|----------------------------------|----------------|-------------------------------|-------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| Values | | | | |
| AV1 | SPACE_TEMP | Space Temperature | Degrees F | 0 |
| AV2 | AV_02 | Analog Value #2 | No Units | 0 |
| AV3 | ACT_COOL_STPT | Active Cooling Setpoint | Degrees F | 74 |
| AV4 | ACT_HEAT_STPT | Active Heating Setpoint | Degrees F | 72 |
| AV5 | OCC_CL_STPT | Occupied Cooling Setpoint | Degrees F | 76 |
| AV6 | OCC_HT_STPT | Occupied Heating Setpoint | Degrees F | 72 |
| AV7 | UNOCC_CL_STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC_HT_STPT | Unoccupied Heating Setpoint | Degrees F | 65 |
| AV9 | MIN_CL_STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX_HT_STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN_STPT_DIFF | Minimum Setpoint Differential | Degrees F | 2 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV21 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV38 | OVRD_TIME | Local Override Timer | Minutes | 60 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| BV28 | LOCAL_OVRD | Local Override Mode | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV2 | SYSTEM_MODE | Control Mode | OFF | 2 |
| | | | AUTO | |
| | | | COOL | |
| | | | HEAT | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

BAC-9000A Series (VAV Controller) Objects



| BAC-9001 PRESSURE INDEPENDENT VAV, SINGLE DUCT OBJECTS | | | | |
|--|------------------|----------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| AI3 | DISCHARGE AIR | Discharge Air Temperature | KMC10K_Type_III | |
| AI7 | PRIMARY DUCT | Primary Duct Pressure | NONE | |
| AI8 | PRIMARY POSITION | Primary Damper Position | | |
| Outputs | | | | |
| A03 | ANALOG HEAT | Analog Heat | 0_100% | 0 |
| A04 | FAN SPEED | Fan Speed | 0_100% | 0 |
| B01 | PRI DAMPER CW | Primary Damper Clockwise | Unknown | Inactive |
| B02 | PRI DAMPER CCW | Primary Damper Counter Clockwise | Unknown | Inactive |
| B06 | FAN | Fan | Unknown | Inactive |
| B07 | HT STAGE 1 | Heating Stage 1 | Unknown | Inactive |
| B08 | HT STAGE 2 | Heating Stage 2 | Unknown | Inactive |
| B09 | HT STAGE 3 | Heating Stage3 | Unknown | Inactive |
| Values | | | | |
| AV1 | SPACE TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT COOL STPT | Active Cooling Setpoint | Degrees F | 74 |
| AV4 | ACT HEAT STPT | Active Heating Setpoint | Degrees F | 70 |
| AV5 | OCC CL STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC HT STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC CL STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC HT STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN CL STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX HT STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN STPT DIFF | Minimum Setpoint Differential | Degrees F | 4 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | MIN COOL FLOW | Minimum Cooling Flow | Cubic Feet per Minute | 100 |
| AV14 | MAX COOL FLOW | Maximum Cooling Flow | Cubic Feet per Minute | 400 |
| AV15 | MIN HEAT FLOW | Minimum Heating Flow | Cubic Feet per Minute | 100 |
| AV16 | MAX HEAT FLOW | Maximum Heating Flow | Cubic Feet per Minute | 400 |
| AV17 | AUXILLARY FLOW | Auxillary Flow | Cubic Feet per Minute | 200 |
| AV18 | PRI K FACT | Primary K Factor | No Units | 904 |
| AV19 | PRI CORR SLOPE | Primary Correction Slope | No Units | 1 |
| AV20 | PRI CORR OFFST | Primary Correction Offset | Cubic Feet per Minute | 0 |
| AV21 | PRI LO FLOW CORR | Primary Low Flow Correction | No Units | 1 |
| AV22 | PRI FLOW STPT | Primary Flow Setpoint | Cubic Feet per Minute | 0 |
| AV23 | PRI RAW FLOW | Primary Raw Flow | Cubic Feet per Minute | 0 |
| AV24 | PRI ACTUAL FLOW | Primary Actual Flow | Cubic Feet per Minute | 0 |
| AV25 | AV_25 | Analog Value #25 | No Units | 0 |
| AV32 | MIN FAN SPEED | Minimum Fan Speed | Percent | 25 |
| AV33 | MAX FAN SPEED | Maximum Fan Speed | Percent | 100 |
| AV34 | AV_34 | Analog Value #34 | No Units | 0 |
| AV36 | DAT RESET | Discharge Air Temp Setpoint | Degrees F | 90 |

| BAC-9001A PRESSURE INDEPENDENT VAV, SINGLE DUCT OBJECTS | | | | |
|---|------------------|--------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV37 | SAT CHANGEOVER | SAT Changeover Temperature | Degrees F | 72 |
| AV38 | LOCAL OVRD TIME | Local Override Timer | Minutes | 60 |
| AV39 | STANDBY TIMER | Standby Timer (motion) | Minutes | 15 |
| AV40 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV41 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV43 | MEASURED MAX | Measured Maximum | Cubic Feet per Minute | 0 |
| AV44 | MEASURED MIN | Measured Minimum | Cubic Feet per Minute | 0 |
| AV45 | PRI SAVE MIN FLO | Primary Saved Minimum Airflow | Cubic Feet per Minute | 0 |
| AV46 | AV_46 | Analog Value #46 | No Units | 0 |
| AV47 | DAT MAXIMUM | Maximum DAT Setpoint | Degrees F | 90 |
| AV48 | CCW DMP POS | CCW Damper Position | Volts | 0 |
| AV49 | CW DMP POS | CW Damper Position | Volts | 0.01 |
| AV50 | DAMPER POSITION | Damper Position | Percent | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV54 | MOTOR PAUSE | Delays Motor Close to Setpoint | Seconds | 0 |
| AV55 | CHNG OVER DELAY | Heating Change Over Delay | Minutes | 3 |
| AV56 | LOW AUTO OCC | Low Limit for Auto Occupy | Cubic Feet per Minute | 50 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| BV1 | NEED AHU | Need For AHU | | Inactive |
| BV2 | NEED COLDER SPLY | Need For Colder Air Supply | | Inactive |
| BV3 | NEED MORE STATIC | Need For More Static Pressure | | Inactive |
| BV4 | LOCAL OVRD | Local Override Mode | | Inactive |
| BV5 | MOTION OVRD | Motion Override Mode | | Inactive |
| BV6 | MOTION SENSOR | Motion Sensor (Wall Stat) | | Inactive |
| BV7 | NEED HOTTER SPLY | Need For Hotter Air Supply | | Inactive |
| BV8 | SUPPLY AIR TYPE | Supply Air Type | | Active |
| BV9 | DAT LIMITING | Discharge Air Temp Limiting | | Inactive |
| BV10 | DIR TO CLOSE | Direction to Close | | Inactive |
| BV11 | AUTO OCCUPANCY | Auto Occupancy Detection | | Inactive |
| BV12 | BALANCE MODE | Balance Mode | | Inactive |
| BV13 | DAT SENSOR | DAT Sensor Present | | Inactive |
| BV14 | PRI BAL TRIGGER | Primary Balance Trigger | | Inactive |
| BV15 | BV_15 | Binary Value #15 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9001A PRESSURE INDEPENDENT VAV, SINGLE DUCT OBJECTS | | | | |
|---|----------------|-----------------------|-----------------------|---------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV2 | FAN CONFIG | Fantype Configuration | MOTION OVERRIDE | 1 |
| | | | NONE | |
| | | | SERIES | |
| | | | PARALLEL | |
| MSV3 | REHEAT | Reheat Type | NONE | 1 |
| | | | STAGED | |
| | | | MODULATING | |
| | | | FLOATING | |
| MSV4 | STPT_MODE | User Setpoint Mode | TIME PROP | 1 |
| | | | Heat | |
| | | | Cool | |
| | | | Unocc Heat | |
| MSV8 | OCCUPIED STATE | Occupied State | Unocc Cool | 1 |
| | | | OCCUPIED | |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| MSV10 | WALL SENSOR | Wall Sensor Type | LOCAL OVERRIDE | 1 |
| | | | STE-9001 TEMP | |
| | | | STE-9021 HUMIDITY | |
| | | | STE-9201 MOTION | |
| | | | STE-9221 HUMIDITY/ | |
| | | | MOTION | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 HUMIDITY/CO2 | |
| | | | STE-9501 MOTION/CO2 | |
| | | | STE-9521 HUMIDITY/MO- | |
| | | | TION/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | NONE | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9001A PRESSURE INDEPENDENT VAV, DUAL DUCT OBJECTS | | | | |
|---|------------------|----------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| A11 | SPACE SENSOR | Space Sensor | KMC10K_Type_II | |
| A12 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| A13 | DISCHARGE AIR | Discharge Air Temperature | KMC10K_Type_III | |
| A14 | AI_04 | Analog Input #4 | no sensor | |
| A15 | SECONDARY DUCT | Secondary Duct Pressure | NONE | |
| A16 | SECONDARY POS | Secondary Damper Position | Volts_0_to_5 | |
| A17 | PRIMARY DUCT | Primary Duct Pressure | NONE | |
| A18 | PRIMARY POSITION | Primary Damper Position | Volts_0_to_5 | |
| Outputs | | | | |
| A03 | AO_03 | Analog Output #3 | no sensor | 0 |
| A04 | AO_04 | Analog Output #4 | no sensor | 0 |
| A05 | AO_05 | Analog Output #5 | no sensor | 0 |
| B01 | PRI DAMPER CW | Primary Damper Clockwise | Unknown | Inactive |
| B02 | PRI DAMPER CCW | Primary Damper Counter Clockwise | Unknown | Inactive |
| B06 | BO_06 | Binary Output #6 | no sensor | Inactive |
| B07 | SEC DAMPER CW | Secondary Damper Clockwise | Unknown | Inactive |
| B08 | SEC DAMPER CCW | Secondary Damper CounterCW | Unknown | Inactive |
| B09 | BO_09 | Binary Output #9 | no sensor | Inactive |
| Values | | | | |
| AV1 | SPACE TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT COOL STPT | Active Cooling Setpoint | Degrees F | 68 |
| AV4 | ACT HEAT STPT | Active Heating Setpoint | Degrees F | 64 |
| AV5 | OCC CL STPT | Occupied Cooling Setpoint | Degrees F | 68 |
| AV6 | OCC HT STPT | Occupied Heating Setpoint | Degrees F | 64 |
| AV7 | UNOCC CL STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC HT STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN CL STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX HT STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN STPT DIFF | Minimum Setpoint Differential | Degrees F | 4 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | MIN COOL FLOW | Minimum Cooling Flow | Cubic Feet per Minute | 100 |
| AV14 | MAX COOL FLOW | Maximum Cooling Flow | Cubic Feet per Minute | 400 |
| AV15 | MIN HEAT FLOW | Minimum Heating Flow | Cubic Feet per Minute | 100 |
| AV16 | MAX HEAT FLOW | Maximum Heating Flow | Cubic Feet per Minute | 400 |
| AV17 | DUAL MINIMUM | Dual Minimum | Cubic Feet per Minute | 400 |
| AV18 | PRI K FACT | Primary K Factor | No Units | 904 |
| AV19 | PRI CORR SLOPE | Primary Correction Slope | No Units | 1 |
| AV20 | PRI CORR OFFST | Primary Correction Offset | Cubic Feet per Minute | 0 |
| AV21 | PRI LO FLOW CORR | Primary Low Flow Correction | No Units | 1 |
| AV22 | PRI FLOW STPT | Primary Flow Setpoint | Cubic Feet per Minute | 0 |
| AV23 | PRI RAW FLOW | Primary Raw Flow | Cubic Feet per Minute | 0 |
| AV24 | PRI ACTUAL FLOW | Primary Actual Flow | Cubic Feet per Minute | 0 |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9001A PRESSURE INDEPENDENT VAV, DUAL DUCT OBJECTS | | | | |
|---|---------------------|--------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV25 | SEC K FACT | Secondary K Factor | No Units | 904 |
| AV26 | SEC CORR SLOPE | Secondary Correction Slope | No Units | 1 |
| AV27 | SEC CORR OFFST | Secondary Correction Offset | Cubic Feet per Minute | 0 |
| AV28 | SEC LO FLOW CORR | Secondary Low Flow Correction | No Units | 1 |
| AV29 | SEC FLOW STPT | Secondary Flow Setpoint | Cubic Feet per Minute | 0 |
| AV30 | SEC RAW FLOW | Secondary Raw Flow | Cubic Feet per Minute | 0 |
| AV31 | SEC ACTUAL FLOW | Secondary Actual Flow | Cubic Feet per Minute | 0 |
| AV32 | AV_32 | Analog Value #32 | No Units | 0 |
| AV38 | LOCAL OVRD TIME | Local Override Timer | Minutes | 60 |
| AV39 | STANDBY TIMER | Standby Timer (motion) | Minutes | 15 |
| AV40 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV41 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV42 | AV_42 | Analog Value #42 | No Units | 0 |
| AV43 | MEASURED MAX | Measured Maximum | Cubic Feet per Minute | 0.3 |
| AV44 | MEASURED MIN | Measured Minimum | Cubic Feet per Minute | 0.3 |
| AV45 | PRI SAVE MIN FLO | Primary Saved Minimum Airflow | Cubic Feet per Minute | 0.3 |
| AV46 | SEC SAVE MIN FLO | Secondary Save Min Flow | Cubic Feet per Minute | 0.3 |
| AV47 | AV_47 | Analog Value #47 | No Units | 0 |
| AV48 | CCW DMP POS | CCW Damper Position | Volts | 3 |
| AV49 | CW DMP POS | CW Damper Position | Volts | 2.999725 |
| AV50 | DAMPER POSITION | Damper Position | Percent | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV52 | SEC CCW DMP POS | CCW Damper Position | Volts | 0.5 |
| AV53 | SEC CW DMP POS | CW Damper Position | Volts | 2.9 |
| AV54 | MOTOR PAUSE | Delays Motor Close to Setpoint | Seconds | 0 |
| AV55 | AV_55 | Analog Value #55 | No Units | 0 |
| AV56 | LOW AUTO OCC | Low Limit for Auto Occupy | Cubic Feet per Minute | 50 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| AV58 | AV_58 | Analog Value #58 | No Units | |
| AV60 | SEC DAMPER POSITION | Damper Position | Percent | 0 |
| BV1 | NEED AHU | Need For AHU | | Inactive |
| BV2 | NEED COLDER SPLY | Need For Colder Air Supply | | Inactive |
| BV3 | NEED MORE STATIC | Need For More Static Pressure | | Inactive |
| BV4 | LOCAL OVRD | Local Override Mode | | Inactive |
| BV5 | MOTION OVRD | Motion Override Mode | | Inactive |
| BV6 | MOTION SENSOR | Motion Sensor (Wall Stat) | | Inactive |
| BV7 | NEED HOTTER SPLY | Need For Hotter Air Supply | | Inactive |
| BV8 | SUPPLY AIR TYPE | Supply Air Type | | Active |
| BV9 | NEED SEC STATIC | Need More Secondary Static | | Inactive |
| BV10 | DIR TO CLOSE | Direction to Close | | Inactive |
| BV11 | AUTO OCCUPANCY | Auto Occupancy Detection | | Inactive |
| BV12 | PRI BALANCE MODE | Primary Balance Mode | | Inactive |
| BV13 | SEC BALANCE MODE | Secondary Balance Mode | | Inactive |
| BV14 | PRI BAL TRIGGER | Primary Balance Trigger | | Inactive |
| BV15 | SEC BAL TRIGGER | Secondary Balance Trigger | | Inactive |
| BV16 | BV_16 | Binary Value #16 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9001A PRESSURE INDEPENDENT VAV, DUAL DUCT OBJECTS | | | | |
|---|----------------|------------------------|-----------------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| | | | MOTION OVERRIDE | |
| MSV2 | MSV_02 | Multistate Variable #2 | | |
| MSV3 | MSV_03 | Multistate Variable #3 | | |
| MSV4 | STPT_MODE | User Setpoint Mode | Heat | 1 |
| | | | Cool | |
| | | | Unocc Heat | |
| | | | Unocc Cool | |
| MSV8 | OCCUPIED STATE | Occupied State | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV10 | WALL SENSOR | Wall Sensor Type | STE-9001 TEMP | 1 |
| | | | STE-9021 HUMIDITY | |
| | | | STE-9201 MOTION | |
| | | | STE-9221 HUMIDITY/ MOTION | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 HUMIDITY/CO2 | |
| | | | STE-9501 MOTION/CO2 | |
| | | | STE-9521 HUMIDITY/MO- TION/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | NONE | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9021A PRESSURE DEPENDENT VAV, SINGLE DUCT OBJECTS | | | | |
|---|------------------|----------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| AI3 | DISCHARGE AIR | Discharge Air Temperature | KMC10K_Type_III | |
| AI8 | PRIMARY POSITION | Primary Damper Position | | |
| Outputs | | | | |
| A03 | ANALOG HEAT | Analog Heat | 0_100% | 0 |
| A04 | AO_04 | Analog Output #5 | 0_100% | 0 |
| B01 | PRI DAMPER CW | Primary Damper Clockwise | Unknown | Inactive |
| B02 | PRI DAMPER CCW | Primary Damper Counter Clockwise | Unknown | Inactive |
| B06 | BO_06 | Binary Output #6 | Unknown | Inactive |
| B07 | HT STAGE 1 | Heating Stage 1 | Unknown | Inactive |
| B08 | HT STAGE 2 | Heating Stage 2 | Unknown | Inactive |
| B09 | HT STAGE 3 | Heating Stage3 | Unknown | Inactive |
| Values | | | | |
| AV1 | SPACE TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT COOL STPT | Active Cooling Setpoint | Degrees F | 77 |
| AV4 | ACT HEAT STPT | Active Heating Setpoint | Degrees F | 67 |
| AV5 | OCC CL STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC HT STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC CL STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC HT STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN CL STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX HT STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN STPT DIFF | Minimum Setpoint Differential | Degrees F | 4 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | AV_13 | Analog Value #13 | No Units | 0 |
| AV36 | DAT STPT | Discharge Air Temp Setpoint | Degrees F | 90 |
| AV37 | SAT CHANGEOVER | SAT Changeover Temperature | Degrees F | 72 |
| AV38 | LOCAL OVRD TIME | Local Override Timer | Minutes | 60 |
| AV39 | STANDBY TIMER | Standby Timer (motion) | Minutes | 15 |
| AV40 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV41 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV47 | DAT MAXIMUM | Maximum DAT Setpoint | Degrees F | 90 |
| AV48 | CCW DMP POS | CCW Damper Position | Volts | 0 |
| AV49 | CW DMP POS | CW Damper Position | Volts | 0.01 |
| AV50 | DAMPER POSITION | Damper Position | Percent | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV55 | CHNG_OVER_DELAY | Cooling Change Over Delay | Minutes | 3 |
| AV56 | LOW AUTO OCC | Low Limit for Auto Occupy | Cubic Feet per Minute | 50 |
| AV57 | AV_57 | Analog Value #57 | No Units | 0 |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9021A PRESSURE DEPENDENT VAV, SINGLE DUCT OBJECTS | | | | |
|---|------------------|---------------------------------|-----------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV64 | DAMPER STPT | Damper Setpoint | Percent | 0 |
| AV65 | MIN COOL DMPR | Minimum Cooling Damper Position | Percent | 10 |
| AV66 | MAX COOL DMPR | Maximum Cooling Damper Position | Percent | 100 |
| AV67 | MIN HEAT DMPR | Minimum Heating Damper Position | Percent | 10 |
| AV68 | MAX HEAT DMPR | Maximum Heating Damper Position | Percent | 100 |
| AV69 | AUXILLARY DMPR | Auxiliary Damper Position | Percent | 50 |
| BV1 | NEED AHU | Need For AHU | | Inactive |
| BV2 | NEED COLDER SPLY | Need For Colder Air Supply | | Inactive |
| BV3 | NEED MORE STATIC | Need For More Static Pressure | | Inactive |
| BV4 | LOCAL OVRD | Local Override Mode | | Inactive |
| BV5 | MOTION OVRD | Motion Override Mode | | Inactive |
| BV6 | MOTION SENSOR | Motion Sensor (Wall Stat) | | Inactive |
| BV7 | NEED HOTTER SPLY | Need For Hotter Air Supply | | Inactive |
| BV8 | SUPPLY AIR TYPE | Supply Air Type | | Active |
| BV9 | DAT LIMITING | Discharge Air Temp Limiting | | Inactive |
| BV10 | DIR TO CLOSE | Direction to Close | | Inactive |
| BV11 | BV_11 | Binary Value #11 | | Inactive |
| BV12 | CALIBRATE DMPR | Start Damper Calibration | | Inactive |
| BV13 | DAT SENSOR | DAT Sensor Present | | Inactive |
| BV14 | BV_14 | Binary Value #14 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| | | | MOTION OVERRIDE | |
| MSV2 | MSV_02 | Multistate Variable #2 | | |
| MSV3 | REHEAT | Reheat Type | NONE | 1 |
| | | | STAGED | |
| | | | MODULATING | |
| | | | FLOATING | |
| | | | TIME PROP | |

| BAC-9021A PRESSURE DEPENDENT VAV, SINGLE DUCT OBJECTS | | | | |
|---|----------------|--------------------|-----------------------------------|---------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| MSV4 | STPT_MODE | User Setpoint Mode | Heat | 1 |
| | | | Cool | |
| | | | Unocc Heat | |
| | | | Unocc Cool | |
| MSV8 | OCCUPIED STATE | Occupied State | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV10 | WALL SENSOR | Wall Sensor Type | STE-9001 TEMP | 1 |
| | | | STE-9021 HUMIDITY | |
| | | | STE-9201 MOTION | |
| | | | STE-9221 HUMIDITY/ MOTION | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 HUMIDITY/CO2 | |
| | | | STE-9501 MOTION/CO2 | |
| | | | STE-9521 HUMIDITY/MO- TION/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | NONE | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

BAC-9300A Series (Unitary Controller) Objects



| BAC-9301A 2-PIPE FCU OBJECTS | | | | |
|------------------------------|------------------|-------------------------------|--------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F (10K) | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| AI3 | DISCHARGE AIR | Discharge Air Temperature | KMC Type III Deg F (10K) | |
| AI4 | OUTDOOR AIR | Outdoor Air Temp | KMC10K_Type_III | |
| AI5 | HUMIDITY | Space Humidity | Humidity (0-100 % 0-5 v) | |
| AI6 | WATER_TEMP | Supply Water Temperature | KMC Type III Deg F (10K) | |
| AI8 | AI_08 | Analog Input #8 | no sensor | |
| BI7 | FAN_ST | Fan | NONE | |
| Outputs | | | | |
| A07 | ANALOG VALVE | Analog Valve Output | 0-100% (0-10 V) | 0 |
| A08 | ANALOG AUX HEAT | Auxiliary Heat | 0-100% (0-10V) | 0 |
| A09 | AO_09 | Analog Output #9 | NONE | 0 |
| A010 | ANALOG_FAN | Fan Speed Control | 0-100% (0-10V) | 0 |
| BO1 | LOW | Fan Low Speed | Unknown | Inactive |
| BO2 | MEDIUM | Fan Medium Speed | Unknown | Inactive |
| BO3 | HIGH | Fan High Speed | Unknown | Inactive |
| BO4 | DIGITAL VALVE | Digital Valve | Unknown | Inactive |
| BO5 | DIGITAL AUX HEAT | Auxiliary Heat | Unknown | Inactive |
| BO6 | BO_06 | Binary Output #6 | Unknown | Inactive |
| Values | | | | |
| AV1 | SPACE_TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT_COOL_STPT | Active Cooling Setpoint | Degrees F | 80 |
| AV4 | ACT_HEAT_STPT | Active Heating Setpoint | Degrees F | 64 |
| AV5 | OCC_CL_STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC_HT_STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC_CL_STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC_HT_STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN_CL_STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX_HT_STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN_STPT_DIFF | Minimum Setpoint Differential | Degrees F | 2 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | AV_13 | Analog Value #13 | No Units | 0 |
| AV19 | WATER_TEMP | Water Temperature | Degrees F | 0 |
| AV20 | DISCHARGE_TEMP | Discharge Air Temp | Degrees F | 0 |
| AV21 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV22 | AV_22 | Analog Value #22 | No Units | 0 |
| AV25 | FAN_OFF_DELAY | Fan Off Delay | Minutes | 2 |
| AV26 | AV_26 | Analog Value #26 | No Units | 0 |
| AV28 | STANDBY_TIMER | Inactivity Timer | Minutes | 20 |
| AV29 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV30 | AV_30 | Analog Value #30 | No Units | 0 |

| BAC-9301A 2-PIPE FCU OBJECTS | | | | |
|------------------------------|----------------|----------------------------------|-------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV34 | FAN_SPEED | Fan Speed | Percent | 0 |
| AV35 | FAN_MAXIMUM | Fan Maximum Speed | Percent | 100 |
| AV36 | FAN_MINIMUM | Fan Minimum Speed | Percent | 35 |
| AV37 | AV_37 | Analog Value #37 | No Units | 0 |
| AV38 | OVRD_TIME | Local Override Timer | Minutes | 60 |
| AV39 | AV_39 | Analog Value #39 | No Units | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV52 | COOL_PROP | Cooling Proportional Band | Degrees F | 2 |
| AV53 | HEAT_PROP | Heating Proportional Band | Degrees F | 2 |
| AV54 | COOL_INTG | Cool Integral | Per Hour | 0 |
| AV55 | HEAT_INTG | Heat Integral | Per Hour | 0 |
| AV56 | START_H2O_EVAL | Offset Temp to Start H2O Evaluat | Degrees F | 10 |
| AV57 | ROOM_CO2 | Room CO2 Level | Parts per Million | 0 |
| BV1 | BV_1 | Binary Value #1 | | Inactive |
| BV2 | BV_2 | Binary Value #2 | | Inactive |
| BV3 | BV_3 | Binary Value #3 | | Inactive |
| BV4 | COND_OVERFLOW | Condensate Overflow | | Inactive |
| BV5 | OCC_SCHEDULE | Occupy Schedule | | Inactive |
| BV6 | MOTION | Motion Detected | | Active |
| BV7 | DAT_SENSOR | DAT Sensor Present | | Inactive |
| BV8 | MODE | Heat or Cool Mode | | Active |
| BV9 | FAN_NEED | Call for Fan | | Inactive |
| BV10 | COOL_HEAT_NEED | Cooling or Heating Needed? | | Active |
| BV11 | SPEED_UP | Speed Up Timers X 15 | | Inactive |
| BV12 | BV_12 | Binary Value #12 | | Inactive |
| BV13 | OCCUPIED_FAN | Fan On During Occupied Mode | | Inactive |
| BV14 | FAN_STATUS | Fan Proof | | Inactive |
| BV15 | BV_15 | Binary Value #15 | | Inactive |
| BV19 | VLV_ACTION | Normal Close/Normal Open | | Inactive |
| BV20 | COOL_STG_1 | Cooling Stage 1 | | Inactive |
| BV21 | BV_21 | Binary Value #21 | | Inactive |
| BV22 | HEAT_STG_1 | Heating Stage 1 | | Inactive |
| BV23 | BV_23 | Binary Value #23 | | Inactive |
| BV28 | LOCAL_OVRD | Local Override Mode | | Inactive |
| BV29 | BV_29 | Binary Value #29 | | Inactive |
| BV33 | STANDBY_ENABLE | Enable Standby Mode | | Active |
| BV34 | AUXILIARY HEAT | Auxiliary Heat | | Inactive |
| BV35 | WATER_EVAL | Water Evaluation Mode | | Inactive |
| BV36 | STPT_HOLD | Hold Temperature Setpoint | | Inactive |
| BV37 | BV_37 | Binary Value #37 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |

| BAC-9301A 2-PIPE FCU OBJECTS | | | | |
|------------------------------|------------------|--------------------------------|------------------------------|---------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| MSV2 | SYSTEM_MODE | Control Mode | OFF | 2 |
| | | | AUTO | |
| | | | COOL | |
| | | | HEAT | |
| MSV3 | FAN_MODE | Fan Auto-Manual Mode | AUTO | 1 |
| | | | LOW | |
| | | | MED | |
| | | | HIGH | |
| MSV4 | AVAILABLE_SPEEDS | Number of Fan Speeds Available | SINGLE SPEED | 1 |
| | | | TWO SPEED | |
| | | | THREE SPEED | |
| MSV9 | WATER_TYPE | Water Supplied to FCU | CHILLED WATER | 1 |
| | | | HOT WATER | |
| | | | UNCONDITIONED | |
| MSV8 | OCCUPIED STATE | Occupied State | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV10 | WALL SENSOR | Wall Sensor Type | STE-9001 Temp | 1 |
| | | | STE-9021 Humidity | |
| | | | STE-9201 Motion | |
| | | | STE-9221 Humidity/Motion | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 Humidity/CO2 | |
| | | | STE-9501 Motion/CO2 | |
| | | | STE-9521 Humidity/Motion/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | None | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9301A 4-PIPE FCU OBJECTS | | | | |
|------------------------------|-----------------|-------------------------------|--------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F (10K) | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| AI3 | DISCHARGE AIR | Discharge Air Temperature | KMC Type III Deg F (10K) | |
| AI4 | OUTDOOR AIR | Outdoor Air Temp | KMC10K_Type_III | |
| AI5 | HUMIDITY | Space Humidity | Humidity (0-100 % 0-5 v) | |
| AI7 | AI_07 | Analog Input #7 | NONE | |
| AI8 | AI_08 | Analog Input #8 | NONE | |
| BI6 | FAN | Fan | NONE | |
| Outputs | | | | |
| A07 | ANALOG_COOLING | Analog Cooling Output | 0-100% (0-10 V) | 0 |
| A08 | ANALOG_HEATING | Analog Heating Output | 0-100% (0-10 V) | 0 |
| A09 | AO_09 | Analog Output #9 | NONE | 0 |
| A010 | ANALOG_FAN | Fan Speed Control | 0-100% (0-10V) | 0 |
| B01 | LOW | Fan Low Speed | Unknown | Inactive |
| B02 | MEDIUM | Fan Medium Speed | Unknown | Inactive |
| B03 | HIGH | Fan High Speed | Unknown | Inactive |
| B04 | DIGITAL_COOLING | Cooling Valve | Unknown | Inactive |
| B05 | DIGITAL_HEATING | Heating Valve | Unknown | Inactive |
| B06 | BO_06 | Binary Output #6 | Unknown | Inactive |
| Values | | | | |
| AV1 | SPACE_TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT_COOL_STPT | Active Cooling Setpoint | Degrees F | 80 |
| AV4 | ACT_HEAT_STPT | Active Heating Setpoint | Degrees F | 64 |
| AV5 | OCC_CL_STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC_HT_STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC_CL_STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC_HT_STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN_CL_STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX_HT_STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN_STPT_DIFF | Minimum Setpoint Differential | Degrees F | 2 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | AV_13 | Analog Value #13 | No Units | 0 |
| AV19 | OUTDOOR_TEMP | Outdoor Temperature | Degrees F | 0 |
| AV20 | DISCHARGE_TEMP | Discharge Air Temp | Degrees F | 0 |
| AV21 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV22 | DEHUM_STPT | Dehumidification Setpoint | Percent | 60 |
| AV23 | AV_23 | Analog Value #23 | No Units | 0 |
| AV24 | DEHUM_DIFF | Dehumidification Differential | Percent | 5 |
| AV25 | FAN_OFF_DELAY | Fan Off Delay | Minutes | 2 |
| AV26 | AV_26 | Analog Value #26 | No Units | 0 |
| AV28 | STANDBY_TIMER | Inactivity Timer | Minutes | 20 |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9301A 4-PIPE FCU OBJECTS | | | | |
|------------------------------|------------------|-----------------------------|-------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV29 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV30 | AV_30 | Analog Value #30 | No Units | 0 |
| AV34 | FAN_SPEED | Fan Speed | Percent | 0 |
| AV35 | FAN_MAXIMUM | Fan Maximum Speed | Percent | 100 |
| AV36 | FAN_MINIMUM | Fan Minimum Speed | Percent | 35 |
| AV37 | AV_37 | Analog Value #37 | No Units | 0 |
| AV38 | OVRD_TIME | Local Override Timer | Minutes | 60 |
| AV39 | AV_39 | Analog Value #39 | No Units | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV52 | COOL PROP | Cooling Proportional Band | Degrees F | 2 |
| AV53 | HEAT PROP | Heating Proportional Band | Degrees F | 2 |
| AV54 | COOL INTG | Cool Integral | Per Hour | 0 |
| AV55 | HEAT INTG | Heat Integral | Per Hour | 0 |
| AV56 | AV_56 | Analog Value #56 | No Units | 0 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| BV1 | BV_1 | Binary Value #1 | | Inactive |
| BV2 | BV_2 | Binary Value #2 | | Inactive |
| BV3 | BV_3 | Binary Value #3 | | Inactive |
| BV4 | COND_OVERFLOW | Condensate Overflow | | Inactive |
| BV5 | OCC_SCHEDULE | Occupy Schedule | | Inactive |
| BV6 | MOTION | Motion Detected | | Active |
| BV7 | DAT_SENSOR | DAT Sensor Present | | Inactive |
| BV8 | MODE | Heat or Cool Mode | | Active |
| BV9 | FAN_NEED | Call for Fan | | Inactive |
| BV10 | COOL_HEAT_NEED | Cooling or Heating Needed? | | Active |
| BV11 | SPEED_UP | Speed Up Timers X 15 | | Inactive |
| BV12 | BV_12 | Binary Value #12 | | Inactive |
| BV13 | OCCUPIED_FAN | Fan On During Occupied Mode | | Inactive |
| BV14 | FAN_STATUS | Fan Proof | | Inactive |
| BV15 | BV_15 | Binary Value #15 | | Inactive |
| BV18 | CL_VLV_ACTION | Normal Close/Normal Open | | Inactive |
| BV19 | HT_VLV_ACTION | Normal Close/Normal Open | | Inactive |
| BV20 | COOL_STG_1 | Cooling Stage 1 | | Inactive |
| BV21 | BV_21 | Binary Value #21 | | Inactive |
| BV22 | HEAT_STG_1 | Heating Stage 1 | | Inactive |
| BV23 | BV_23 | Binary Value #23 | | Inactive |
| BV27 | OAT_SENSOR | Outdoor Sensor Present? | | Inactive |
| BV28 | LOCAL_OVRD | Local Override Mode | | Inactive |
| BV29 | BV_29 | Binary Value #29 | | Inactive |
| BV31 | DEHUM_ENABLE | Enable Dehumidification | | Inactive |
| BV32 | DEHUM_MODE | Dehumidification Mode | | Inactive |
| BV33 | STANDBY_ENABLE | Enable Standby Mode | | Active |
| BV34 | BV_34 | Binary Value #34 | | Inactive |
| BV36 | STPT_HOLD | Hold Temperature Setpoint | | Inactive |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9301A 4-PIPE FCU OBJECTS | | | | |
|------------------------------|------------------|--------------------------------|------------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| BV37 | BV_37 | Binary Value #37 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| MSV2 | SYSTEM_MODE | Control Mode | OFF | 2 |
| | | | AUTO | |
| | | | COOL | |
| | | | HEAT | |
| MSV3 | FAN_MODE | Fan Auto-Manual Mode | AUTO | 1 |
| | | | LOW | |
| | | | MED | |
| | | | HIGH | |
| MSV4 | AVAILABLE_SPEEDS | Number of Fan Speeds Available | SINGLE SPEED | 1 |
| | | | TWO SPEED | |
| | | | THREE SPEED | |
| MSV8 | OCCUPIED STATE | Occupied State | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV10 | WALL SENSOR | Wall Sensor Type | STE-9001 Temp | 1 |
| | | | STE-9021 Humidity | |
| | | | STE-9201 Motion | |
| | | | STE-9221 Humidity/Motion | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 Humidity/CO2 | |
| | | | STE-9501 Motion/CO2 | |
| | | | STE-9521 Humidity/Motion/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | None | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-93X1A RTU OBJECTS | | | | |
|-----------------------|------------------|----------------------------------|--------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F (10K) | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| AI3 | DISCHARGE AIR | Discharge Air Temperature | KMC Type III Deg F (10K) | |
| AI4 | OUTDOOR AIR | Outdoor Air Temp | KMC10K_Type_III | |
| AI5 | HUMIDITY | Space Humidity | Humidity (0-100 % 0-5 v) | |
| AI6 | AI_06 | Analog Input #6 | NONE | |
| AI7 | AI_07 | Analog Input #7 | NONE | |
| AI8 | AI_08 | Analog Input #8 | NONE | |
| AI9* | DUCT | Duct Pressure | NONE | |
| Outputs | | | | |
| A07 | COOLING_OUTPUT | Analog Cooling Output | 0-100% (0-10 V) | 0 |
| A08 | HEATING_OUTPUT | Analog Heating Output | 0-100% (0-10 V) | 0 |
| A09 | ECON_DAMPER | Economizer Output | 0-100% (0-10 V) | 0 |
| A010 | FAN_SPEED | Analog Output #10 | PSI (0-100 % 0-10 V) | Inactive |
| B01 | FAN | Fan Start - Stop | Unknown | Inactive |
| B02 | CL STAGE 1 | Cool Stage 1 | Unknown | Inactive |
| B03 | CL STAGE 2 | Cool Stage 2 | Unknown | Inactive |
| B04 | BO_04 | Binary Output #04 | Unknown | Inactive |
| B05 | HT STAGE 1 | Heating Stage 1 | Unknown | Inactive |
| B06 | HT STAGE 2 | Heating Stage 2 | Unknown | Inactive |
| Values | | | | |
| AV1 | SPACE_TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT_COOL_STPT | Active Cooling Setpoint | Degrees F | 74 |
| AV4 | ACT_HEAT_STPT | Active Heating Setpoint | Degrees F | 70 |
| AV5 | OCC_CL_STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC_HT_STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC_CL_STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC_HT_STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN_CL_STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX_HT_STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN_STPT_DIFF | Minimum Setpoint Differential | Degrees F | 2 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | DAT RESET | Discharge Air Temperature Setpoi | Degrees F | 0 |
| AV14 | MIN DAT | Min Dishcharge Air Temp | Degrees F | 55 |
| AV15 | MIN_ECON_DAMPER | Minimum Econ Damper | Percent | 10 |
| AV16 | ECON_ENABLE_TEMP | Econimizer Enable Temperature | Degrees F | 60 |
| AV17 | AV_17 | Analog Value #17 | No Units | 0 |
| AV19 | OUTDOOR_TEMP | Outdoor Air Temperature | Degrees F | 0 |
| AV20 | DISCHARGE_TEMP | Discharge Air Temp | Degrees F | 0 |
| AV21 | REL_HUMIDITY | Relative Humidity | Percent | 0 |
| AV22 | DEHUM_STPT | Dehumidification Setpoint | Percent | 60 |
| AV23 | AV_23 | Analog Value #23 | No Units | 0 |
| AV24 | DEHUM_DIFF | Dehumidification Differential | Percent | 5 |
| AV25 | FAN_OFF_DELAY | Fan Off Delay | Minutes | 2 |
| AV26 | MIN_OFF_TIME | Equipment Delay | Minutes | 5 |
| AV27 | STAGE_DELAY | Stage Delay | Minutes | 10 |
| AV28 | STANDBY_TIMER | Inactivity Timer | Minutes | 20 |
| AV29 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV30 | AV_30 | Analog Value #30 | No Units | 0 |
| AV33 | AV_33 | Analog Value #33 | No Units | 0 |
| AV34 | AV_34 | Analog Value #34 | No Units | 0 |
| AV35 | FAN_MAXIMUM | Fan Maximum Speed | Percent | 90 |
| AV36 | FAN_MINIMUM | Fan Minimum Speed | Percent | 30 |
| AV37 | AV_37 | Analog Value #37 | No Units | 0 |

| BAC-93X1A RTU OBJECTS | | | | |
|-----------------------|-----------------|--------------------------------|-------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV38 | OVRD_TIME | Local Override Timer | Minutes | 60 |
| AV39 | AV_39 | Analog Value #39 | No Units | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV52 | COOL PROP | Cooling Proportional Band | Degrees F | 2 |
| AV53 | HEAT PROP | Heating Proportional Band | Degrees F | 2 |
| AV54 | COOL INTG | Cool Intergral | Per Hour | 0 |
| AV55 | HEAT INTG | Heat Intergral | Per Hour | 0 |
| AV56 | AV_56 | Analog Value #56 | No Units | 0 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| AV58 | CO2_RANGE | CO2 Range (above setpoint) | Parts per Million | 200 |
| AV59 | CO2_SETPOINT | CO2 Setpoint | Parts per Million | 800 |
| BV1 | BV_1 | Binary Value #1 | | Inactive |
| BV2 | BV_2 | Binary Value #2 | | Inactive |
| BV3 | BV_3 | Binary Value #3 | | Inactive |
| BV4 | BV_4 | Binary Value #4 | | Inactive |
| BV5 | OCC_SCHEDULE | Occupy Schedule | | Inactive |
| BV6 | MOTION | Motion Detected | | Active |
| BV7 | DAT_SENSOR | DAT Sensor Present | | Inactive |
| BV8 | MODE | Heat or Cool Mode | | Active |
| BV9 | FAN_NEED | Call for Fan | | Inactive |
| BV10 | COOL_HEAT_NEED | Cooling or Heating Needed? | | Active |
| BV11 | SPEED_UP | Speed Up Timers X 15 | | Inactive |
| BV12 | HEATING_FAN | Fan Active In Heat | | Active |
| BV13 | OCCUPIED_FAN | Fan On During Occupied Mode | | Inactive |
| BV14 | FAN_STATUS | Fan Proof | | Inactive |
| BV15 | BV_15 | Binary Value#15 | | Inactive |
| BV16 | ECON_ENABLE | Econimizer | | Inactive |
| BV17 | ECON_MODE | Start Stop Econimizer | | Inactive |
| BV18 | CL_VLV_ACTION | Normal Close/Normal Open | | Inactive |
| BV19 | HT_VLV_ACTION | Normal Close/Normal Open | | Inactive |
| BV20 | COOL_STG_1 | Cooling Stage 1 | | Inactive |
| BV21 | COOL_STG_2 | Cooling Stage 2 | | Inactive |
| BV22 | HEAT_STG_1 | Heating Stage 1 | | Inactive |
| BV23 | HEAT_STG_2 | Heating Stage 2 | | Inactive |
| BV24 | BV_24 | Binary Value #24 | | Inactive |
| BV27 | OAT_SENSOR | Outdoor Sensor Present? | | Inactive |
| BV28 | LOCAL_OVRD | Local Override Mode | | Inactive |
| BV29 | CO2 VENT ENABLE | Enable/Disable CO2 Ventilation | | Inactive |
| BV31 | DEHUM_ENABLE | Enable Dehumidification | | Inactive |
| BV32 | DEHUM_MODE | Dehumidification Mode | | Inactive |
| BV33 | STANDBY_ENABLE | Enable Standby Mode | | Active |
| BV34 | BV_34 | Binary Value #34 | | Inactive |
| BV36 | STPT_HOLD | Hold Temperature Setpoint | | Inactive |
| BV37 | BV_37 | Binary Value #37 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |

| BAC-93X1A RTU OBJECTS | | | | |
|-----------------------|----------------|----------------------|------------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| MSV2 | SYSTEM_MODE | Control Mode | OFF | 2 |
| | | | AUTO | |
| | | | COOL | |
| | | | HEAT | |
| MSV3 | FAN_MODE | Fan Auto-Manual Mode | AUTO | 1 |
| | | | ON | |
| MSV8 | OCCUPIED STATE | Occupied State | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV10 | WALL SENSOR | Wall Sensor Type | STE-9001 Temp | 1 |
| | | | STE-9021 Humidity | |
| | | | STE-9201 Motion | |
| | | | STE-9221 Humidity/Motion | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 Humidity/CO2 | |
| | | | STE-9501 Motion/CO2 | |
| | | | STE-9521 Humidity/Motion/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | None | |

***NOTE:** **A19** is for the **optional** air pressure sensor (in the BAC-9311). All models of the BAC-9300 series have **8 standard** inputs—2 analog for the temp. sensor port and 6 universal inputs (software configurable as analog, binary, or accumulator on terminals).

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs**. Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-93X1A HPU OBJECTS | | | | |
|-----------------------|------------------|--------------------------------|--------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| AI1 | SPACE SENSOR | Space Sensor | KMC Type II Deg F (10K) | |
| AI2 | SPACE SETPOINT | Space Setpoint | TABLE_4 | |
| AI3 | DISCHARGE AIR | Discharge Air Temperature | KMC Type III Deg F (10K) | |
| AI4 | OUTDOOR AIR | Outdoor Air Temp | KMC10K_Type_III | |
| AI5 | HUMIDITY | Space Humidity | Humidity (0-100 % 0-5 v) | |
| AI7 | AI_07 | Analog Input #7 | NONE | |
| AI8 | AI_08 | Analog Input #8 | NONE | |
| AI9* | DUCT | Duct Pressure | NONE | |
| BI6 | FAN_ST | Fan | NONE | |
| Outputs | | | | |
| A07 | AO_07 | Analog Output #7 | no sensor | 0 |
| A08 | AO_08 | Analog Output #8 | no sensor | 0 |
| A09 | ECON_DAMPER | Economizer Output | 0-100% (0-10 V) | 0 |
| A010 | AO_10 | Analog Output #10 | no sensor | 0 |
| B01 | FAN | Fan Start - Stop | Unknown | Inactive |
| B02 | COMPRESSOR_1 | Stage 1 Compressor | Unknown | Inactive |
| B03 | COMPRESSOR_2 | Stage 2 Compressor | Unknown | Inactive |
| B04 | REVERSING_VALVE | Reversing Valve | Unknown | Inactive |
| B05 | AUXILIARY_HEAT | Auxiliary Heat | Unknown | Inactive |
| B06 | BO_06 | Binary Output #6 | no sensor | Inactive |
| Values | | | | |
| AV1 | SPACE_TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT_COOL_STPT | Active Cooling Setpoint | Degrees F | 80 |
| AV4 | ACT_HEAT_STPT | Active Heating Setpoint | Degrees F | 64 |
| AV5 | OCC_CL_STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC_HT_STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC_CL_STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC_HT_STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN_CL_STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX_HT_STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN_STPT_DIFF | Minimum Setpoint Differential | Degrees F | 2 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | DAT_RESET | Discharge Air Reset STPT | Degrees F | 0 |
| AV14 | MIN DAT | Min Discharge Air Temp | Degrees F | 55 |
| AV15 | MIN_ECON_DAMPER | Minimum Econ Damper | Percent | 10 |
| AV16 | ECON_ENABLE_TEMP | Economizer Enable Temperature | Degrees F | 60 |
| AV17 | CMP_LOCKOUT | Compressor Lockout Temperature | Degrees F | 25 |
| AV18 | AUX_HT_LOCKOUT | OAT AUX Heat Lockout | Degrees F | 60 |
| AV19 | OUTDOOR_TEMP | Outdoor Air Temperature | Degrees F | 0 |
| AV20 | DISCHARGE_TEMP | Discharge Air Temp | Degrees F | 0 |
| AV21 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV22 | DEHUM_STPT | Dehumidification Setpoint | Percent | 60 |
| AV23 | AV_23 | Analog Value #23 | No Units | 5 |
| AV24 | DEHUM_DIFF | Dehumidification Differential | Percent | 5 |
| AV25 | FAN_OFF_DELAY | Fan Off Delay | Minutes | 2 |
| AV26 | MIN_OFF_TIME | Equipment Delay | Minutes | 5 |
| AV27 | STAGE_DELAY | Stage Delay | Minutes | 10 |
| AV28 | STANDBY_TIMER | Inactivity Timer | Minutes | 20 |
| AV29 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-93X1A HPU OBJECTS | | | | |
|-----------------------|------------------|--------------------------------|-------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV30 | AV_30 | Analog Value #30 | No Units | 0 |
| AV38 | OVRD_TIME | Local Override Timer | Minutes | 60 |
| AV39 | AV_39 | Analog Value #39 | No Units | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV52 | COOL PROP | Cooling Proportional Band | Degrees F | 2 |
| AV53 | HEAT PROP | Heating Proportional Band | Degrees F | 2 |
| AV54 | COOL INTG | Cool Intergral | Per Hour | 0 |
| AV55 | HEAT INTG | Heat Intergral | Per Hour | 0 |
| AV56 | AV_56 | Analog Value #56 | No Units | 0 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| AV58 | CO2_RANGE | CO2 Range (above setpoint) | Parts per Million | 200 |
| AV59 | CO2_SETPOINT | CO2 Setpoint | Parts per Million | 800 |
| BV1 | BV_1 | Binary Value #1 | | Inactive |
| BV2 | BV_2 | Binary Value #2 | | Inactive |
| BV3 | BV_3 | Binary Value #3 | | Inactive |
| BV4 | BV_4 | Binary Value #4 | | Inactive |
| BV5 | OCC_SCHEDULE | Occupy Schedule | | Inactive |
| BV6 | MOTION | Motion Detected | | Active |
| BV7 | DAT_SENSOR | DAT Sensor Present | | Inactive |
| BV8 | MODE | Heat or Cool Mode | | Active |
| BV9 | FAN_NEED | Call for Fan | | Inactive |
| BV10 | COOL_HEAT_NEED | Cooling or Heating Needed? | | Active |
| BV11 | SPEED_UP | Speed Up Timers X 15 | | Inactive |
| BV12 | BV_12 | Binary Value #12 | | Inactive |
| BV13 | OCCUPIED_FAN | Fan On During Occupied Mode | | Inactive |
| BV14 | FAN_STATUS | Fan Proof | | Inactive |
| BV15 | REV_VLV_POLARITY | Reversing Valve Action | | Inactive |
| BV16 | ECON_ENABLE | Economizer | | Inactive |
| BV17 | ECON_MODE | Start Stop Economizer | | Inactive |
| BV18 | BV_18 | Binary Value #18 | | Inactive |
| BV20 | COOL_STG_1 | Cooling Stage 1 | | Inactive |
| BV21 | COOL_STG_2 | Cooling Stage 2 | | Inactive |
| BV22 | HEAT_STG_1 | Heating Stage 1 | | Inactive |
| BV23 | HEAT_STG_2 | Heating Stage 2 | | Inactive |
| BV24 | AUX_HEAT_STG | Auxiliary Heat Stage | | Inactive |
| BV25 | AUX_LOCKOUT | Aux Heat Lockout | | Inactive |
| BV26 | COMP_LOCKOUT | Compressor Lockout | | Inactive |
| BV27 | OAT_SENSOR | Outdoor Sensor Present? | | Inactive |
| BV28 | LOCAL_OVRD | Local Override Mode | | Inactive |
| BV29 | CO2 VENT ENABLE | Enable/Disable CO2 Ventilation | | Inactive |
| BV31 | DEHUM_ENABLE | Enable Dehumidification | | Inactive |
| BV32 | DEHUM_MODE | Dehumidification Mode | | Inactive |
| BV33 | STANDBY_ENABLE | Enable Standby Mode | | Active |
| BV34 | BV_34 | Binary Value #34 | | Inactive |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

***NOTE:** **AI9** is for the **optional** air pressure sensor (in the BAC-9311A(C)(E)). All models of the BAC-9300A series have **8 standard** inputs—2 analog for the temp. sensor port and 6 universal inputs (software configurable as analog, binary, or accumulator on terminals).

| BAC-93X1A HPU OBJECTS | | | | |
|-----------------------|------------------|---------------------------|------------------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| BV36 | STPT_HOLD | Hold Temperature Setpoint | | Inactive |
| BV37 | ENBL_CMP_LOCKOUT | Enable Compressor Lockout | | Active |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| MSV2 | SYSTEM_MODE | Control Mode | OFF | 2 |
| | | | AUTO | |
| | | | COOL | |
| | | | HEAT | |
| | | | EMERGENCY_HEAT | |
| MSV3 | FAN_MODE | Fan Auto-Manual Mode | AUTO | 1 |
| | | | ON | |
| MSV5 | AUX_HEAT | Auxiliary Heat | None | 1 |
| | | | 3rd Stage | |
| | | | Comp Lockout | |
| MSV8 | OCCUPIED STATE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV10 | WALL SENSOR | Wall Sensor Type | STE-9001 Temp | 1 |
| | | | STE-9021 Humidity | |
| | | | STE-9201 Motion | |
| | | | STE-9221 Humidity/Motion | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 Humidity/CO2 | |
| | | | STE-9501 Motion/CO2 | |
| | | | STE-9521 Humidity/Motion/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | None | |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9311A VAV WITH REMOTE ACTUATOR OBJECTS | | | | |
|--|------------------|----------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| Inputs | | | | |
| A11 | SPACE SENSOR | Space Sensor | KMC Type II Deg F | |
| A12 | SPACE SETPOINT | Space Setpoint | Table 4 | |
| A13 | DISCHARGE AIR | Discharge Air Temperature | KMC Type III Deg F | |
| A18 | PRIMARY POSITION | Primary Damper Position | 0-12 Volts | |
| A19* | PRIMARY DUCT | Primary Duct Pressure | NONE | |
| Outputs | | | | |
| A07 | ANALOG HEAT | Analog Heat | 0-100 % (0-10 V) | 0 |
| A08 | FAN SPEED | Fan Speed | 0_100% | 0 |
| A09 | AO_09 | Analog Output #9 | NONE | 0 |
| B01 | FAN | Fan | Unknown | Inactive |
| B02 | HT STAGE 1 | Heating Stage 1 | Unknown | Inactive |
| B03 | HT STAGE 2 | Heating Stage 2 | Unknown | Inactive |
| B04 | HT STAGE 3 | Heating Stage3 | Unknown | Inactive |
| B05 | PRI DAMPER CW | Primary Damper Clockwise | Unknown | Inactive |
| B06 | PRI DAMPER CCW | Primary Damper Counter Clockwise | Unknown | Inactive |
| Values | | | | |
| AV1 | SPACE TEMP | Space Temperature | Degrees F | 0 |
| AV2 | STPT REFERENCE | Setpoint Reference | Degrees F | 72 |
| AV3 | ACT COOL STPT | Active Cooling Setpoint | Degrees F | 74 |
| AV4 | ACT HEAT STPT | Active Heating Setpoint | Degrees F | 70 |
| AV5 | OCC CL STPT | Occupied Cooling Setpoint | Degrees F | 74 |
| AV6 | OCC HT STPT | Occupied Heating Setpoint | Degrees F | 70 |
| AV7 | UNOCC CL STPT | Unoccupied Cooling Setpoint | Degrees F | 80 |
| AV8 | UNOCC HT STPT | Unoccupied Heating Setpoint | Degrees F | 64 |
| AV9 | MIN CL STPT | Minimum Cooling Setpoint | Degrees F | 68 |
| AV10 | MAX HT STPT | Maximum Heating Setpoint | Degrees F | 76 |
| AV11 | MIN STPT DIFF | Minimum Setpoint Differential | Degrees F | 4 |
| AV12 | STBY_OFFSET | Standby Offset | Degrees F | 3 |
| AV13 | MIN COOL FLOW | Minimum Cooling Flow | Cubic Feet per Minute | 100 |
| AV14 | MAX COOL FLOW | Maximum Cooling Flow | Cubic Feet per Minute | 400 |
| AV15 | MIN HEAT FLOW | Minimum Heating Flow | Cubic Feet per Minute | 100 |
| AV16 | MAX HEAT FLOW | Maximum Heating Flow | Cubic Feet per Minute | 400 |
| AV17 | AUXILLARY FLOW | Auxillary Flow | Cubic Feet per Minute | 200 |
| AV18 | PRI K FACT | Primary K Factor | No Units | 904 |
| AV19 | PRI CORR SLOPE | Primary Correction Slope | No Units | 1 |
| AV20 | PRI CORR OFFST | Primary Correction Offset | Cubic Feet per Minute | 0 |
| AV21 | PRI LO FLOW CORR | Primary Low Flow Correction | No Units | 1 |
| AV22 | PRI FLOW STPT | Primary Flow Setpoint | Cubic Feet per Minute | 0 |
| AV23 | PRI RAW FLOW | Primary Raw Flow | Cubic Feet per Minute | 0 |
| AV24 | PRI ACTUAL FLOW | Primary Actual Flow | Cubic Feet per Minute | 0 |
| AV25 | AV_25 | Analog Value #25 | No Units | 0 |
| AV32 | MIN FAN SPEED | Minimum Fan Speed | Percent | 25 |
| AV33 | MAX FAN SPEED | Maximum Fan Speed | Percent | 100 |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9311A VAV WITH REMOTE ACTUATOR OBJECTS | | | | |
|--|------------------|-------------------------------|-----------------------|----------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| AV34 | AV_34 | Analog Value #34 | No Units | 0 |
| AV36 | DAT STPT | Discharge Air Temp Setpoint | Degrees F | 90 |
| AV37 | SAT CHANGEOVER | SAT Changeover Temperature | Degrees F | 72 |
| AV38 | LOCAL OVRD TIME | Local Override Timer | Minutes | 60 |
| AV39 | STANDBY TIMER | Standby Timer (motion) | Minutes | 15 |
| AV40 | OCCUPANCY TRIGGE | Occupancy Trigger | Minutes | 5 |
| AV41 | REL_HUMIDITY | Relative Humidity | Relative Humidity | 0 |
| AV43 | MEASURED MAX | Measured Maximum | Cubic Feet per Minute | 0 |
| AV44 | MEASURED MIN | Measured Minimum | Cubic Feet per Minute | 0 |
| AV45 | PRI SAVE MIN FLO | Primary Saved Minimum Airflow | Cubic Feet per Minute | 0 |
| AV46 | AV_46 | Analog Value #46 | No Units | 0 |
| AV47 | DAT MAXIMUM | Maximum DAT Setpoint | Degrees F | 90 |
| AV48 | CCW DMP POS | CCW Damper Position | Volts | 0 |
| AV49 | CW DMP POS | CW Damper Position | Volts | 0.01 |
| AV50 | DAMPER POSITION | Damper Position | Percent | 0 |
| AV51 | APP_ID | Application Identification | No Units | 0 |
| AV55 | CHNG OVER DELAY | Heating Change Over Delay | Minutes | 3 |
| AV56 | LOW AUTO OCC | Low Limit for Auto Occupy | Cubic Feet per Minute | 50 |
| AV57 | ROOM CO2 | Room CO2 Level | Parts per Million | 0 |
| BV1 | NEED AHU | Need For AHU | | Inactive |
| BV2 | NEED COLDER SPLY | Need For Colder Air Supply | | Inactive |
| BV3 | NEED MORE STATIC | Need For More Static Pressure | | Inactive |
| BV4 | LOCAL OVRD | Local Override Mode | | Inactive |
| BV5 | MOTION OVRD | Motion Override Mode | | Inactive |
| BV6 | MOTION SENSOR | Motion Sensor (Wall Stat) | | Inactive |
| BV7 | NEED HOTTER SPLY | Need For Hotter Air Supply | | Inactive |
| BV8 | SUPPLY AIR TYPE | Supply Air Type | | Active |
| BV9 | DAT LIMITING | Discharge Air Temp Limiting | | Inactive |
| BV10 | DIRECTION-CLOSE | Clockwise Close | | Inactive |
| BV11 | AUTO OCCUPANCY | Auto Occupancy Detection | | Inactive |
| BV12 | BALANCE MODE | Balance Mode | | Inactive |
| BV13 | DAT SENSOR | DAT Sensor Present | | Inactive |
| BV14 | PRI BAL TRIGGER | Primary Balance Trigger | | Inactive |
| BV15 | BV_15 | Binary Value #15 | | Inactive |
| BV40 | ICO_FAN | Fan Icon | | Inactive |
| BV41 | ICO_FAN_LOW | Icon Fan Low Speed | | Inactive |
| BV42 | ICO_FAN_MEDIUM | Icon Fan Medium Speed | | Inactive |
| BV43 | ICO_FAN_HIGH | Icon Fan Auto | | Inactive |
| BV44 | ICO_FAN_AUTO | Icon Fan Auto | | Inactive |
| BV45 | ICO_OCCUPIED | Icon Occupied | | Inactive |
| BV46 | ICO_STANDBY | Icon Standby | | Inactive |
| BV47 | ICO_COOLING | Icon Cooling | | Inactive |
| BV48 | ICO_HEATING | Icon Heating | | Inactive |
| BV49 | ICO_AUTO_MODE | Icon Auto Mode | | Inactive |
| BV50 | ICO_OVERRIDE | Icon Override | | Inactive |

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs.** Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

| BAC-9311A VAV WITH REMOTE ACTUATOR OBJECTS | | | | |
|--|----------------|-----------------------|------------------------------|---------|
| OBJECT | NAME | DESCRIPTION | UNITS or STATE | DEFAULT |
| MSV1 | OCCUPIED MODE | Occupied Mode | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| | | | MOTION OVERRIDE | |
| MSV2 | FAN CONFIG | Fantype Configuration | NONE | 1 |
| | | | SERIES | |
| | | | PARALLEL | |
| MSV3 | REHEAT | Reheat Type | NONE | 1 |
| | | | STAGED | |
| | | | MODULATING | |
| | | | FLOATING | |
| | | | TIME PROP | |
| MSV8 | OCCUPIED STATE | Occupied State | OCCUPIED | 1 |
| | | | STANDBY | |
| | | | UNOCCUPIED | |
| | | | LOCAL OVERRIDE | |
| MSV6 | WALL SENSOR | Wall Sensor Type | STE-9001 Temp | 1 |
| | | | STE-9021 Humidity | |
| | | | STE-9201 Motion | |
| | | | STE-9221 Humidity/Motion | |
| | | | STE-9301 CO2 | |
| | | | STE-9321 Humidity/CO2 | |
| | | | STE-9501 Motion/CO2 | |
| | | | STE-9521 Humidity/Motion/CO2 | |
| | | | STE-6014/7 | |
| | | | STE-6010 | |
| | | | None | |

***NOTE:** AI9 is for the **optional** air pressure sensor (in the BAC-9311A). All models of the BAC-9300A series have **8 standard** inputs—2 analog for the temp. sensor port and 6 universal inputs (software configurable as analog, binary, or accumulator on terminals).

NOTE: As a best practice when doing custom configuration and programming, **avoid reusing objects for custom programs that are reserved for KMC default programs**. Create new objects for custom programming instead. This avoids having custom objects being overwritten in the future during events such as a firmware upgrade.

APPENDIX: K FACTORS FOR VAV

To properly set up a VAV controller, the correct K factor for the VAV box must be entered into the controller. Typically, this is part of the airflow chart that the manufacturer places on the VAV unit. If this information is missing and not available from the manufacturer, use a generic K factor from the following chart as an approximate value.

| DUCT SIZE (INCHES) | K FACTOR | |
|-----------------------|----------|-----|
| | CFM | LPS |
| 4 (Round) | 265 | 8 |
| 5 | 357 | 11 |
| 6 | 460 | 14 |
| 7 | 652 | 19 |
| 8 | 890 | 27 |
| 9 | 1145 | 34 |
| 10 | 1443 | 43 |
| 12 | 1972 | 59 |
| 14 | 2771 | 86 |
| 16 | 3741 | 111 |
| 24 x 16 (Rectangular) | 6980 | 208 |

WE VALUE YOUR FEEDBACK!

Help us improve this document.

[Click here to take a 3-minute survey.](#)

Your input helps us make our documents clearer and more useful.

INDEX

Symbols

0–12 VDC
 Inputs [13](#)
 Outputs [14](#)
2-Pipe FCU [92](#)
2-Pipe vs. 4-Pipe FCU [52](#)
4–20 mA
 Inputs [14](#)
 Output Override Boards [17](#)
4-Pipe FCU [95](#)
10K and 1K Ohm [13](#)

A

Abbreviations, NetSensor Screen [28](#)
Accessories [4](#)
Active Inputs [13](#)
Actuator, Remote for VAV [19](#)
AC vs. DC Power [24](#)
Adapter, HPO-9005 Room Sensor [12](#)
ADVC [28](#)
AHU (Air Handling Unit) [63](#)
AI (Analog Inputs) [10](#), [13](#)
Airflow
 Balancing [33](#), [79](#)
 Setpoints Sequence [76](#)
 Troubleshooting Issues [41](#)
Analog
 Inputs (AI) [13](#)
 Outputs (AO) [14](#), [35](#), [40](#)
 Sensors (STE-6000) [12](#)
Application, Selecting [31](#)
AUMD [28](#)
AUX [28](#)
AUXH [28](#)
Auxiliary and Emergency Heat [62](#)
AXLK [28](#)

B

BAC-7xxx Cross-Reference [45](#)
BAC-58xx Cross-Reference [45](#)
BAC-5051E Router [21](#), [36](#)
BAC-5900A Series General Purpose [16](#)
BAC-9000A Series VAV Controller [32](#),
 [41](#), [70](#), [83](#)
BAC-9300A Series Unitary Controller
 [46](#), [47](#), [55](#), [63](#), [70](#), [92](#), [98](#), [101](#)
BAC-9311
 Connecting Remote Actuator [19](#)
 VAV Objects [104](#)
BACnet IP [22](#)
BACnet Objects [81](#)
Balancing VAV Airflow [32](#), [79](#)
BAUD [28](#)
Binary
 Inputs (BI) [13](#)
 Outputs (BO) [14](#)
BLNC [28](#)

C

Calibration [12](#), [32](#), [39](#)
CAN-5900 Series Expansion Modules
 [8](#), [16](#), [37](#)
Cautions [6](#)
CAV (Constant Air Volume) [46](#)
Changeover [50](#), [58](#), [66](#), [76](#)
CHNG [28](#)
CMLK [28](#)
CNFG [28](#)
CO2 Sensor [11](#), [28](#), [38](#)
Cold Start [35](#)
COMM [28](#)
Communication Issues [36](#)
Configuration [25](#), [27](#)
Connect [42](#)
Connections
 Ethernet [9](#)
 Ethernet Network [22](#)
 Inputs [9](#)
 MS/TP Network [20](#)
 Output Override Boards [14](#)
 Outputs [14](#)
 Power [23](#)
 Room Sensor Port [9](#)
 Switched Common [14](#)
Connect Lite (App) [25](#)
Connect (Software) [25](#)
Control Basic Programs [43](#)
Controller Cross-References [45](#)
Converge (Niagara) [25](#)
Cooling/Heating Changeover [50](#), [58](#),
 [66](#), [76](#)
Cross-References [45](#)
CVA [28](#)

D

DAEN [28](#)
Daisy-Chaining Ethernet [22](#)
Damper Operation [78](#)
DAT (Discharge Air Temperature) [51](#),
 [59](#), [67](#), [76](#)
Date and Time [43](#)
DCV (Demand Control Ventilation) [11](#),
 [28](#), [38](#)
DC vs. AC Power [24](#)
DDIR [28](#)
Defaults, Factory [31](#)
DEHU [28](#)
Dehumidification [50](#), [58](#), [66](#)
Delay, Fan [35](#)
Designing Web Graphics [25](#)
DHDF [29](#)
Diagnostics, VAV System [80](#)
D ID [29](#)
DIFF [29](#)
Digital. See Binary [13](#), [14](#)

Digital Sensor. See NetSensor

DMIN [29](#)

Dual Duct [79](#)

E

Economizer [61, 69](#)

EETM [29](#)

EIO (Expansion Input Output) [8](#)

Electric Heating (Two-Pipe Option) [53](#)

ELOC [29](#)

Emergency and Auxiliary Heat [62](#)

ENDH [29](#)

ENEC [29](#)

English Units [31](#)

ENST [29](#)

EOL (End of Line) [21](#)

EQDY [29](#)

ESD (Electrostatic Static Discharge) [6](#)

Ethernet [9, 22](#)

EVAL [29](#)

F

Factory Defaults [31, 35](#)

Fan

Control [61, 69](#)

Delay [35](#)

Icons [27](#)

Operation [53, 78](#)

Speed [27, 53](#)

Status [51, 59, 67](#)

FCU (Fan Coil Unit)

2-Pipe Objects [92](#)

4-Pipe Objects [95](#)

Sequences [47](#)

FNDY [29](#)

FNHT [29](#)

FNOC [29](#)

FNTF [29](#)

Fob, HPO-9003 NFC [25, 26, 37](#)

Foreign Device [22](#)

Four-Pipe vs. Two Pipe FCU [52](#)

FSPD [29](#)

Fuses (Network Bulbs) [37](#)

G

Ground

Circuit [14](#)

Earth [20](#)

Versus Switched (Relay) Common [14](#)

H

Handling Precautions [6](#)

HAO (Hand-Off-Auto) [16](#)

HPO-0055 Isolation Bulbs [8, 37](#)

HPO-0063 Output Override Jumper [18](#)

HPO-6700 Series Override Boards [18](#)

HPO-9003 NFC-Bluetooth/USB Module
[25, 26, 37](#)

HPO-9005 Room Sensor Adapter [12](#)

HPO-9901 Kit [38](#)

HPU (Heat Pump Unit) [55, 101](#)

HVA [29](#)

I

Icons [27](#)

Important Notices [6](#)

Inputs

0–12 VDC [13](#)

4–20 mA [14](#)

Passive [13, 14](#)

Pulse [14](#)

Troubleshooting [38](#)

Universal [9](#)

Installation [4, 9](#)

IP [22](#)

Isolation Bulbs (HPO-0055) [8, 37](#)

J

Jumper [18, 38](#)

K

K Factor [107](#)

KMC Connect [42](#)

KMD-11xx Cross-Reference [45](#)

L

LED Indicators [37](#)

M

MAC [29](#)

Maintenance [44](#)

MAX [29](#)

Menus [27](#)

Metric Units [31](#)

MIN [29](#)

Mixed Units [31](#)

MNCL [29](#)

MNDC [29](#)

MNDM [29](#)

MNFN [29](#)

MNHT [29](#)

Modes, Icons [27](#)

Modulating Heating and Cooling [52, 68, 77](#)

Motion Sensor [39, 49, 65, 74](#)

MS/TP Network [20](#)

MXCL [29](#)

MXDT [29](#)

MXFN [30](#)

MXHT [30](#)

N

NetSensor
 Balancing VAV [32](#)
 CO2 Sensor [11](#)
 Cross-Reference [45](#)
 Mapping to Objects [10](#)
 Menus [27](#)
 Replacements [44](#)
 Room Sensor Port [9](#)
 Troubleshooting [41](#)

Network
 Ethernet [22](#)
 MS/TP [20](#)

NFC
 Controllers [26](#)
 Disabling/Enabling [26](#)

NFC (Near Field Communication) [25](#),
 [26](#), [36](#)

Niagara (Converge) [25](#)

Notices [6](#)

O

OAT (Outside Air Temperature) [59](#), [67](#)

Objects, BACnet [81](#)

OCCL [30](#)

Occupancy Mode [27](#), [49](#), [57](#), [65](#), [74](#)

OCHT [30](#)

Offset, Setpoint [13](#)

Operation [5](#)

Outage, Power [35](#)

Outputs [35](#)
 4–20 mA [17](#)
 Analog (Universal) [40](#)
 Override Boards [16](#)
 Relay or Triac [40](#)
 Troubleshooting [40](#)

Override
 Occupancy [13](#), [27](#)
 Output Boards [17](#)

OVRD [30](#)

OVRT [30](#)

P

Passive Inputs [13](#), [14](#)

Passwords [26](#), [42](#)

Phasing
 CAN Expansion Module [36](#)
 MS/TP [20](#), [36](#)
 Power [41](#)

PID (Proportional Integral Derivative)
 Control Loops [51](#), [59](#), [67](#), [75](#)

PKFT [30](#)

PMAX [30](#)

PMIN [30](#)

Ports [9](#), [22](#)

Power
 Capacity and Phasing [41](#)
 Connecting to Controllers [23](#)
 Outage/Removal [35](#)
 Troubleshooting [38](#)

PRI [30](#)

Programming [25](#)

PSW [30](#)

Pulse Inputs [14](#)

R

Reheat [52](#), [60](#), [68](#), [77](#)

Reinitialize [31](#), [35](#)

Relays [17](#)

Remote Actuator [19](#)

Repeater [21](#)

Reset [31](#), [35](#)

Restart [31](#), [35](#)

Restore [31](#)

Reversing Valve [62](#)

RHTP [30](#)

Room Sensor. *See also* Sensors

Room Sensor Port [9](#)

Room Sensors (STE-xxxx) [10](#)

RSTR [30](#), [31](#)

RTDs [13](#)

RTU (Roof Top Unit) [63](#), [98](#)

RVA [30](#)

S

SAT (Supply Air Temperature) [76](#)

Schedules [43](#), [50](#), [58](#), [66](#), [75](#)

SC (Switched Common) [15](#)

SEC [30](#)

SENSORON [13](#)

Sensors
 Airflow [72](#)
 Cross-Reference [45](#)
 Motion [39](#), [57](#)
 Mounting and Maintenance [4](#)
 Temperature [39](#), [51](#), [72](#)

Sequences of Operations
 AHU [63](#)
 CAV [46](#)
 FCU [47](#)
 HPU [55](#)
 RTU [63](#)
 VAV [70](#)

Setpoints
 Airflow Operation [76](#)
 Offset (AV2) [13](#)
 Room Temperature Operation [48](#), [56](#),
 [64](#), [73](#)
 Troubleshooting [39](#)

SKFT [30](#)
SMAX [30](#)
SMIN [30](#)
Software [25](#)
Specifications [4](#)
S (Shield) Terminal [20](#)
Staged Heating and Cooling [60, 68, 78](#)
Standby [27, 49, 57, 65, 74](#)
Start (Reset), Cold or Warm [35](#)
Status [7](#)
STBO [30](#)
STBT [30](#)
STDY [30](#)
STE-6000 Series [12](#)
STE-9000 Series NetSensors. See Net-Sensor
STPT [30](#)
Submittal Sheets [5](#)
Support [6](#)
Surge Suppressor [21](#)
Switched (Relay) Commons [14](#)
Switches [21](#)
SYST [30](#)
System
 Diagnostics, VAV [80](#)
 Integration [81](#)
 Mode [50, 58, 66](#)

T

Temperature
 2-Pipe Water Supply Evaluation [52](#)
 Sensing [51, 59, 66](#)
 Troubleshooting [39](#)

Thermistor [12](#)
Time and Date [43](#)
Transformer, Power and Phasing [41](#)
Trends [43](#)
Triac [17](#)
Troubleshooting [36](#)
Two Pipe vs. Four Pipe FCU [52](#)

U

UNCL [30](#)
UNHT [30](#)
Units (English, Metric, or Mixed) [31](#)
Upgrade [44](#)

V

VA [30](#)
Valve Operation [52](#)
VAV (Variable Air Volume)
 Balancing [32](#)
 Cross-Reference [45](#)
 K Factor [107](#)
 Objects [104](#)
 Sequences [70](#)
 Troubleshooting [41](#)
Video Tutorials [5](#)

W

Warm Start [35](#)
Web Pages, User Interface and Configuration [22, 25, 43](#)
Wiring [20](#)
WorkBench, Converge for Niagara [25](#)
WST (Water Supply Temperature)
 Sensor [51](#)