




# Single Duct Variable Air Volume (VAV) Terminal Unit

## Series Fan Powered with Modulating Reheat

### Pressure Independent

#### Model: BAC-8005/8205

If controllers are to be networked together, turn **ON** EOL dip switches on the controllers at both physical ends of the network. Connect shield to earth ground at only one point.



External connections::




A11 = DAT SENSOR  
AO3 = MOD REHEAT  
AO4 = FAN SPEED  
BO5 = FAN ENABLE

#### NOTES:

1. Controller settings must be initially set using an STE-8XXX.
2. See SimplyVAV.com for accessories and additional details.

#### SEQUENCE OF OPERATION:

1. Changeover: If the discharge air temperature (DAT) drops below 72°F, cool air is said to be available. As the DAT rises above 76°F, warm air is said to be available. Any time warm air is available, auxiliary heat is locked out.
2. Cool air available: As space temperature rises above the cooling setpoint, the controller increases airflow. At a space temperature of 2°F above the cooling setpoint, maximum cooling airflow is maintained. On a decrease in space temperature, the controller reduces airflow. From cooling setpoint to heating setpoint, minimum cooling airflow is maintained. If the temperature drops further and heating is required, the auxiliary flow rate is maintained.
3. Warm air available: As space temp drops below the heating setpoint, the controller increases airflow. At a temperature 2°F below the heating setpoint, maximum heating airflow is maintained. On an increase in space temperature, airflow decreases. As space temperature rises above the heating setpoint, minimum heating airflow is maintained.
4. The fan is started during occupied and standby modes. During unoccupied mode, the fan starts on a call for heating only. The fan stops only during unoccupied mode when there is no call for heat. During occupied mode, the fan runs at maximum fan speed. During standby and unoccupied modes, the fan runs at minimum fan speed.
5. As the space temp drops below the heating setpoint, the heating output modulates open. As the space temp rises toward the heating setpoint, the heating output modulates closed. If the heating loop is less than 10%, the heating output remains at zero percent.
6. If DAT limiting is enabled and a DAT sensor is detected, the discharge air reheat setpoint is determined based on the heating loop. The discharge air setpoint is limited to a maximum of 15°F above space temperature.



© 2014 KMC CONTROLS, INC.



KMC CONTROLS, INC.  
19476 INDUSTRIAL DR.  
NEW PARIS, IN 46553  
PHONE: 574.831.5250  
FAX: 574.831.5252  
SimplyVAV.com

DRAWING TITLE: SERIES FPB W/MODULATING REHEAT

CREATION DATE: 3/7/2014

FILENAME: SS14007A\_SimplyVAV\_SER\_FAN\_MOD\_RHT

REVISION DATE: 3/7/2014

REVISION: INITIAL RELEASE